





Version


V2 - 17.09.24


Based on: 5F-Product Images-BS-16.09.24





12 - Antenna Cover

8 - SFP / Laser - Planet







14 - Mounting Bracket











2 - SFP - Spare



13 - Enclosure Cover










1 - DC Power Supply Socket



handles

9 – Earth Label

1 - DC Power Supply Socket

14 – Main Label
Main label will be going on the lower half of the right handside of the unit (opposite to air vent)

7 – Earth Point

6 – GNSS Antenna



6 – GNSS Antenna



