USER MANUAL

multi-function button

multi-function button Product Overview

We are delighted that you have chosen our multi-function button product. The stable protocol decoding, simple and fashionable display style, physical function buttons and display work perfectly together (displaying air conditioning temperature, air volume, battery preheating, etc.), combined with our unique ambient lighting effects, further highlight the uniqueness of the product.

Product Specifications:

Display resolution: 128*128

Interface support: Type_C charging interface

Input voltage: DC5V

Working current: 200MA

I. Product Installation Effect






II. The product can be installed by replacing the installation bracket of old 3\Y, refreshing 3, compatible with left and right steering vehicles, and the screen can be rotated



III. Product Function Introduction







- 1. We achieve the function of each button by pressing it up or down. Pressing down on a button activates the function on the left side of the icon, and pressing up activates the function on the right side.
- 2. The middle screen displays the air conditioning temperature, air volume, and ambient lighting. To change the mode, press the middle screen down, and each press will switch to the next mode.
- 3. When switched to air conditioning temperature or air volume, rotate the knob to adjust the temperature or air volume.
- 4.In the temperature adjustment interface, press three seconds to enter the degree, and then press three seconds to exit the degree.

IV. Product Ambient Lighting



- 1. When switched to ambient lighting mode, rotate the knob to select the light color.
- 2. The ambient lighting will also change with the turn signal lights.
- V.Battery Preheating and Sport Mode Display





The bottom left of the display shows the battery preheating, and the right side shows the sport mode position.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- -- Reorient or relocate the receiving antenna.
- -- Increase the separation between the equipment and receiver.
- -- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- -- Consult the dealer or an experienced radio/TV technician for help. To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm distance between the radiator and your body: Use only the supplied antenna.

Warranty Card

Pro	oduct		model:				
Da	te	of				_	
Ma	aintenanco	e					
Sig	nature of	maintenai					
Wa	arranty in	structions:					
1. The company provides a free warranty period, calculate							
fro	m the dat	te of purch	ase.				
2. Human damage, exterior wear, and damage caused by abnormal external conditions are							
no	t covered	by the fre	e warranty.				
3、	3. In case of product quality problems, please contact the company immediately, do not						
dis	assemble	it by your	self.				
4、	Please carry this card to the designated maintenance center for maintenance.						
En	iov the r	maintena	nce service p	rovided by our co	ompany with this c	ard.	