




User Guide


Advanced Home Security Solution

What's included


Your Sensforge security camera comes with everything you need for a quick and easy setup:




Camera




Power Adapter




Power Cable




Screw Kit



Quick Start Guide




SD Card





Wall Mount

Camera Layout



Push camera up
to reveal SD card slot
and reset button



Indicator Color	Meaning
Solid Blue	Device is On
Slow Blue Flash	Firmware Update is in Progress
Flashing Blue	Device is Connecting to Wi-Fi

Quick Setup Steps

Getting started is simple! Follow the steps below to set up your Sensforge security camera. In just minutes, you'll have your camera connected, mounted, and ready to protect your home.

1. Download the App

Find and install the Sensforge app from the App Store or Google Play.




Or




2. Create or Sign In

Open the app, then login or create a new account to get started.




3. Add the Camera to the App

In the app, select “Add Device” and follow the on-screen prompts to scan the QR code on the camera or manually input the device information.



Flip the camera over to reveal the QR code at the bottom.




Quick Setup Steps

Getting started is simple! Follow the steps below to set up your Sensforge security camera. In just minutes, you'll have your camera connected, mounted, and ready to protect your home.


4. Prepare the Camera for Pairing

Plug in the camera, tilt the lens upward to expose the reset button, and press and hold it for 10-15 seconds until the indicator light flashes. This signals the camera is ready to connect.



5. Connect to Wi-Fi

Select your home Wi-Fi network (2.4 Ghz or 5 Ghz) in the app and enter your Wi-Fi password to link the camera.



6. Complete Setup

Once the connection is established, name your camera and customize your settings for optimal use.

Wall Installation Guide


Easily mount your camera on any wall with these simple steps for secure and optimal placement.

1. Choose the Location

Select a spot with a clear view and access to a power outlet.


2. Mark and Drill Holes

Mark the screw holes and drill them. Insert wall anchors if needed.




3. Secure the Bracket

Attach the mounting bracket to the wall using screws.



4. Mount the Camera

Place the camera onto the bracket and ensure it's securely attached.



⚠ Important Warning: This camera is *not* waterproof and is designed for indoor use only. Using it outdoors or in wet conditions is at your own risk and may void the warranty. Ensure proper placement in a dry, protected environment to maintain functionality.

Indoor Camera Setup Instructions

Learn how to place your camera on any flat surface for clear and effective indoor surveillance.


1. Choose the Perfect Spot

Select a flat, stable surface with a clear view of the area you want to monitor. Ensure the spot is near a power outlet and within range of your Wi-Fi signal for interrupted performance.




2. Prepare the Camera

Remove any protective coverings and attach the power cable to the camera. Plug the other end of the cable into a nearby power outlet.



3. Adjust the Camera Angle

Adjust the camera's position and tilt to capture the desired area. Use the mobile app to test and fine-tune the viewing angle.




How to Access Customer Support

For any assistance or inquiries, simply access our customer support through the app. From the Help section, you can view helpful FAQs, connect with Tech Support, or contact the Help Desk for more detailed guidance.


1. Open the App Profile Settings

Tap on the Profile Icon to access your settings. This will take you to the main settings page where you can manage your account and preferences.



2. Access the Help Section

In the settings menu, click on the Help option. Here, you'll find various resources to assist you with any issues or questions regarding your security camera.




Troubleshooting Your Camera

If you're facing any issues with your security camera, follow these steps to quickly resolve common problems. For further assistance, our AI chat support is available to guide you.

Wi-Fi Connection Issues

Ensure your router is powered on and within range of the camera.



App Not Pairing

Restart the camera and ensure the correct Wi-Fi password is entered.



No Video Feed

Check that the camera lens is clean and free from obstructions.

FCC Statements

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Information

Please note that changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

FCC compliance: this equipment has been tested and found to comply with the limits for a class B digital device, pursuant to the part 15 of the FCC rules. These limits are designed to provide resonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instruction, may cause harmful intereference to radio communications. However, there is no guarantee that interference will not occur in a particular installation, if this equipment does cause harmful interference to radio or television reception, which can be detemined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Increase the separation between the equipment and reciever.
- Connect the equipment into an outlet on a circuit different from that to which the reciever is connected.
- Consult the dealer or an experienced radio/TV technician to help.

To maintain compliance with the FCC's RF exposure guidelines, this equipment should be installed and operated with a minimum distance of 20cm between the radiator and your body.

Use only the supplied antenna.

FCC Conditions

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Warranty Compliance

We are committed to delivering high-quality products that meet your expectations and provide reliable performance for years to come. To ensure customer satisfaction and peace of mind, this product is covered by a comprehensive one-year limited warranty. The terms and conditions of this warranty are designed to protect your investment while ensuring compliance with all relevant regulations and industry standards.

Warranty Coverage

The one-year limited warranty guarantees that the product is free from defects in materials and workmanship under normal use during the warranty period. If the device fails due to manufacturing defects or functional issues, we will repair or replace it at no additional cost to you, subject to the terms outlined in the warranty policy. This includes coverage for the internal components, casing, and any included accessories, provided they are used in accordance with the instructions in the manual.

Warranty Eligibility

To remain eligible for warranty coverage, you must adhere to the proper use and maintenance guidelines outlined in the user manual. Any unauthorized modifications, repairs, or improper handling may void the warranty. Additionally, warranty claims must be accompanied by proof of purchase, such as a receipt or invoice, which verifies the product's purchase date and authenticity.

Extended Warranty Options

For added peace of mind, we offer optional extended warranty plans to provide additional coverage beyond the standard one-year warranty period. These plans include enhanced services such as expedited repairs, accidental damage protection, and extended technical support.

Support and Documentation

For complete details about the warranty terms and conditions, including exclusions and coverage limits, please refer to the warranty section on our product page. If you have questions or need clarification, our dedicated support team is available to assist. We are proud to stand behind our products and are committed to resolving any issues promptly and professionally. Your satisfaction is our priority, and we are here to ensure your product operates reliably throughout its lifespan.

Company Statement

- (1) We have tried our best to ensure the completeness and accuracy of the materials. If you have any questions or disputes, we reserve the rights to provide clarification or interpretation.
- (2) We will update the content promptly based on product functionality and regularly modify the products or programs described in this information. Updates will be included in the new version without prior notification.
- (3) The content of this material is for customer reference only. There is no guarantee that it is exactly the same as the product. Please refer to the actual product for accurate information.
- (4) The camera parts shown in this instruction are for illustration purposes only and do not represent the purchased configuration.

Operating conditions:

Temperature: -10° to 45°C (14° to 113°F)
Humidity: 95% or less (non-condensing)