

140 mm

正
280 mm

反

英 法 德 意大利 西班牙

Warning:

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.



Smart music boxing target Instruction Manual

Installation method 1:

Installation method 2:



1. Stick the short strip on the back of the machine



3. Paste the back at a suitable height



2. Stick the long strip on the wall



4. Installation completed



Bluetooth connection: Long press and hold the "on/off" button for 3 seconds to turn on the device. Click the power button to switch to Bluetooth mode, and then turn on the Bluetooth on your phone. You can find the Bluetooth of the "boxing ring". If you don't want Bluetooth mode, click to switch.

Volume adjustment: There are a total of 5 volume levels. Click the "VOLUME" button to adjust the volume level. If you feel the volume is too loud, you can quickly switch the volume level by clicking on it.

Speed regulation: Click the "SPEED" button to adjust the speed, there are a total of 9 gears. The higher the speed gear, the faster the corresponding striking speed, which exercises reaction ability.

Sticker installation, Velcro installation
Easy to install, tear off the sticker and install directly, saving time and effort
Supports one click Bluetooth for faster connection,
You can play your favorite music freely

Warning:

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and
- (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.
NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna,
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

1

6

Método de instalación 1:

Pegatinas mágicas



1. pegue la tira corta en la parte posterior de la máquina



3. pegue la parte posterior a la altura adecuada

Método de instalación 2:

Pegatinas mágicas



2. pega tiras largas a la pared



4. se completa la instalación



Conexión bluetooth: presione la tecla "on / off" durante 3 segundos para apagar la tecla "on / off" y haga clic en la tecla on para cambiar al modo bluetooth, y luego abra el Bluetooth del teléfono móvil para encontrar el Bluetooth del "boxeo", si no desea el modo bluetooth, haga clic para cambiar.

Ajuste de volumen: un total de 5 tamaños de volumen, haga clic en el botón "volume" para ajustar el tamaño del volumen, si siente que el sonido es alto, puede hacer clic rápidamente para cambiar el tamaño del sonido.

Ajuste de velocidad: haga clic en el botón "speed" para ajustar la velocidad, cuanto más alta sea la velocidad de un total de 9 marchas, más rápida será la velocidad de golpe correspondiente para ejercitar la capacidad de respuesta.

Méthode d'installation 1:

Poster magique



1. Collez la bande courte à l'arrière de la machine



3. Collez le dos à la bonne hauteur

Méthode d'installation 2:

Poster magique



2. Collez de longues bandes sur le mur



4. Installation terminée



Connexion Bluetooth: appuyez longuement sur 3 secondes pour allumer et éteindre la touche "on / OFF" après avoir cliqué sur la clé on pour devenir le mode Bluetooth, puis le Bluetooth du téléphone est activé, vous pouvez trouver le Bluetooth du "disque de boxe", si vous ne voulez pas le mode Bluetooth, cliquez pour basculer.

Réglage du volume: 5 tailles de volume au total, la touche "volume" clique pour régler la taille du volume, les mots qui se sentent forts peuvent changer rapidement de taille de son en un clic.

Réglage de la vitesse: cliquez sur la touche "speed" pour ajuster la vitesse, un total de 9 vitesses plus le rapport de vitesse est élevé, plus la vitesse de frappe correspondante est rapide et exerce la réactivité.

Installation d'autocollants,
installation d'autocollants magiques,
installation facile, déchirer l'autocollant,
Support Bluetooth à une touche,
connexion plus rapide,
Peut jouer votre musique préférée comme vous le souhaitez

5

2

Installationsmethode 1:

Klettverschluss



1. Kleben Sie den kurzen Streifen auf die Rückseite der Maschine



3. Kleben Sie die Rückseite auf einer geeigneten Höhe

Installationsmethode 2:

Klettverschluss



2. Kleben Sie den langen Streifen an die Wand



4. Installation abgeschlossen



Bluetooth-Verbindung: Halten Sie die Taste "Ein/Aus" drei Sekunden lang gedrückt, um das Gerät einzuschalten. Klicken Sie dann auf die Ein-/Aus-Taste, um in den Bluetooth-Modus zu wechseln. Schalten Sie dann das Bluetooth-Gerät Ihres Telefons ein und Sie finden das Bluetooth für den "Boxing". Wenn Sie den Bluetooth-Modus nicht möchten, klicken Sie zum Umschalten.

Lautstärkeregelung: Es gibt insgesamt fünf Lautstärkeebenen. Klicken Sie auf die Schaltfläche "VOLUME", um die Lautstärke einzustellen. Wenn Sie das Gefühl haben, dass der Ton zu laut ist, können Sie die Lautstärke schnell durch Klicken umschalten.

Geschwindigkeitsanpassung: Klicken Sie auf die Schaltfläche "SPEED", um die Geschwindigkeit einzustellen. Es gibt insgesamt neun Gänge. Je höher der Gang, desto schneller die entsprechende Schlaggeschwindigkeit, die Reaktionsfähigkeit trainiert.

Montage von Aufklebern, Klettverschluss
Einfach zu installieren, den Aufkleber abzureißen und direkt zu installieren, spart Zeit und Mühe
Unterstützt ein Klick Bluetooth für schnellere Verbindung,
Sie können Ihre Lieblingsmusik frei spielen

Metodo di installazione 1:

Velcro



1. Stick la striscia corta sul retro della macchina




3. Incolla la schiena ad un'altezza adeguata

Metodo di installazione 2:

Velcro



2. Stick la striscia lunga sul muro



4. Installazione completata



Connessione Bluetooth: Premere a lungo e tenere premuto il pulsante "on/off" per 3 secondi per accendere il dispositivo, quindi fare clic sul pulsante di accensione per passare alla modalità Bluetooth. Quindi accendere il Bluetooth del telefono e si può trovare il Bluetooth per il "box ring". Se non si desidera la modalità Bluetooth, fare clic per commutare.

Regolazione del volume: Ci sono un totale di 5 livelli di volume. Fare clic sul pulsante "VOLUME" per regolare il livello del volume. Se si sente che il suono è troppo forte, è possibile cambiare rapidamente il livello del volume facendo clic.

Regolazione della velocità: Fare clic sul pulsante "VELOCITÀ" per regolare la velocità. Ci sono un totale di 9 marce. Più alta è la velocità di marcia, più veloce è la velocità di attacco corrispondente, che esercita la capacità di reazione.

Installazione di adesivi, installazione di velcro
Facile da installare, strappare l'adesivo e installare direttamente, risparmiando tempo e fatica
Supporta un clic Bluetooth per una connessione più veloce,
Puoi riprodurre la tua musica preferita liberamente

3

4

2025.1.17