

尺寸: 105x142mm

### FCC Caution

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:  
-- Reorient or relocate the receiving antenna.  
-- Increase the separation between the equipment and receiver.  
-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.  
-- Consult the dealer or an experienced radio/TV technician for help.  
The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

### Bluetooth audio ( WS-Y01 )

1. ① Power key
  - ① Power on: long press for 1.5 seconds.
  - ② Power off: long press for 3 seconds.
  - ③ Mode conversion: long press for 1.5 seconds.
  - ④ Play / pause: short press once.
  - ⑤ Answer / hang up: short press once to answer a call when calling, and short press once to hang up during a call.
  - ⑥ Reject call: double click when calling.
  - ⑦ Return call: when Bluetooth is still, double-click to repeat the last call number.
2. + short press once: play the next song  
long press: increase the volume.
3. - short press once: play the previous song  
long press: volume down.
4. Box function: (in Bluetooth mode,  
the two speakers will play each other automatically.)
5. Automatic station search: press the power button to turn to FM mode and double-click it quickly.

#### Power key / function conversion

Short press one song,  
long press volume up

Short press previous song,  
long press volume down

