

骨传导无线耳机

使用说明书


健康 · 舒适 · 释放双耳

Bone conduction wireless headset

User Manual

Health · Comfort · Release the ears

按键功能概述



外观展示



控制说明

开机: 耳机处于关机状态, 长按电源键, 保持3秒, 红蓝灯交替闪烁, 提示音响起;
关机: 耳机处于开机状态, 长按电源键, 保持3秒, 红灯长亮1秒熄灭, 提示音响起;
连接BT: 1.开机后进入配对状态, 此时打开您所要配对的设备蓝牙并搜索耳机, 点击蓝牙名YWD_H02进行配对, 提示音响起;
2.手动关闭蓝牙设备或耳机超出蓝牙信号范围, 打开设备蓝牙或3分钟内回到连接范围, 自动回连, 连接成功, 指示灯熄灭, 提示音响起; 3分钟蓝牙配对超时或回连不成功自动关机, 红灯常亮1秒, 提示音响起;
配对成功: 开机状态下, 耳机自动进入搜索配对模式, 配对成功, 指示灯熄灭, 提示音响起;
断开蓝牙: 1.耳机超出连接范围, 红蓝灯交替闪烁, 超过3分钟, 耳机关机, 提示音响起;
2.手机主动断开蓝牙, 红蓝灯交替闪烁, 提示音响起;
播放/暂停: 蓝牙连接状态下, 单击电源键功能, 指示灯熄灭;
上一曲: 音乐状态下, 双击“+”按键播放下一曲;
下一曲: 音乐状态下, 双击“-”按键播放上一曲;
音量加: 音乐和通话状态下, 单击“+”按键, 音量加一格, 音量最大时提示音响起;
音量减: 音乐和通话状态下, 单击“-”按键, 音量减一格;
语音助手: 连接蓝牙后, 未断开电话, 长按2秒“功能键”进入语音模式, 再长按2秒退出
接听/拒接/挂断: 来电状态下, 单击电源键为接听, 长按2秒电源键为拒接/通话状态
下, 单击电源键为挂断;
恢复出厂设置: 蓝牙未连接状态下, 一起长按“+”按键和“-”按键5秒, 红灯长亮1秒熄灭, 提示音响起, 表示恢复出厂设置成功;
耳机电量提示: 低电量状态下, 耳机红灯快闪, 提示音每1分钟提示一次, 5次后关机;
充电: 耳机正在充电, 红灯长亮; 耳机充满电, 蓝灯长亮;

充电器和电池

充电器和电池
使用任何充电器给本耳机充电前, 请先检查充电器的规格标注是否符合要求(建议充电器输出电压为: DC5V +/- 0.25V, 输出电流为: 100mA - 500mA), 充电电压过高极有可能损坏蓝牙耳机。

警告: 仅可使用经过认可与此配套的充电器, 使用其它规格的充电器可能违反对设备的认可和保修条款, 并可能导致危险。如果出厂是配充电线出货的, 需连接通过3C认证的充电器或电脑给其充电。禁止对本产品严重碰撞, 严重撞击有可能损坏电子主板及电池。


电池充电

本耳机使用内置式不可拆卸充电电池, 请勿尝试从耳机中取出电池, 以免损坏耳机。长期不使用耳机时, 请将其存放到干燥通风的地方, 并每隔两个月给其充电一次。

1.当连接的耳机闪红灯, 并听到滴滴的低电量提示音时, 表示耳机电量不足。如果继续使用会自动关机, 此时需要充电, 将充电器的连接线插头插入耳机插孔中。
2.将充电器插到交流电源插座上。
3.充电时指示灯亮红灯。如果充电未开始, 请断开电源与耳机的连接, 然后将其重新插入耳机再试一次。电池充满电后, 红灯熄灭, 蓝灯常亮, 此时断开充电器与电源插座和耳机连接。

4.实际通话时间和待机时间可能与手机、使用设置、使用方法和环境而存在差异。

佩戴说明



将耳机挂在颈后, 两侧扬声器贴在面颊骨, 调整佩戴的舒适度。

产品规格

音乐播放时间	-----标准状态:8小时	喇叭阻抗	-----8Ω±3dB
待机时间	-----10天	麦克灵敏度	------32±2dB
充电时间	-----2小时	产品重量	-----22g
BT版本	-----5.4	蓝牙连接距离	-----10米



品 牌 _____
产品名称 骨传导无线耳机
产品型号 _____
生产日期 _____
检 验 格 合格
检 验 员 _____

重要说明

- 本款耳机扬声器的正确佩戴位置为耳朵前方的面颊骨处, 请勿将扬声器置于耳内;
- 长时间听大音量的音乐可能会带来不适感, 请尽可能使用中等左右的音量, 避免长时间使用大音量;
- 无论音量大小, 使用耳机都将影响您对周围环境的感知, 使用耳机时多加注意;
- 切勿抛扔、坐压耳机或将其浸入盐水中; 耳机应远离火和高压设备;
- 不适合三岁以下儿童使用, 包含小零件;
- 请勿将其归类为生活垃圾, 而将其送往当地相应的电器电子设备回收站;

★若用户因违反以上警告内容造成的人身财产损失, 本公司不承担任何责任。

FCC Warning Statement:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.


This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

The device has been evaluated to meet general RF exposure requirement.



Brand _____
Product Name 骨传导无线耳机
Product Type _____
Production Date _____
Test _____ Qualified
Inspector _____

Overview Of Button Functions



Free your ears, feel free, listen to music while listening to the sound of the appearance; Listening to music, making phone calls, playing games, stereo sounds, real sound effects, clear and shocking; It is the best choice for your office, going out and driving!

Appearance display



Control Description

Power on: When the headset is turned off, press and hold the power button for 3 seconds, the red and blue lights flash alternately, and a prompt sound sounds;
Power off: When the headset is turned on, press and hold the power button for 3 seconds, the red light stays on for 1 second and then goes out, and a prompt sound sounds;

Connect BT: 1. After turning on, enter the pairing state. At this time, turn on the Bluetooth of the device you want to pair and search for the headset. Click the Bluetooth name YWD_H02 to pair, and the prompt sound sounds;

2. Manually turn off the Bluetooth device or the headset is out of the Bluetooth signal range, turn on the device Bluetooth or return to the connection range within 3 minutes, automatically reconnect, the connection is successful, the indicator light goes out, and the prompt sound sounds; 3 minutes Bluetooth pairing timeout or reconnection is unsuccessful, the headset automatically shuts down, the red light stays on for 1 second, and the prompt sound sounds;

Pairing success: When the headset is turned on, it automatically enters the search pairing mode, the pairing is successful, the indicator light goes out, and the prompt sound sounds;

Disconnect Bluetooth: 1. The headset is out of the connection range, the red and blue lights flash alternately, and the headset shuts down after 3 minutes, and the prompt sound sounds;

2. The phone actively disconnects Bluetooth, the red and blue lights flash alternately, and a prompt sound sounds;

Play/Pause: When Bluetooth is connected, click the power button and the indicator light goes out;

Previous song: When the music is on, double-click the “+” button to play the previous song;

Next song: When the music is on, double-click the “-” button to play the previous song;

Volume plus: When the music is on or in a call, click the “+” button to increase the volume by one level, and a prompt sound sounds when the volume is at maximum;

Volume minus: When the music is on or in a call, click the “-” button to decrease the volume by one level;

Voice assistant: After connecting Bluetooth, the voice assistant will automatically stop playing the music. Phone, long press the “-” function key for 2 seconds to enter the voice mode, and long press it for 2 seconds to exit; Answer/Reject/Hang up: In the incoming call state, single-click the power button to answer, long press the power button for 2 seconds to reject; in the call state, single-click the power button to hang up;

Restore factory settings: Bluetooth not connected, long press the “+” button and the “-” button for 5 seconds, the red light will stay on for 1 second and then go out, and the prompt sound will sound, indicating that the factory settings have been restored successfully;

Earphone low battery prompt: In the low battery state, the earphone red light flashes quickly, the prompt sound prompts once every 1 minute, and a prompt sound sounds after 5 times;

Charging: The earphone is charging, the red light is on; the earphone is fully charged, the blue light is on;

Chargers and Batteries

Charger and battery

Before using any charger to charge the headset, please check whether the specifications of the charger meet the requirements (recommended charger output voltage is: DC5V +/- 0.25V, the output current is: 100mA - 500mA), the charging voltage is extremely high and it is possible to damage Bluetooth headset.

WARNING: Only use chargers approved with this accessory. Use of other types of chargers may violate approval and warranty terms, and may cause danger, if the factory is shipped with a charging cable, you need to connect a 3C certified Charger or computer. It is forbidden to severely collide with this product. Serious impact may damage the electronic motherboard and battery.

Charge the battery

This headset uses a built-in non-removable rechargeable battery. Do not attempt to remove the battery from the headset, as it may damage the headset. When you are not using the headset, store it in a dry and ventilated place and charge it every two months. 1. When the connected headset flashes red and you hear a low battery sound, it means that the headset is low on power. If you continue to work it will automatically shut down. At this time, you need to charge, plug the charger's cable into the headphone jack.

2. Plug the charger into an AC power outlet.

3. The red indicator light is on when charging. If charging does not start, disconnect the power supply from the headset, then plug it back into the headset and try again. When the battery is fully charged, the red light goes out and the blue light is always on.

4. The actual call time and standby time may differ from the phone, usage settings, usage and environment.

Wearing Instruction



Hang the earphones behind the neck and attach the speakers on the sides to adjust the wearing comfort.

Product Specifications

Music playing time	-----Standard status: 8 hours	Speaker impedance	-----8Ω±3dB
Standby time	-----10 days	Mike sensitivity	------38±2dB
Charging time	-----2 hours	Product weight	-----22g
BT version	-----5.4	Connection distance	-----10m

Important

- The correct position of this headset speaker is the cheek bone in front of the ear. Do not put the speaker in the ear.
- Listening to high volume music for a long time may bring discomfort, please try to use a medium or so volume as much as possible to avoid using large volume for a long time;
- Regardless of the volume, using headphones will affect your perception of the surrounding environment. Pay more attention when using headphones;
- Do not throw, sit or press the headset or immerse it in salt water; Keep the headset away from fire and high voltage equipment;
- Not suitable for children under three years old, including small parts;
- Do not classify it as domestic waste, and send it to the corresponding local electrical and electronic equipment recycling station;

★The company will not bear any responsibility for personal and property damage caused by the violation of the above warning content.