


Smart Projector



※Quick Installation Guide※




Attention

Please read this manual carefully before use and keep it for future reference.


- 1.The projector is non dustproof or waterproof.
- 2.In order to reduce the risk of fire and electric shock, do not expose the projector to rain and fog.
- 3.Please use the original power adapter. The projector should work under specified rated power supply.
- 4.When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain. Children should use the projector under the supervision of adults.
- 5.Do not cover the vents of projector. Heating will reduce the life of projector and cause danger.
- 6.Regularly clean projector vents, or dust may cause cooling malfunction.
- 7.Do not use the projector in greasy, damp, dusty or smoky environment. Oil or chemicals will cause malfunction.
- 8.Please handle with care during daily use.
- 9.Please cut off the power if the projector is out of use for long time.
- 10.Non-professionals are forbidden to disassemble the projector for testing and maintenance.

Structure description

This manual is for reference only. It is subject to change without prior notice. Hotack reserves the right of final interpretation.




Remote Component and Functions




Switch in the Applications

Click on "My apps" to view installed programs, click program icon to switch between applications. Move to "My Apps", click OK to enter. All Apps' can be clearly distinguished from the icons.



Settings

Enter to setup Networking, Bluetooth, Language, Other Setting, Projection, Audio, Date And Time



Networking Setting

Settings - Networking Setting - WIFI setting, WIFI "ON", select objective WIFI ID and input password to connect internet.




BT Setting

Settings - BT setting, BT "ON", click Refresh Device and choose objective device to pair.



Language Setting

Settings - Language Setting, enter to setup language and select input method.



Other Setting

Setting - Other Setting, enter to get Application setting, Factory Reset Setting, and Developer opinions.

