

## Use it to explain the book

**Before using this product, please take a few minutes to read this manual carefully.**

### **One: Instructions for use**

- Long press the button for 1.5 seconds to turn on, the motor vibrates, the manual version enters the standby mode LED light is on, the APP version enters the standby mode LED light is blinking. Short press the key, the motor in 1-10 mode cycle frequency conversion.

- DC charging, charging 1Hz flash, full of long bright, can not work when charging.

- The package contains a charging cable that connects the USB first to a USB power adapter or USB port.

- Charging state: light flashing.

- Full power: the light is on.

### **Two: maintenance and maintenance**

- Clean and dry the water with clean water before and after use, away from high temperature, low temperature and humid environment

- If you do not use this product for a long time, please charge it every three months

- This product is only suitable for adults

- Do not use excessive force during use

- Do not soak in water and high temperature environment for a long time

- Please do not put this product into the trash can should be treated as old electronic and electrical products

### **Three: APP download(Only for products with APP function)**

#### **IOS system**

- Search for "Mu Se" in the APP STORE to download the installation and update

- Scan the QR code on the right with your phone. Follow the prompts to install "Mu Se "APP



#### **Android system**

- Search for "Mu Se" in the mobile phone store to download and install Scan the QR code next to download

- Click the "Mu Se" icon to enter the APP, please note first time login Copies of the

- Click "New User Registration" and use your mobile phone number or email address to complete Sign in

- After registration, enter the account and password to log in to the APP Device binding

- The customer needs to bind the device after the first login

- Click "+" to display the device binding scan box

- Scan the QR code, such as successful scanning, can also

Bind with input number 5881

- Long press the device icon to delete the device

In addition to and device name changes

- After the device is deleted, if the customer wants to restore it, it needs to be restored

Binding code of the new scanning device



## **FCC Warning**

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.