



**Pairing Instructions:**  
1. To start the pairing process turn on the Bluetooth® device



2. Open the charging case and remove the earbuds. They will automatically turn on and start searching for a Bluetooth® device.

3. Go to your Bluetooth® settings on your device and click on **OWS-15**. When the earbuds are paired successfully you will hear a voice prompt indicating that they are paired successfully.

**Please note:** make sure the two devices via Bluetooth® devices are within 30 feet in order for them to be paired.

Once the earbuds are paired successfully, they will reconnect to the device automatically when turned back on.

**Multi-Function Key**

- **Answer The Call:** Touch the left or right earbud 1 time
- **Hang Up:** Touch the left or right earbud 1 time
- **Reject The Call:** Touch the left or right earbud for 2 seconds
- **Play/Pause Music:** Touch the left or right earbud 1 time
- **Increase Volume:** Touch the right earbud 3 times
- **Decrease Volume:** Touch the left earbud 3 times
- **Next Track:** Touch the right earbud 2 times
- **Previous Track:** Touch the left earbud 2 times
- **Activate Voice Assistant:** Touch the left or right earbud for 2 seconds release when you hear the beep

**Specifications: 5.1**

- **Bluetooth® Version:**
- **Opening Distance:** 30 Feet
- **Battery Capacity:** 200 mAh
- **Music Playtime:** 3 Hours
- **Charge Time:** 1 Hour

**Simultaneous translation**

Supports 115 language translations



**Low Battery Alert**

When the earbud battery is low it will play the warning sound until it shuts off.

**Charging the Earbuds & Case**

**Charging the Earbud Case:** Connect the earbud case and will charge by using the Type C USB cable provided.

**Charging the Earbuds:** Place the earbuds in the charging case. The case will automatically charge earbuds. The red LED light indicates the earbuds are charging and will turn off when they are fully charged.

**Turn On/Off**

The earbuds will automatically turn on when they are taken out of the charging case. If the earbuds do not automatically turn on, long press the earbud for 3 seconds to power on.

The earbuds will automatically turn off once they are placed in the charging case. You can also long press the earphones for 5 seconds to power off.

Chinese	Danish (Denmark)
English	Greek (Greece)
Arabic	Estonian (Estonia)
German	Basque
Spanish	Persian (Iran)
French	Portuguese (Brazil)
Italian	Urdu (India)
Japanese	Galician
Korean	Gujarati (India)
Russian	Hebrew (Israel)
Vietnamese	Kosovian (Kosovo)
Portuguese	Hungarian (Hungary)
Hindi	American (American)
Indonesian	Indonesian (Indonesia)
Thai	Georgian (Georgia)
Bahasa Melayu	Kazakh (Kazakhstan)
Chinese	Marathi (India)
Burmese	Uyghur (Uyghuristan)
Traditional Chinese	Armenian (Armenia)
Japanese	Macaronesian (North Macedonia)
Cantonese	Tajik (Tajikistan)
Turkish	Mongolian (Mongolia)
Afrikaans (Afrikaans)	Hebrew (Israel)
Azerbaijani (Latin Azerbaijan)	Maltese (Malta)
Bulgarian (Bulgaria)	Written Norwegian (Norway)
Basque (Basque)	Tamil (Tamil)
Spanish (Spain)	Dutch (Belgium)
Georgian (Georgia)	Urdu (India)
Czech (Czech)	Polish (Poland)
Welsh (Wales)	Yiddish (Yiddish)

Gujarati (India)	Spanish (Dominican Republic)
Urdu (India)	Spanish (Spain)
Hebrew (Israel)	Spanish (Portugal)
Portuguese (Brazil)	Spanish (Mexico)
Urdu (India)	Spanish (Panama)
Galician	Spanish (Peru)
Gujarati (India)	Spanish (Paraguay)
Hebrew (Israel)	Spanish (Colombia)
Kosovian (Kosovo)	Spanish (Venezuela)
Hungarian (Hungary)	Spanish (Cuba)
American (American)	Spanish (Chad)
Indonesian (Indonesia)	Spanish (Czech Republic)
Georgian (Georgia)	Spanish (Slovakia)
Kazakh (Kazakhstan)	Spanish (Slovenia)
Marathi (India)	Spanish (Serbia)
Uyghur (Uyghuristan)	Spanish (Croatia)
Armenian (Armenia)	Spanish (Bosnia and Herzegovina)
Macaronesian (North Macedonia)	Spanish (Montenegro)
Tajik (Tajikistan)	Spanish (Albania)
Mongolian (Mongolia)	Spanish (Kosovo)
Hebrew (Israel)	Spanish (Cyprus)
Maltese (Malta)	Spanish (Turkey)
Written Norwegian (Norway)	Spanish (Azerbaijan)
Tamil (Tamil)	Spanish (Georgia)
Dutch (Belgium)	Spanish (Armenia)
Urdu (India)	Spanish (Azerbaijan)
Polish (Poland)	Spanish (Azerbaijan)
Yiddish (Yiddish)	Spanish (Azerbaijan)

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
  - Increase the separation between the equipment and receiver.
  - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
  - Consult the dealer or an experienced radio/TV technician for help.
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

材质：105g 铜板纸，四折，双面印刷