

1	2	3	4	5	6	7	8
版本	更改内容			设计	更改日期		

**APP蓝牙无线跳蛋
使用说明书**

70 mm

90 mm

产品信息

名称：APP 蓝牙无线跳蛋
颜色：紫、玫红
材质：医用硅胶+ ABS
供电：锂电池

充电：约 1 小时(充电闪烁,充满长亮)
噪声：小于 50 分贝
模式：9-频震动
距离：5-10 米

使用方法

1、扫描 (图 2 或首页) 二维码进入下载页面
2、依 (图 4) 下载界面提示下载并安装软件
3、长按 (图1) 跳蛋开/关机按键 2 秒,启动跳蛋(指示灯亮)
4、运行 (图3) 蓝牙APP进入登录界面,国内用户可使用手机号码和邮箱登录,国外用户仅可使用邮箱登录 (图3-1),登录成功后进入趣玩界面 (图5) 点击“+”添加情趣设备,扫码 (图6-1) 后添加设备,设备添加后,APP界面会显示产品图标,长按可修改名称或删除设备 (图6),点按产品图标进入模式选择界面 (图7),左右划动可选择“经典模式”、“音乐模式”、“划一划”、“摇一摇”、“互动模式”。点击任意模式,产品会进入相应的模式界面,在“音乐模式”下 (图8),选择相应的播放器,播放歌曲,产品随着音乐的旋律而震动。
5、在手机APP的互动界面,点击“+”添加好友,在好友列表中点击好友“确定”后可以与好友互动,该模式有三种互动方式“视频互动”、“玩具互动”、“文字互动”。本机已连接产品时,右上角的蓝牙图标为蓝色,未连接为白色 (图9);当互动的双方都有连接设备时,就能有趣地互相控制对方的设备,界面底部可以输入文字信息进行互动。
6、登录模式为单机模式时,部分功能不可使用。

使用指南

急速体验,扫码下载

图 1 图 2 图 3 图 3-1 图 6-1

图 4 图 5 图 6 图 7 图 8 图 9

Instructions of APP Bluetooth Smart Egg Shaped Vibrator

Product information

Name: APP Bluetooth wireless jump
Color: purple, rose red
Material: medical silicon gel + ABS
Power supply: lithium battery
Charging: about 1 hour (charging flash, full of long light)
Noise: less than 50 dB
Mode: 9-frequency vibration
Distance: 5-10m

Using method

1. Scan the QR code (Fig. 2 or home page) to enter the download page.
2. Download and install the software according to the download interface (Fig. 4).
3. Long press (Fig. 1) egg jumping on / off button for 2 seconds to start egg jumping (indicator light is on).
4. Run the app (Figure 3), and enter the login interface. Domestic users can log in with their mobile phone number and email address, while foreign users can only log in with their email address (Figure 3-1). After successful login, enter the fun play interface (Figure 5). Click “+” to add a fun device and scan the code (Figure 6-1) to add a device. After the device is added, the app interface will display a product icon. Long press to modify the name or delete the device (Figure 6). On the product icon, click the icon to enter the mode selection interface (Figure 7). Swipe left and right to select “classic mode”, “music mode”, “swipe”, “shake”, “interactive mode”. Click any mode and the product will enter the corresponding mode interface. In the “music mode” (Figure 8), select the corresponding player to play the song. The product vibrates with the melody of the music.
5. In the interactive interface of mobile app, click “+” to add friends, and click friends in the friends list. After “OK”, you can interact with friends. There are three interactive modes in this mode: “video interaction”, “toy interaction” and “text interaction”. When the product is connected, the Bluetooth in the upper right corner is blue, but not white (Fig. 9); when both sides of the interaction have connected devices, they can control each other's devices interestingly, and text messages can be entered at the bottom of the interface for interaction.
6. Some functions cannot be used when login mode is single mode.

User Guide

Experience, scan and download

Figure 1 Figure 2 Figure 3 Figure 3-1 Figure 6-1

Figure 4 Figure 5 Figure 6 Figure 7 Figure 8 Figure 9

单位：PCS
尺寸：140*90mm
工艺要求：对折 成型尺寸 70X90mm

材质：128g 铜版纸
表面处理：四色双面印刷
档案比例：1 : 1

105020225 APP 跳蛋说明书 140*90mm 128g铜版纸 四色双面印刷 增加产品二维码 中/英文
对折 成型尺寸 70*90mm

设计	日期	产品型号	版本	说明书
审核	日期	APP	公差	±1mm
批准	日期	第1页,共1页		

Safiman 鸿记铺科技

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.