

<h3>OPINUS 音贝奇</h3> <p>—— 真无线蓝牙耳机 ——</p> <p>Real 2 Pro 使用说明书</p> <p>扫描下方二维码可下载电子版说明书</p>	<p>轻触感应区 (耳机柄 1/3 位置)</p> <p>重触感应区 (耳机柄 1/3 位置)</p>	<h3>4.连接</h3> <p>蓝牙直接连接，打开充电盒上盖。 打开手机蓝牙并搜索“YINPAGE Real 2 Pro”进行连接。配对成功后，长按使用，无需重复配对。</p> <h3>3.充电</h3> <p>将耳机放入充电盒，盖合后会上盖，即可为耳机充电。 (注意：无法连续充电，5.5秒时自动关机)</p> <h3>二、功能操作</h3> <table border="1"> <thead> <tr> <th>按键功能</th><th>操作</th><th>提示音</th><th>指示灯</th></tr> </thead> <tbody> <tr> <td>1.开机</td><td>耳机开盖后即可自动开机</td><td>-</td><td>-</td></tr> <tr> <td>接听/挂断</td><td>单击</td><td>/</td><td>/</td></tr> <tr> <td>播放/暂停</td><td>单击</td><td>/</td><td>/</td></tr> </tbody> </table>	按键功能	操作	提示音	指示灯	1.开机	耳机开盖后即可自动开机	-	-	接听/挂断	单击	/	/	播放/暂停	单击	/	/	<table border="1"> <thead> <tr> <th>上一首</th><th>双点左键</th><th>/</th><th>/</th></tr> </thead> <tbody> <tr> <td>下一首</td><td>双击右键<th>/</th><th>/</th></td></tr> <tr> <td>音量加</td><td>长按左键<th>/</th><th>/</th></td></tr> <tr> <td>音量减</td><td>长按右键<th>/</th><th>/</th></td></tr> <tr> <td>降噪模式</td><td>三击右键</td><td>普通/通透/降噪</td><td>/</td></tr> <tr> <td>游戏模式</td><td>三击左键</td><td>游戏模式/静音模式</td><td>/</td></tr> <tr> <td>语音助手</td><td>双点左键</td><td>唤醒</td><td>/</td></tr> <tr> <td>充电提示</td><td>当电池电量低于 2v 时</td><td>短促音</td><td>自行熄灭</td></tr> <tr> <td>低电提醒</td><td>当电池电压低于 3.1v 时耳机自动关机</td><td>长促音</td><td>白灯闪三次</td></tr> <tr> <td>恢复出厂设置</td><td>耳机盒在完全充满电的情况下，长按充电仓上盖 10 秒，完成充电仓电量重置约需 3s</td><td>-</td><td>白、绿三色同时亮起 1s 后重新开机</td></tr> <tr> <td>耳机充电</td><td>将耳机放入充电盒并盖合即可自动充电</td><td>/</td><td>充电白灯常亮 充电器亮红灯</td></tr> </tbody> </table>	上一首	双点左键	/	/	下一首	双击右键 <th>/</th> <th>/</th>	/	/	音量加	长按左键 <th>/</th> <th>/</th>	/	/	音量减	长按右键 <th>/</th> <th>/</th>	/	/	降噪模式	三击右键	普通/通透/降噪	/	游戏模式	三击左键	游戏模式/静音模式	/	语音助手	双点左键	唤醒	/	充电提示	当电池电量低于 2v 时	短促音	自行熄灭	低电提醒	当电池电压低于 3.1v 时耳机自动关机	长促音	白灯闪三次	恢复出厂设置	耳机盒在完全充满电的情况下，长按充电仓上盖 10 秒，完成充电仓电量重置约需 3s	-	白、绿三色同时亮起 1s 后重新开机	耳机充电	将耳机放入充电盒并盖合即可自动充电	/	充电白灯常亮 充电器亮红灯	<h3>三、产品参数</h3> <table border="1"> <thead> <tr> <th>播放时间</th><td>约8小时</td><th>连接距离</th><td>10M</td></tr> </thead> <tbody> <tr> <td>待机时长</td><td>>95天</td><td>通话时长</td><td>约5小时</td></tr> <tr> <td>麦克风灵敏度</td><td>-42±1dB</td><td>频率范围</td><td>20-20000Hz</td></tr> <tr> <td>耳机阻抗</td><td>50mΩ</td><td>喇叭</td><td>10mm</td></tr> <tr> <td>充电仓电池</td><td>800mAh</td><td>充电时间</td><td><2小时</td></tr> </tbody> </table>	播放时间	约8小时	连接距离	10M	待机时长	>95天	通话时长	约5小时	麦克风灵敏度	-42±1dB	频率范围	20-20000Hz	耳机阻抗	50mΩ	喇叭	10mm	充电仓电池	800mAh	充电时间	<2小时	
按键功能	操作	提示音	指示灯																																																																																		
1.开机	耳机开盖后即可自动开机	-	-																																																																																		
接听/挂断	单击	/	/																																																																																		
播放/暂停	单击	/	/																																																																																		
上一首	双点左键	/	/																																																																																		
下一首	双击右键 <th>/</th> <th>/</th>	/	/																																																																																		
音量加	长按左键 <th>/</th> <th>/</th>	/	/																																																																																		
音量减	长按右键 <th>/</th> <th>/</th>	/	/																																																																																		
降噪模式	三击右键	普通/通透/降噪	/																																																																																		
游戏模式	三击左键	游戏模式/静音模式	/																																																																																		
语音助手	双点左键	唤醒	/																																																																																		
充电提示	当电池电量低于 2v 时	短促音	自行熄灭																																																																																		
低电提醒	当电池电压低于 3.1v 时耳机自动关机	长促音	白灯闪三次																																																																																		
恢复出厂设置	耳机盒在完全充满电的情况下，长按充电仓上盖 10 秒，完成充电仓电量重置约需 3s	-	白、绿三色同时亮起 1s 后重新开机																																																																																		
耳机充电	将耳机放入充电盒并盖合即可自动充电	/	充电白灯常亮 充电器亮红灯																																																																																		
播放时间	约8小时	连接距离	10M																																																																																		
待机时长	>95天	通话时长	约5小时																																																																																		
麦克风灵敏度	-42±1dB	频率范围	20-20000Hz																																																																																		
耳机阻抗	50mΩ	喇叭	10mm																																																																																		
充电仓电池	800mAh	充电时间	<2小时																																																																																		
<h3>四、产品安全信息</h3> <p>在使用本产品前请阅读所有的提示和警告。不规范使用将会给产品或人身安全带来损害。</p> <ol style="list-style-type: none"> 产品内含电池，请勿将本产品存放在阳光直射或明火等过热环境中。请勿将本产品存放在高温、强光及强磁环境下。 产品不可放置在火源附近等恶劣环境中，禁止敲击、投掷、穿刺、挤压或投入水中；若出现脱落、请勿使用。 产品使用寿命：45℃以下。 请勿违反说明书内容不当使用，造成产品损坏或危及人身安全财产受损，后果自行承担。 非专业人士严禁拆解本产品，否则可能会导致起火，甚至彻底报废本产品。 请勿使用超出本产品电流负载量（用电器），超负荷会触发自动停止工作。 请按照用户手册的指示对耳机充电触点进行清洁，以避免长期污垢导致耳机无法充电或开机的问题。 请勿将本产品置于水中（或洗衣液中），若产品出现进 	<p>水情况，请耐心等待其自然晾干后再使用。</p> <ol style="list-style-type: none"> 防腐蚀：除珍珠壳配件物料，避免儿童无法接触到的位置，防止误食，切勿置于水中，避免产生激烈化学反应，影响人身财产安全，后果自行承担。 <p>电子产品含有有害物质清单：</p> <table border="1"> <thead> <tr> <th>有害物质或元素名称</th><th>塑料零件</th><th>金属零件</th><th>线路板</th><th>线缆</th></tr> </thead> <tbody> <tr> <td>铅</td><td>EL</td><td>EL</td><td>EL</td><td>EL</td></tr> <tr> <td>镉</td><td>EL</td><td>EL</td><td>EL</td><td>EL</td></tr> <tr> <td>六价铬</td><td>EL</td><td>EL</td><td>EL</td><td>EL</td></tr> <tr> <td>多溴联苯或多溴二苯醚</td><td>EL</td><td>NA</td><td>EL</td><td>EL</td></tr> </tbody> </table> <p>本表格依据 GB/T 17534《电子信息产品有害物质限制》制定。 注：EL=豁免浓度，X=不确定，NA=不含。 执行标准：GB/T 26577-2011</p>	有害物质或元素名称	塑料零件	金属零件	线路板	线缆	铅	EL	EL	EL	EL	镉	EL	EL	EL	EL	六价铬	EL	EL	EL	EL	多溴联苯或多溴二苯醚	EL	NA	EL	EL	<h3>五、包装清单</h3> <ul style="list-style-type: none"> 耳机*1 大小中号耳塞*1 充电线*1 说明书+保修卡*1 <h3>六、保修政策</h3> <ol style="list-style-type: none"> 签收之日起7天无理由退货，15天免费售后（如：天然、劣等件等），非质量问题退换货邮费由消费者承担，再次发货的邮费由商家承担，如有发错物品，请一并寄回。 如您是在当地门店购买，您可到当地售后服务中心享受本公司提供的自购买之日起15天包换服务，如当地无售 	<p>后服务中心，可委托经销商进行包换服务。</p> <p>3. 经所购产品的商品，经本公司检测判定后，可享受12个月(产品质保期限)保修服务，服务方式为客户维修；随机配件为消耗品，不在保修范围内。</p> <h3>非保修条例</h3> <ol style="list-style-type: none"> 未按规定的修、用、维护、滥用、盗窃、事故、改动、篡改或修改标注、仿伪标识； 产品原序列号有涂改、替换、篡改等现象； 提供凭证上的号码，编号与产品实物不符的； 产品超过本公司规定保质期保期； 正常使用意外致外表面损伤； 外包装及内部的产品，销售人员承诺的产品之外的服务及附带的赠品和附件； 不可抗力，如产品长时间暴露在非常温度、湿度环境造成的性能损失； 未经操作者同意，人为拆毁、擅自改装造成产品损坏，因不可抗力造成的损失，恕不赔偿。 <h3>保修记录表</h3> <table border="1"> <thead> <tr> <th>problems</th><th>Doubtless on the left side</th><th>/</th><th>/</th></tr> </thead> <tbody> <tr> <td>not booting</td><td>Double-click on the right ear</td><td>/</td><td>/</td></tr> <tr> <td>volume up/down</td><td>Long press on the right ear</td><td>/</td><td>/</td></tr> <tr> <td>volume reduction</td><td>Long press on the left ear</td><td>/</td><td>/</td></tr> <tr> <td>reconnection mode</td><td>Three clicks on the right ear</td><td>/</td><td>/</td></tr> <tr> <td>game mode</td><td>Two clicks on the right ear</td><td>/</td><td>/</td></tr> <tr> <td>voice assistant</td><td>Four clicks on the right ear</td><td>/</td><td>/</td></tr> <tr> <td>voice assistant</td><td>When the battery voltage is below 3.1v</td><td>/</td><td>/</td></tr> <tr> <td>Low power shutdown</td><td>When the battery voltage is below 3.1v</td><td>/</td><td>/</td></tr> <tr> <td>Restore Factory Settings</td><td>Press and hold the reset button for 10 seconds</td><td>/</td><td>/</td></tr> <tr> <td>Headset Charging</td><td>Press and hold the reset button for 10 seconds</td><td>/</td><td>/</td></tr> </tbody> </table>	problems	Doubtless on the left side	/	/	not booting	Double-click on the right ear	/	/	volume up/down	Long press on the right ear	/	/	volume reduction	Long press on the left ear	/	/	reconnection mode	Three clicks on the right ear	/	/	game mode	Two clicks on the right ear	/	/	voice assistant	Four clicks on the right ear	/	/	voice assistant	When the battery voltage is below 3.1v	/	/	Low power shutdown	When the battery voltage is below 3.1v	/	/	Restore Factory Settings	Press and hold the reset button for 10 seconds	/	/	Headset Charging	Press and hold the reset button for 10 seconds	/	/	<p>尊敬的用户，非常感谢您使用音贝奇产品，请您认真填写并妥善保管。</p> <p>本公司保留对该产品服务售后服务的解释权。</p> <table border="1"> <thead> <tr> <th colspan="2">保修卡片</th></tr> <tr> <th>经销商信息</th><th>用户姓名</th></tr> </thead> <tbody> <tr> <td>用户名</td><td>保修日期</td></tr> <tr> <td>客户姓名</td><td>保修日期</td></tr> <tr> <td>联系电话</td><td>保修日期</td></tr> <tr> <td>联系地址</td><td>保修日期</td></tr> </tbody> </table> <p>售后热线：400-808-2787 质检员: PASSED</p>	保修卡片		经销商信息	用户姓名	用户名	保修日期	客户姓名	保修日期	联系电话	保修日期	联系地址	保修日期
有害物质或元素名称	塑料零件	金属零件	线路板	线缆																																																																																	
铅	EL	EL	EL	EL																																																																																	
镉	EL	EL	EL	EL																																																																																	
六价铬	EL	EL	EL	EL																																																																																	
多溴联苯或多溴二苯醚	EL	NA	EL	EL																																																																																	
problems	Doubtless on the left side	/	/																																																																																		
not booting	Double-click on the right ear	/	/																																																																																		
volume up/down	Long press on the right ear	/	/																																																																																		
volume reduction	Long press on the left ear	/	/																																																																																		
reconnection mode	Three clicks on the right ear	/	/																																																																																		
game mode	Two clicks on the right ear	/	/																																																																																		
voice assistant	Four clicks on the right ear	/	/																																																																																		
voice assistant	When the battery voltage is below 3.1v	/	/																																																																																		
Low power shutdown	When the battery voltage is below 3.1v	/	/																																																																																		
Restore Factory Settings	Press and hold the reset button for 10 seconds	/	/																																																																																		
Headset Charging	Press and hold the reset button for 10 seconds	/	/																																																																																		
保修卡片																																																																																					
经销商信息	用户姓名																																																																																				
用户名	保修日期																																																																																				
客户姓名	保修日期																																																																																				
联系电话	保修日期																																																																																				
联系地址	保修日期																																																																																				
<h3>YINPAGE</h3> <p>—— TVS Wireless headset ——</p> <p>Real 2 Pro instructions for use</p> <p>扫描下方二维码可下载电子版说明书</p>	<p>Fingerpoint setting area (1/3 position of headphone handle)</p> <p>Fingerpoint setting area (1/3 position of headphone handle)</p> <h3>L Power on/off Control</h3> <p>L Power on The headset can be turned on automatically by opening the cover</p>	<h3>2. Connect</h3> <p>The first time to connect the device, open the charging compartment cover and open the phone to search for "YINPAGE Real 2 Pro" to connect. After the connection is successful, there is no need to reconnect again for subsequent use.</p> <p>Note: Bluetooth is not connected at all times.</p> <h3>3. Power off</h3> <p>Put the headset into the charging compartment and close the top cover of the charging compartment to turn off the charging. Note: No connection status, 5 minutes automatic shutdown</p> <h3>2. Functional operation</h3> <table border="1"> <thead> <tr> <th>Key Function</th><th>manipulate</th><th>Prompt tone</th><th>Indicator Lights</th></tr> </thead> <tbody> <tr> <td>Answer/hang up</td><td>click</td><td>/</td><td>/</td></tr> <tr> <td>Play/Pause</td><td>click</td><td>/</td><td>/</td></tr> </tbody> </table>	Key Function	manipulate	Prompt tone	Indicator Lights	Answer/hang up	click	/	/	Play/Pause	click	/	/	<table border="1"> <thead> <tr> <th>problems</th><th>Doubtless on the left side</th><th>/</th><th>/</th></tr> </thead> <tbody> <tr> <td>not booting</td><td>Double-click on the right ear</td><td>/</td><td>/</td></tr> <tr> <td>volume up/down</td><td>Long press on the right ear</td><td>/</td><td>/</td></tr> <tr> <td>volume reduction</td><td>Long press on the left ear</td><td>/</td><td>/</td></tr> <tr> <td>reconnection mode</td><td>Three clicks on the right ear</td><td>/</td><td>/</td></tr> <tr> <td>game mode</td><td>Two clicks on the right ear</td><td>/</td><td>/</td></tr> <tr> <td>voice assistant</td><td>Four clicks on the right ear</td><td>/</td><td>/</td></tr> <tr> <td>voice assistant</td><td>When the battery voltage is below 3.1v</td><td>/</td><td>/</td></tr> <tr> <td>Low power shutdown</td><td>When the battery voltage is below 3.1v</td><td>/</td><td>/</td></tr> <tr> <td>Restore Factory Settings</td><td>Press and hold the reset button for 10 seconds</td><td>/</td><td>/</td></tr> <tr> <td>Headset Charging</td><td>Press and hold the reset button for 10 seconds</td><td>/</td><td>/</td></tr> </tbody> </table>	problems	Doubtless on the left side	/	/	not booting	Double-click on the right ear	/	/	volume up/down	Long press on the right ear	/	/	volume reduction	Long press on the left ear	/	/	reconnection mode	Three clicks on the right ear	/	/	game mode	Two clicks on the right ear	/	/	voice assistant	Four clicks on the right ear	/	/	voice assistant	When the battery voltage is below 3.1v	/	/	Low power shutdown	When the battery voltage is below 3.1v	/	/	Restore Factory Settings	Press and hold the reset button for 10 seconds	/	/	Headset Charging	Press and hold the reset button for 10 seconds	/	/	<h3>3. Product Parameters</h3> <table border="1"> <thead> <tr> <th>Parameter Item</th><th>Value</th><th>Unit</th></tr> </thead> <tbody> <tr> <td>Playing time</td><td>10H30</td></tr></tbody></table>	Parameter Item	Value	Unit	Playing time	10H30																				
Key Function	manipulate	Prompt tone	Indicator Lights																																																																																		
Answer/hang up	click	/	/																																																																																		
Play/Pause	click	/	/																																																																																		
problems	Doubtless on the left side	/	/																																																																																		
not booting	Double-click on the right ear	/	/																																																																																		
volume up/down	Long press on the right ear	/	/																																																																																		
volume reduction	Long press on the left ear	/	/																																																																																		
reconnection mode	Three clicks on the right ear	/	/																																																																																		
game mode	Two clicks on the right ear	/	/																																																																																		
voice assistant	Four clicks on the right ear	/	/																																																																																		
voice assistant	When the battery voltage is below 3.1v	/	/																																																																																		
Low power shutdown	When the battery voltage is below 3.1v	/	/																																																																																		
Restore Factory Settings	Press and hold the reset button for 10 seconds	/	/																																																																																		
Headset Charging	Press and hold the reset button for 10 seconds	/	/																																																																																		
Parameter Item	Value	Unit																																																																																			
Playing time	10H30																																																																																				

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference that may be received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance may void the user's authority to operate the equipment.

The equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference to other licensed operations in this band. This equipment generates, uses, and can radiate radio frequency energy, and if not installed and used in accordance with the instructions, may cause interference to radio communications. It has been tested and found to comply with the limits for a Class B digital device, which provides a reasonable assurance that interference will not occur in a particular installation if this equipment does cause harmful interference to radio or television reception. If interference does occur, the user is advised to take the following steps, which can be determined by turning the equipment off and on, the use of one of the following steps to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected
- Consult the dealer or a qualified radio/TV technician for help

The device has been evaluated to meet general RF exposure requirements. The device can be used in portable general RF exposure environments. The device has been evaluated to meet portable general RF exposure without restriction.