




NTV-n77(3450-3550)-PC1.5-30-30-L-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PASS




NTV-n77(3450-3550)-PC1.5-30-30-L-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS




NTV-n77(3450-3550)-PC1.5-30-30-L-DFT-BPSK-Inner_1RB_Left-30-1000-PASS




NTV-n77(3450-3550)-PC1.5-30-30-L-DFT-BPSK-Inner_1RB_Left-1000-3000-PASS




NTV-n77(3450-3550)-PC1.5-30-30-L-DFT-BPSK-Inner_1RB_Left-3000-6000-PASS




NTV-n77(3450-3550)-PC1.5-30-30-L-DFT-BPSK-Inner_1RB_Left-6000-20000-PASS




NTV-n77(3450-3550)-PC1.5-30-30-L-DFT-BPSK-Inner_1RB_Left-20000-40000-PASS




NTV-n77(3450-3550)-PC1.5-30-30-L-DFT-BPSK-Inner_1RB_Right-0.009-0.15-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-BPSK-Inner_1RB_Right-30-1000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-BPSK-Inner_1RB_Right-1000-3000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-BPSK-Inner_1RB_Right-3000-6000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-BPSK-Inner_1RB_Right-6000-20000-PASS











NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-BPSK-Inner_1RB_Right-20000-40000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-QPSK-Inner_1RB_Left-3
0-1000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-QPSK-Inner_1RB_Left-10
00-3000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-QPSK-Inner_1RB_Left-3
000-6000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-QPSK-Inner_1RB_Left-60
00-20000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-QPSK-Inner_1RB_Left-2
0000-40000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-QPSK-Inner_1RB_Right-0
.009-0.15-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-QPSK-Inner_1RB_Right-
0.15-30-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-QPSK-Inner_1RB_Right-3
0-1000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-QPSK-Inner_1RB_Right-1000-3000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-QPSK-Inner_1RB_Right-3000-6000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-QPSK-Inner_1RB_Right-6000-20000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-L-DFT-QPSK-Inner_1RB_Right-20000-40000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PASS











NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-BPSK-Inner_1RB_Left-30-1000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-BPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-BPSK-Inner_1RB_Left-3
000-6000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-BPSK-Inner_1RB_Left-60
00-20000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-BPSK-Inner_1RB_Left-2
0000-40000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-BPSK-Inner_1RB_Right-0
.009-0.15-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-BPSK-Inner_1RB_Right-
0.15-30-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-BPSK-Inner_1RB_Right-3
0-1000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-BPSK-Inner_1RB_Right-
1000-3000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-BPSK-Inner_1RB_Right-3
000-6000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-BPSK-Inner_1RB_Right-6000-20000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-BPSK-Inner_1RB_Right-20000-40000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-QPSK-Inner_1RB_Left-30-1000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-QPSK-Inner_1RB_Left-6000-20000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-QPSK-Inner_1RB_Left-2
0000-40000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-QPSK-Inner_1RB_Right-
0.009-0.15-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-QPSK-Inner_1RB_Right-
0.15-30-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-QPSK-Inner_1RB_Right-
30-1000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-QPSK-Inner_1RB_Right-
1000-3000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-QPSK-Inner_1RB_Right-
3000-6000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-QPSK-Inner_1RB_Right-
6000-20000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-M-DFT-QPSK-Inner_1RB_Right-
20000-40000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-BPSK-Inner_1RB_Left-300-1000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-BPSK-Inner_1RB_Left-1000-3000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-BPSK-Inner_1RB_Left-3000-6000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-BPSK-Inner_1RB_Left-6000-20000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-BPSK-Inner_1RB_Left-20000-40000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-BPSK-Inner_1RB_Right-0.009-0.15-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-BPSK-Inner_1RB_Right-3 0-1000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-BPSK-Inner_1RB_Right-1000-3000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-BPSK-Inner_1RB_Right-3 000-6000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-BPSK-Inner_1RB_Right-6000-20000-PASS











NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-BPSK-Inner_1RB_Right-2 0000-40000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS



NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-QPSK-Inner_1RB_Left-3
0-1000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-QPSK-Inner_1RB_Left-10
00-3000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-QPSK-Inner_1RB_Left-3
000-6000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-QPSK-Inner_1RB_Left-60
00-20000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-QPSK-Inner_1RB_Left-2
0000-40000-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-QPSK-Inner_1RB_Right-0
.009-0.15-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-QPSK-Inner_1RB_Right-
0.15-30-PASS

NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-QPSK-Inner_1RB_Right-3
0-1000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-QPSK-Inner_1RB_Right-1000-3000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-QPSK-Inner_1RB_Right-3000-6000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-QPSK-Inner_1RB_Right-6000-20000-PASS




NTNV-n77(3450-3550)-PC1.5-30-30-H-DFT-QPSK-Inner_1RB_Right-20000-40000-PASS




NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PASS











NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-BPSK-Inner_1RB_Left-0.15-5-30-PASS




NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-BPSK-Inner_1RB_Left-30-1000-PASS




NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-BPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-BPSK-Inner_1RB_Left-30
00-6000-PASS

NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-BPSK-Inner_1RB_Left-60
00-20000-PASS

NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-BPSK-Inner_1RB_Left-20
000-40000-PASS

NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-BPSK-Inner_1RB_Right-0.
009-0.15-PASS

NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-BPSK-Inner_1RB_Right-
0.15-30-PASS

NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-BPSK-Inner_1RB_Right-3
0-1000-PASS

NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-BPSK-Inner_1RB_Right-
1000-3000-PASS

NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-BPSK-Inner_1RB_Right-3
000-6000-PASS




NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-BPSK-Inner_1RB_Right-6000-20000-PASS




NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-BPSK-Inner_1RB_Right-20000-40000-PASS




NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PASS




NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-QPSK-Inner_1RB_Left-0.15-5-30-PASS




NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-QPSK-Inner_1RB_Left-30-1000-PASS










NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS



NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-QPSK-Inner_1RB_Left-6000-20000-PASS


NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-QPSK-Inner_1RB_Left-2
0000-40000-PASS

NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-QPSK-Inner_1RB_Right-0
.009-0.15-PASS

NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-QPSK-Inner_1RB_Right-
0.15-30-PASS

NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-QPSK-Inner_1RB_Right-3
0-1000-PASS

NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-QPSK-Inner_1RB_Right-
1000-3000-PASS

NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-QPSK-Inner_1RB_Right-3
000-6000-PASS

NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-QPSK-Inner_1RB_Right-
6000-20000-PASS

NTNV-n77(3450-3550)-PC1.5-30-40-L-DFT-QPSK-Inner_1RB_Right-2
0000-40000-PASS