




NTNV-n78(3700-3800)-PC1.5-30-80-L-DFT-QPSK-Inner_1RB_Left-2
6000-40000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-L-DFT-QPSK-Inner_1RB_Right-0
.009-0.15-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-L-DFT-QPSK-Inner_1RB_Right-
0.15-30-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-L-DFT-QPSK-Inner_1RB_Right-3
0-1000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-L-DFT-QPSK-Inner_1RB_Right-
1000-3000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-L-DFT-QPSK-Inner_1RB_Right-3
000-6000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-L-DFT-QPSK-Inner_1RB_Right-
6000-26000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-L-DFT-QPSK-Inner_1RB_Right-2
6000-40000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-BPSK-Inner_1RB_Left-30-1000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-BPSK-Inner_1RB_Left-1000-3000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-BPSK-Inner_1RB_Left-3000-6000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-BPSK-Inner_1RB_Left-6000-26000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-BPSK-Inner_1RB_Left-26000-40000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-BPSK-Inner_1RB_Right-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-BPSK-Inner_1RB_Right-3 0-1000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-BPSK-Inner_1RB_Right-1000-3000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-BPSK-Inner_1RB_Right-3 000-6000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-BPSK-Inner_1RB_Right-6000-26000-PASS











NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-BPSK-Inner_1RB_Right-2 6000-40000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-QPSK-Inner_1RB_Left-0 .009-0.15-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-QPSK-Inner_1RB_Left-0 15-30-PASS



NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-QPSK-Inner_1RB_Left-3
0-1000-PASS

NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-QPSK-Inner_1RB_Left-10
00-3000-PASS

NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-QPSK-Inner_1RB_Left-3
000-6000-PASS

NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-QPSK-Inner_1RB_Left-60
00-26000-PASS

NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-QPSK-Inner_1RB_Left-2
6000-40000-PASS

NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-QPSK-Inner_1RB_Right-
0.009-0.15-PASS

NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-QPSK-Inner_1RB_Right-
0.15-30-PASS

NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-QPSK-Inner_1RB_Right-
30-1000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-QPSK-Inner_1RB_Right-1000-3000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-QPSK-Inner_1RB_Right-3000-6000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-QPSK-Inner_1RB_Right-6000-26000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-M-DFT-QPSK-Inner_1RB_Right-26000-40000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PASS











NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-BPSK-Inner_1RB_Left-0.15-5-30-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-BPSK-Inner_1RB_Left-30-1000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-BPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-BPSK-Inner_1RB_Left-3
000-6000-PASS

NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-BPSK-Inner_1RB_Left-60
00-26000-PASS

NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-BPSK-Inner_1RB_Left-2
6000-40000-PASS

NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-BPSK-Inner_1RB_Right-0
.009-0.15-PASS

NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-BPSK-Inner_1RB_Right-
0.15-30-PASS

NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-BPSK-Inner_1RB_Right-3
0-1000-PASS

NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-BPSK-Inner_1RB_Right-
1000-3000-PASS

NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-BPSK-Inner_1RB_Right-3
000-6000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-BPSK-Inner_1RB_Right-6000-26000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-BPSK-Inner_1RB_Right-26000-40000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-QPSK-Inner_1RB_Left-3000-10000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-QPSK-Inner_1RB_Left-10000-30000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-QPSK-Inner_1RB_Left-30000-60000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-QPSK-Inner_1RB_Left-60000-260000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-QPSK-Inner_1RB_Left-2
6000-40000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-QPSK-Inner_1RB_Right-0
.009-0.15-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-QPSK-Inner_1RB_Right-
0.15-30-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-QPSK-Inner_1RB_Right-3
0-1000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-QPSK-Inner_1RB_Right-
1000-3000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-QPSK-Inner_1RB_Right-3
000-6000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-QPSK-Inner_1RB_Right-
6000-26000-PASS




NTNV-n78(3700-3800)-PC1.5-30-80-H-DFT-QPSK-Inner_1RB_Right-2
6000-40000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-BPSK-Inner_1RB_Left-30-1000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-BPSK-Inner_1RB_Left-1000-3000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-BPSK-Inner_1RB_Left-3000-6000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-BPSK-Inner_1RB_Left-6000-26000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-BPSK-Inner_1RB_Left-26000-40000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-BPSK-Inner_1RB_Right-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-BPSK-Inner_1RB_Right-0.15-30-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-BPSK-Inner_1RB_Right-3 0-1000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-BPSK-Inner_1RB_Right-1000-3000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-BPSK-Inner_1RB_Right-3 000-6000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-BPSK-Inner_1RB_Right-6000-26000-PASS







NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-BPSK-Inner_1RB_Right-2 6000-40000-PASS







NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-QPSK-Inner_1RB_Left-0.1 5-30-PASS


NTVN-n78(3700-3800)-PC1.5-30-90-L-DFT-QPSK-Inner_1RB_Left-3
0-1000-PASS

NTVN-n78(3700-3800)-PC1.5-30-90-L-DFT-QPSK-Inner_1RB_Left-10
00-3000-PASS

NTVN-n78(3700-3800)-PC1.5-30-90-L-DFT-QPSK-Inner_1RB_Left-3
000-6000-PASS

NTVN-n78(3700-3800)-PC1.5-30-90-L-DFT-QPSK-Inner_1RB_Left-60
00-26000-PASS


NTVN-n78(3700-3800)-PC1.5-30-90-L-DFT-QPSK-Inner_1RB_Left-2
6000-40000-PASS

NTVN-n78(3700-3800)-PC1.5-30-90-L-DFT-QPSK-Inner_1RB_Right-0
.009-0.15-PASS

NTVN-n78(3700-3800)-PC1.5-30-90-L-DFT-QPSK-Inner_1RB_Right-
0.15-30-PASS

NTVN-n78(3700-3800)-PC1.5-30-90-L-DFT-QPSK-Inner_1RB_Right-3
0-1000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-QPSK-Inner_1RB_Right-1000-3000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-QPSK-Inner_1RB_Right-3000-6000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-QPSK-Inner_1RB_Right-6000-26000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-L-DFT-QPSK-Inner_1RB_Right-26000-40000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-BPSK-Inner_1RB_Left-0.009-0.15-PASS











NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-BPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-BPSK-Inner_1RB_Left-3000-10000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-BPSK-Inner_1RB_Left-10000-30000-PASS



NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-BPSK-Inner_1RB_Left-3
000-6000-PASS

NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-BPSK-Inner_1RB_Left-60
00-26000-PASS

NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-BPSK-Inner_1RB_Left-2
6000-40000-PASS

NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-BPSK-Inner_1RB_Right-0
.009-0.15-PASS

NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-BPSK-Inner_1RB_Right-
0.15-30-PASS

NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-BPSK-Inner_1RB_Right-3
0-1000-PASS

NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-BPSK-Inner_1RB_Right-
1000-3000-PASS

NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-BPSK-Inner_1RB_Right-3
000-6000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-BPSK-Inner_1RB_Right-6000-26000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-BPSK-Inner_1RB_Right-26000-40000-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-QPSK-Inner_1RB_Left-0.009-0.15-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-QPSK-Inner_1RB_Left-0.15-30-PASS




NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-QPSK-Inner_1RB_Left-30-1000-PASS



NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-QPSK-Inner_1RB_Left-1000-3000-PASS



NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-QPSK-Inner_1RB_Left-3000-6000-PASS



NTNV-n78(3700-3800)-PC1.5-30-90-M-DFT-QPSK-Inner_1RB_Left-6000-26000-PASS