

68\*64mm

多功能手机蓝牙  
指环遥控器

LY-09



视频/阅读/自拍遥控器说明书


产品简介

视频/阅读遥控器支持短视频(抖音、快手、微视等)及个别手机阅读APP的翻页功能,支持调节手机音量加减,真正释放双手!还是一个自拍遥控器,在观看短视频时,拍个美美的自拍照!

规格参数

适用系统:视频/阅读/自拍遥控器  
支持iOS 14.8/Android 8.0以上  
蓝牙版本:蓝牙5.3  
发射频率: 2.4-2.4835GHz  
工作电压: 3.9-4.2V(聚合物锂电池)  
工作温度: 0-50°C  
通讯距离: 10m

按键功能说明

- 
1. 长按5秒开关机, 长按2秒锁屏, 单击暂停, 双击点赞
  2. 单击上翻页, 长按加音量, 短按连续拍照
  3. 单击下翻页, 长按减音量, 短按连续拍照
  4. 单击左翻页, 长按播放上一曲, 双击返回主菜单
  5. 单击右翻页, 长按播放下一曲, 双击暂停歌曲

使用说明

操作如下(手机型号: iPhone X, iOS14.8):  
长按3秒1键开机, 蓝色指示灯闪烁时, 在手机蓝牙中搜索, 蓝牙设备名称: LY-09, 与手机蓝牙配对成功后, 进入短视频APP, 以抖音短视频APP为例: 按下①键播放或暂停视频, 双击①键给视频点赞, 按下②③④⑤键可实现视频上下左右(以实际为准)的翻动, 详情参照功能键操作。

1. 苹果手机需设置方可使用。设置如下: 设置→辅助功能→触控→辅助触控→打开, 出现圆点即可。如圆点不在拍照键上, 可调整鼠标圆点, 设置如下:

抖音拍照视频设置:  
1. 点开抖音拍照 2. 右侧第三个选项 3. 打开使用音量键拍照。  
完成以上设置就可以使用2号键正常拍照啦

关于苹果手机

使用苹果手机/平板时, 请注意以下几点:

1. 确保手机ios软件为14.8以上
2. 辅助触控功能必须打开

iOS14.8以上版本需设置方可使用。设置如下: 设置→辅助功能→触控→辅助触控→打开, 出现圆点即可。



注: iOS系统用户如遇触控辅助圆点指标持续往上跳动后无法上下操作, 应调节跟踪灵敏度从左右调节到适应位置便可以正常使用(执行触控手势)必须打开如上图5

在遥控器搜索或连接状态中, 15分钟无任何操作(视型号而定), 遥控器进入休眠状态, 只需短按1键, 即时唤醒, 继续搜索或自动回连。不使用时, 长按5秒1键关机。

放入盒内自动关机, 拿起自动开机连接。

Android版本手机蓝牙配对即可使用, 如鼠标或圆点不在拍照键上, 可参考设置1。

提示: 如因iOS系统升级造成本产品不能使用, 属不可抗力。

Multifunction  
Mobile phone bluetooth  
Ring remote control

LY-09



Video/Reading/Selfie Remote Control Instructions

Product introduction

The video/reading remote control supports short videos (Tik Tok, Kuai shou, Weishi, etc.) and the page-turning function of individual mobile phone reading APPs, supports adjusting the volume of the mobile phone to increase or decrease, and truly releases both hands! It is also a selfie remote control, when watching short videos, take a beautiful selfie!

Specifications

Applicable system: video/reading/selfie remote control  
Support iOS 14.8/Android 8.0 and above  
Bluetooth version: Bluetooth 5.3  
Transmission frequency: 2.4-2.4835GHz  
Working voltage: 3.9-4.2V (polymer lithium battery)  
Operating temperature: 0-50°C  
Communication distance: 10m

Button function description

1. Press and hold for 5 seconds to power on and off, press and hold for 2 seconds to lock the screen, click to pause, double-click to like
2. Click to page up, long press to increase volume
3. Click to page down, long press to decrease volume

4. Click on the left page, long press to play the previous track, double-click to return to the main menu
5. Right click to page, long press to play the next song, double-click to pause the song



Instructions for use

The operation is as follows (iPhone X, iOS14.8):

Press and hold the ① button for 3 seconds to turn on the power, when the blue indicator flashes, search in the Bluetooth of the mobile phone, the Bluetooth device name: LY-09, after successfully pairing with the Bluetooth of the mobile phone, enter the short video APP, take the Douyin short video APP as an example: Press the ① button to play or pause the video, double-click the ① button to like the video, and press the ②③④⑤ button to flip the video up, down, left and right (subject to the actual situation). For details, refer to the function key operation.

1. The iPhone can only be used after setting. The settings are as follows: Settings→Accessibility→Touch→Assistive Touch→On, and a dot appears. If the dot is not on the camera button, you can adjust the mouse dot, and the settings are as follows:

Tiktok camera video settings:  
1. Click on Tiktok to take photos 2. The third option on the right 3. Turn on and use the volume key to take photos.  
After completing the above settings, you can use the second button to take photos normally



About Apple phones

When using an iPhone/tablet, please pay attention to the following points:

1. Ensure that the iOS software on the phone is 14.8 or above
2. The auxiliary touch function must be turned on

iOS 14.8 and above versions require settings before use. The settings are as follows: Settings→Accessibility→Touch Control→Assistive Touch Control Open and a dot will appear.

Note: iOS system users should adjust the tracking if they encounter the touch assisted dot indicator continuously jumping up and down and cannot operate it up and down The sensitivity can be adjusted from left to right to the appropriate position for normal use (by performing touch gestures), and it must be turned on as shown in Figure 5



If unable to operate normally, please lower the sensitivity.

Tracking sensitivity adjustment slide, after adjustment You must turn off the auxiliary touch and try again Enable auxiliary touch control.

In the remote control search or connection state, if there is no operation for 15 minutes (depending on the model), the remote control will enter the sleep state, just short press the 1 button to wake up immediately, continue to search or automatically reconnect. When not in use, press and hold the 1 button for 5 seconds to turn off the device.

Put it into the remote control compartment to automatically shut down, pick it up and automatically turn it on to connect.

The Android version of the mobile phone can be used after Bluetooth pairing. If the mouse or dot is not on the camera button, please refer to Setting 1.

Tip: If this product cannot be used due to the upgrade of the iOS system, it is a force majeure.

**FCC Caution:**

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.