

FRONT



XDINARY HEROES
OFFICIAL LIGHT STICK

85

85

85

85

85

95

사용방법

버튼 짧게 누르기

버튼을 누르면 ON - BLINK - FLICKER - REVERSE - DIMMING SPIN - OFF 순으로 LED 모드가 변경됩니다.

버튼 길게 누르기


버튼을 3초간 길게 누르면 파란색으로 깜박이며, 블루투스 페어링 모드가 됩니다.
기기와 블루투스 연결 후 애플리케이션을 통하여 다양한 경험을 즐길 수 있습니다.

중앙 제어

공연장에서 중앙 제어가 시작되면 별도의 버튼 조작 없이 자동으로 응원불 조명이 제어됩니다.
중앙 제어가 시작되면 응원불 조명을 사용자가 스스로 제어할 수 없습니다.

건전지 삽입 및 교체

아래의 그림과 같이 손잡이 하단을 돌려서 분리 후 내부에 있는 건전지 소켓을 꺼내주세요.
AAA 건전지 3개를 소켓에 적혀있는 방향에 맞춰 삽입해 주세요. (소켓에 스프링이 있는 부분이 (-) 극입니다.)



품질 보증서

- 본 제품은 엄격한 공정관리 및 품질검사를 통해 만들어진 제품입니다.
- 제품 보증 기간은 구매일로부터 6개월입니다.
- A/S 처리 기준 (무상 수리)
 - 구매일로부터 보증기간 내에 정상적으로 사용한 경우
 - 제품 외관에 이물질, 스크래치 등이 있는 경우 (미사용품에 한함) (유상 수리)
 - 보증기간이 경과한 경우
 - 고객 부주의에 의한 파손, 고장이 발생한 경우
 - 화재, 홍수, 지진 등 천재지변에 의해 고장이 발생한 경우
 - 고객 임의로 분해, 수리 및 개조로 발생한 고장의 경우
- 보증기간 이내라 하더라도 유상 A/S로 판단될 경우 요금이 발생합니다.
- 공식 판매처에서 구매한 제품에 대해서만 환불, 교환, A/S 등 고객 서비스 및 지원을 받으실 수 있습니다.
- 본 보증서는 대한민국 내에서만 유효합니다.

주의사항

- 강한 충격을 받으면 고장의 원인이 됩니다.
- 물에 담거나 담그지 마세요.
- 제품이 정동되어 있을 때 발광된 부분을 바라보지 마세요.
- 직사광선, 고온 및 습한 장소에 보관하지 마세요.
- 임의로 분해하거나 개조하지 마세요.
- 제품 손상 등 이상이 있는 경우 사용을 중지하시고 A/S 의뢰하세요. 2차 불량이 발생할 수 있습니다.
- 영/유아의 손이 닿지 않는 곳에 보관하세요.
- 건전지의 (-) 극부터 (+) 극 순으로 삽입해 주세요.
- 정품 AAA 알카라인 건전지를 사용해 주세요.
- 새 건전지와 사용한 건전지를 혼용하지 마세요.
- 동일한 제조사의 건전지를 사용해 주세요.
- 매번 공연 시 새로운 건전지를 사용해 주세요.
- 사용하지 않거나 방전 시에는 건전지를 분리하여 보관해 주세요.
- 건전지 잔량이 낮을 경우 LED가 동작하지 않습니다.

How to use

Press the button briefly

Once you press the button, the LED mode changes in the order of ON - BLINK - FLICKER - REVERSE - DIMMING SPIN - OFF.

Press and hold the button


If you press and hold the button for 3 seconds, it will blink in blue, and the Bluetooth pairing mode will be activated. After connecting the device through Bluetooth, you can enjoy diverse experiences using the application.

Central control

When central control is activated in the concert hall, the lighting of the light stick will be automatically controlled without any additional button operation.
When central control is activated, users are unable to individually control the lighting of the light stick.

Inserting and replacing the battery

As shown in the figure below, rotate the bottom part of the handle to separate.
Insert 3 AAA batteries in the direction written on the socket.
(The part with the spring in the socket is the (-) pole.)



Certificate of quality

- This product has been manufactured by strict process control and quality testing.
- The Warranty Period lasts for 6 month from the date you purchased the Product.
- Repair Service Criteria (Free repair)
 - If product has been used normally within the warranty period from the date of purchase.
 - If there are foreign substances, scratches, etc. on the exterior of the product. (Limited to unused products only) (Paid repair)
 - If the warranty period expired.
 - In the case that product has been damaged or is malfunctioning due to customer's carelessness.
- In the case of malfunction due to natural disasters, such as fire, flood, earthquake, etc.
- In the case of product malfunction caused by disassembly, repair, and modification by the customer.
- Even if it is within the warranty period, a fee will be charged the repair requires payment according to the terms above.
- Customer service and support such as return, exchange, repair, etc. are available only for products purchased from official vendors.
- This warranty is valid only in Korea.

Precautions

- Strong shock may cause breakdown.
- Do not let the product touch or soak in water.
- Do not look at the illuminated part when the product is on.
- Do not store in a place with direct sunlight, high temperature, and humidity.
- Do not disassemble or remodel.
- If there is an abnormality including (but not limited to) damage to the product, do not use the product and request customer support. Secondary defects may occur.
- Keep out of reach of infants/children.
- Insert in order of (-) pole to (+) pole of the battery.
- Use genuine AAA alkaline batteries.
- Do not mix new and used batteries.
- Use batteries from the same manufacturer.
- Please use new batteries for each show.
- When product is not used or discharged, store batteries separately.
- If the remaining battery is low, the LED will not work.

BACK

A/S 접수방법

미사용 제품 또는 정상적으로 사용 중 발생한 문제의 경우 전화/이메일을 통해 고객상담 후, 제품 수리 및 교환 절차를 안내해 드립니다.

상호명 사운드컨텐츠 연락처 02-381-3758
주소 경기도 고양시 덕양구 상송로193길 1-6 3층 일부 (상송동)

고객정보 / 구매정보

이름	구매처
전화	구매일
주소	

使用方法

短按按钮

按钮按轻的话, 会按照 WHITE ON - BLINK - FLICKER - REVERSE - DIMMING SPIN - OFF 的顺序变更为LED模式。

长按按钮


长按三秒蓝色闪光灯亮起后, 进入蓝牙配对模式。
与蓝牙连接后, 可通过APP程序感受多样性体验。

中央控制

在演出现场, 将中央控制打开的话, 无需另行其他操作, 应援棒可自动形成照明模式。
中央控制启动后, 用户将无法自行调控应援棒的照明。

电池的插入与更换

如下图所示, 转动把手的下端, 分离后, 把内部的电池插座拿出来。
请按照插座上写着的方向插入3个AAA电池. (插座上有弹簧的部分是(-)极)



品质保证书

- 本产品是通过严格的工艺管理和质量检查生产出来的产品。
- 产品保修期为自购买之日起6个月。
- A/S处理标准 (无偿维修)
 - 从购买之日起在保修期内正常使用的情况
 - 产品外观有异物、划痕等情况 (仅限未使用产品) (有偿维修)
 - 超过保修期的情况
 - 因顾客疏忽发生破损、出现故障的情况
 - 因火灾、洪水、地震等自然灾害发生故障的情况
 - 因顾客随意拆解、修理及改造发生故障的情况
 - 即使在保修期内, 如判断为有偿售后服务的话, 也会产生相应费用。
- 唯有在官方销售点购买的产品才有退货、换货、售后服务等顾客服务和支援。
- 本保证书只在韩国国内有效。

注意事项

- 如遭受强烈冲击, 可致使形成故障。
- 不要触碰水或浸入水中。
- 产品的灯光部分开启时, 不要注视发光的部分。
- 不要将产品保管在阳光直射、高温和潮湿的地方。
- 不要随意拆解或改造。
- 如产品有损坏等异常情况, 请停止使用并委托售后服务. 可能会发生二次不良。
- 请保管在驱动/无法触及的地方。
- 请按照电池的(-)极到(+)极的顺序插入。
- 请使用正品AAA碱性电池。
- 不要将新电池和用过的电池进行混用。
- 请使用同一制造商所生产的电池。
- 每次观看演出时, 请使用新的电池。
- 不使用时或放电时, 请进行分离保管电池。
- 电池剩余量过低的话, LED将不进行工作。

使用方法

ボタンを短く押す。

ボタンを押すと ON - BLINK - FLICKER - REVERSE - DIMMING SPIN - OFF の順にLEDモードが変更されます。

ボタンを長く押す。


ボタンを3秒間長く押すと青色に点滅し, Bluetoothペアリングモードになります。
デバイスとBluetoothが接続された後, アプリケーションを通して様々な体験を楽しむことができます。

中央制御

会場で中央制御が始まると, 別途のボタン操作なしに自動的にペンライトの照明が制御されます。
中央制御が始まると, ペンライトの照明をユーザーが自ら制御することはできません。

乾電池の挿入及び交換

下図の通り, 握り手の下端を回して取り外した後, 内部にある乾電池ソケットを取り出してください。
4乾電池3個をソケットに書かれている方向に合わせて挿入してください。
(ソケットにスプリングがある部分が(-)極です。)



品質保証書

- 本製品は厳格な工程管理および品質検査を通して制作された製品です。
- 製品保証期間は購入日から6ヶ月です。
- アフターサービス処理基準 (無償修理)
 - 購入日から保証期間内に正常に使用した場合
 - 製品の外観に異物、スクラッチなどがある場合 (未使用品に限りです) (有償修理)
 - 保証期間が経過した場合
 - お客様の不注意による破損、故障が発生した場合
 - 火災、洪水、地震など天災地変により故障が発生した場合
 - お客様より任意に分解、修理、改造し発生した故障
 - 保証期間内でも有償アフターサービスと判断された場合、料金が発生します。
- 公式販売先でご購入された製品に対して、返品、交換、アフターサービス等のカスタマーサービス及びサポートをお受けいただけます。
- 本保証書は大韓民国内でのみ有効となります。

注意事項

- 強い衝撃を受けると故障の原因となります。
- 水に触れたり沈めないでください。
- 製品が点灯している時, 発光された部分を目で見ないでください。
- 直射日光、高温や湿った場所での保管は避けてください。
- 任意に分解したり改造しないでください。
- 製品に損があるなど異常がある場合は, 使用を中止しアフターサービスにご依頼ください。さらなる不良が発生する可能性があります。
- 乳幼児の手の届かない場所に保管してください。
- 乾電池を(-)極から(+)極の順に挿入してください。
- 真正4乾電池をご使用ください。
- 新しい乾電池と使用済みの乾電池を混用しないでください。
- 同一メーカーの電池だけをご使用ください。
- 毎回公演の際, 新しい乾電池に替えてご使用ください。
- 使用しない場合や放電の際は, 電池を取り外して保管してください。
- 電池残量が低い場合, LEDが動作しません。

95

FCC STATEMENT:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.

Radiation Exposure Statement

The device has been evaluated to meet general RF exposure requirement in portable exposure condition without restriction.