

---


---

Exquisite products, wonderful life

---

## Projector User 's Manual

---



## Precautions

- Before using the product, please read the instruction manual carefully and keep it in a safe place for emergency use.
- Please use the machine carefully, and do not drop or hit it at high altitude during transportation to avoid damage to the original machine. Please put on the lens protection cover after use to avoid scratches.
- Please use the standard power cord for power

### High temperature

- When the projector is working, it is forbidden to block the air inlet or outlet to avoid damage caused by the high internal temperature of the machine due to poor ventilation.
- Do not look directly at the projector lens with your eyes to avoid damaging your eyes due to strong light.


### Electric shock prevention

- In order to prevent electric shock, if there is any problem with the product, please do not disassemble it by yourself (there are no customer-serviceable parts in the machine), please contact professional maintenance personnel for assistance.
- To prevent fire and electric shock, do not expose the machine to rain or moisture.

### Working environment

- Only applicable to areas with an altitude of 2000 meters and below.
- Suitable for tropical climate conditions, the maximum allowable ambient temperature is 95 °F.

## Packing list




Projector\*1



Remote control\*1



Manual cord\*1



Power cord\*1

## Troubleshooting


### 1. Why doesn't anything work when external USB flash device connected?

- The USB file system must be in FAT32 or NTFS format and does not support EXFAT.

### 2. Why is the display of the projector available but without audio?


- Dolby sound is not supported.
- Fire stick: Enter "Setting" and find "Display & Sound". Then select "on" for "navigation sounds". Select "Stereo (or PCM)" for "surround sound".
- Netflix does not support same screen, there is sound, and the screen will go black.

## Appearance and function



# Signal source equipment


Computer/DVD/Games console



※: → Represents the direction of signal transmission.


When connecting the equipment, please pay attention to switching the correspondence signal source.

Window system : Press the [  +  ] key combination on the keyboard on the laptop to select the screen [Copy].




# Power on connection


## 1 Turn on the projector




Projector optical machine lifting



Projector optical rotation





Connect the projector to the power cord




Press the power button to turn on the device

## 2 Dust elimination

When there are dust spots on the projected image, open the dust removal cover and use a cotton swab to clean the dust on the screen.



# Installation mode


① Press the “

The image shows a 'Settings' menu with various icons and labels. The 'Projection' icon, which is a camera with a projector symbol, is highlighted with a red box. Other icons include Network (Wi-Fi), Bluetooth, Language (EN), Date, Application (blue flower), Other Settings (gear), System (house), and About (key).


② Choose projection method.



Front Desktop




Rear ceiling



Desktop



Front ceiling



## Launcher debug


When the image is blurred, please manually turn to the focus knob until the image is clear.




Correct display



Display Blur




Focus knob



Asymmetric width on both sides


Facing the screen

# Display settings


Press the “

The image shows a 'Settings' menu with a 3x3 grid of icons. The icons are: Network (Wi-Fi), Bluetooth, Projection (camera), Language (EN), Date, System (cube), Application (four circles), Other Settings (gear), and About (wrench). The 'Projection' icon is highlighted with a red border.

- Digital Zoom: Scale the image proportionally.




- Four-point keystone correction: Stretch the screen four points to make the screen horizontal and vertical.



# Basic setting

## 1. Projector connect to WIFI


- ① Press the “

The image shows a grid of nine settings icons. The 'Network' icon, which is a blue square with a white Wi-Fi symbol, is highlighted with a red rectangular box. The other icons are white with blue outlines: 'Bluetooth' (blue circle with a white 'B'), 'Projection' (blue camera icon), 'Language' (blue square with 'EN'), 'Date' (blue square with a white calendar icon), 'System' (blue cube icon), 'Application' (blue four-leaf clover icon), 'Other Settings' (blue gear icon), and 'About' (blue wrench icon). The background is a light blue with a subtle wavy pattern.

- ② Select a network and connect.



## 2. Projector connected to Bluetooth

- ① Press the “


The image shows a 'Settings' menu with nine options arranged in a 3x3 grid. The options are: Network (Wi-Fi icon), Bluetooth (Bluetooth icon, highlighted with a red box), Projection (camera icon), Language (EN icon), Date (calendar icon), System (cube icon), Application (leaf icon), Other Settings (gear icon), and About (key icon). The background has a light blue wavy pattern.

- ② Search bluetooth device name and connect it .



### 3. Mobile phone connected to projector Bluetooth speaker

- ① Press the “up” button on the remote control, and Click the [Speaker Mode] on the [APPS] option.




- ② Turn on Bluetooth on your phone, Search bluetooth device name [NL-XXXX] and connect it .




## 4. Apple Phone screen projection

- ① Apple phone and projector connected to the same WiFi.
- ② Press the “up” button on the remote control, and Click the [iOSCast] on the [APPS] option.




- ③ On your iOS device, open Control Center and tap Screen Mirroring. Select [BirdCast-XXXX] from the list.



## 5. Android and Microsoft system screen projection

Press the “up” button on the remote control, and Click the [Miracast] on the [APPS] option.




Enter the interface shown in the figure below.



## 5.1 Android phone screen projection:

- ① Turn on [WLAN].
- ② open phone console , clik [Smart View]on the Samsung Phone.
- ③ connect projector device [NEWLINK\_XXXX].



## 5.2 Microsoft laptop screen projection:

- ① Press the combination keys [WIN+k] on your keyboard.
- ② Select [NEWLINK\_XXXX] to connect and start wireless projection.



## FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum distance between 20cm the radiator your body: Use only the supplied antenna.