


User Manual



Scan the QR code to watch the operation tutorial.

Product Introduction

Before using this product, please read the manual carefully.

Menu Button/Back Button

Press: Open app list / Return to the previous screen.

Double-press: Change the menu style.

Press and hold: Open volume adjustment.

Power Button

Press and hold: Turn on/off, restart.

Press: Light up screen / Turn off screen /

Return to the main watch face.

Double-press: Open multitasking interface.

Screenshot: Long press the upper button and the lower button at the same time.

Force restart: Press the power button 15 times in a row quickly, the machine will force a factory reset.

① If you feel discomfort on your skin while wearing the watch, please remove it promptly and seek medical advice.



Menu Button


Pull-out Rotat

Power Button

Powering On and Charging

The watch can be powered on by pressing and holding the lower button.

Align the charging area of the watch with the face of the charging dock, the dock will automatically attach itself until the charging interface appears on the watch screen.




① If the battery power is too low, the device cannot be turned on. Please charge it in a timely manner.

Installing the SIM Card

Please use a standard Nano-SIM card and ensure that the metallic chip on the SIM card is clean and free from dirt or oxidation.


When positioning the card, align the notch on the SIM card with the notch in the slot, and then place the SIM card into the slot. Once the card is properly in place, align the hole in the slot with the opening on the watch, and then push the slot back into the watch.



① After the installation of the SIM card, it is necessary to reboot the watch by long-pressing the power key for the watch to recognize the SIM card.

Usage

- ① Swipe down once on any screen: Opens the notification and status bar.
- ② Swipe down twice on any screen: Opens the control center.
2. Swipe from right to left on the watch face: Switch function cards.
3. Swipe from left to right on the watch face: Open the phone menu.
4. Swipe from left to right on other screens: Return to the previous page.



Application installation and uninstallation


Application installation

1. In the watch function menu, find the app market and directly download and install it for use.

App uninstallation

1. Find the app market in the function menu, open it, find the three horizontal bars in the upper left corner, find the app management the lower left corner, open it, find the corresponding "software management" and then you can uninstall it.

2. Find the settings in the function menu, then find "Applications and Notifications" in the settings, view all applications, find the corresponding software uninstall it.



Status bar

Bluetooth: Show the status of the Bluetooth switch.

WIFI: Display the status of the WIFI switch.

Mode: Clicking will activate flight mode. Mobile

Data: Mobile data switch is on.

Brightness: Slide to adjust screen brightness. Transport

NFC: Can record NFC access cards, community access cards, door locks, etc. Location

Information: Enables precise location after turning on.

Volume: Can adjust volume size.

One-Key Drain: Uses sound frequency vibration to drain water.

Switch: Switch between round and square screens.

Power Saving Mode Selection: Switch between various saving modes. One-Key

Cleanup: One-click cleanup of background running applications.



Product Information

Parameters

Display: 1.95 inch AMOLED

Resolution: 720x720 pixels

Input Rating: 5V == 1A

Wireless Connectivity: Bluetooth, WiFi

Battery Capacity: High-Voltage 2100 mAh

Operating Temperature: 0°C~45°C

Ingress Protection Level: IP67

Bluetooth Transmit Power: ≤20dBm (EIRP)

Contents

Smart Watch x1

Charging Cable x1

User Guide x1

Screen Protector x1