

- Long press for 3 seconds to turn on the speaker, after turned on, you will hear a sound indicator. After blue light indicator quickly flashes, you could hear a bluetooth status tone. Portable speaker will enter into pairing mode automatically.
- Activate the wireless function on your smartphone.
- Select the name of the speaker from the list: Cubitt Power Mini Speaker. When pairing is successful, there will be a sound indicator, press play to start your music.
- If no Bluetooth connection is made within 15 minutes, the speaker will power off automatically.

- **Play/Pause:** Short press Play/Pause button to start, pause and resume music playback. When there is an incoming call, short press Play/Pause button to answer the call or end the call.
- **Reset:** Long press the Play/Pause button for 8 seconds.
- **Next track:** During music playback, long press the + button for 3 seconds to select the next track.
- **Previous track:** During music playback, long press the - button for 3 seconds to select the previous track.
- **Increase the volume:** Short press the + button to increase the volume of the speaker.
- **Decrease the volume:** Short press the - button to decrease the volume of the speaker.

- It may be necessary to **clean** your appliance regularly.
- Clean the surface of the appliance with a soft, damp cloth.
- Do not use **solvents, chemicals** or **cleaning fluids** containing **alcohol**, ammonia or abrasive substances.
- **WARNING:** Never intentionally immerse the appliance in water or any other liquid.



110 mm

Thank you for purchasing Cubitt Power Mini Speaker. Please read this user manual carefully before operating and keep these instructions for future reference.

The diagram shows the control panel and battery pack assembly. The control panel is a rectangular unit with a digital display and several buttons. The buttons are labeled 1 through 5. 1 is the power button, 2 is the mode button, 3 is the start button, and 4 is the stop button. 5 is the battery pack, which is a large rectangular unit with a grid of cells. The battery pack is connected to the control panel via a cable.

1. On/Off, Reset, Play/Pause, Answer/End the call
2. Volume down and previous track(-) button
3. Volume up and next track(+) button
4. Type C charging port
5. Device

- Audio output: 5W
- Battery capacity: 600mAh
- Mode: Wireless
- Wireless: Version 5.4
- Maximum wireless range: 10 meters
- Charging time: 2-3 hours
- Operating time: 5-6 hours
- Speaker frequency: 100HZ-18KHZ
- Speaker driver: 40mm
- Water resistance: IPX6
- Dimensions: 58*31*64mm
- Charging Current: 5V 0.5A

- Unpack the appliance and its various components and check that each part is in good condition.

Fully charge the battery before using the device for the first time or when you have not used it for some time.

- Connect the USB-A end to an adapter or computer, then connect the USB-C end to the charging port on the device. Red light indicates charging status, LED light will turn off when fully charged.

5. TURNING THE SPEAKER ON OR OFF
You can switch the speaker on or off by long press the on/off button for 3 seconds.

80 mm

English

Español

FCC COMPLIANCE INFORMATION

FCC STATEMENT

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment. This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

RF Exposure Information

The device has been evaluated to meet general RF exposure requirement.

The device can be used in 0mm exposure condition, compliance with exposure requirements.




FCC ID: 2BOEC-POWERMINI
cubittofficial.com
@cubitt

Tu Power Mini Speaker

Gracias por adquirir el Altavoz Cubitt Power Mini Speaker. Por favor, lea atentamente este manual de usuario antes de usar el dispositivo y consérvelo para futuras consultas.

Descripción y Características:



1. Encendido/Apagado, Restablecer, Reproducir/Pausar, Contestar/ Finalizar llamada
2. Botón de volumen (-) y pista anterior
3. Botón de volumen (+) y pista siguiente
4. Puerto de carga tipo C
5. Dispositivo

Características:

- Potencia de salida: 5W
- Capacidad de batería: 600mAh
- Modo: Inalámbrico
- Versión inalámbrica: 5.4
- Alcance inalámbrico máximo: 10 metros
- Tiempo de carga: 2-3 horas
- Tiempo de funcionamiento: 5-6 horas
- Frecuencia del altavoz: 100Hz-18KHz
- Controlador del altavoz: 40mm
- Resistencia al agua: IPX6
- Dimensiones: 583164mm
- Corriente de carga: 5V 0.5A

Instalación / Uso:

1. ANTES DE USAR POR PRIMERA VEZ

- Desembale el dispositivo y sus componentes, y verifique que todo esté en buen estado.

2. CARGA DEL ALTAVOZ

- Cargue completamente el dispositivo antes del primer uso o si no lo ha usado en mucho tiempo.
- Conecte el extremo USB-A a un adaptador o computadora, luego conecte el extremo USB-C al puerto de carga del dispositivo.
- Una luz roja indica que está cargando. La luz LED se apagará cuando esté completamente cargado.

3. ENCENDER O APAGAR EL ALTAVOZ

Mantenga presionado el botón de encendido durante 3 segundos para encender o apagar el dispositivo.

4. MODO INALÁMBRICO - CONEXIÓN A UN SMARTPHONE

- Mantenga presionado el botón de encendido  durante 3 segundos para encender el altavoz. Una vez encendido, una luz azul comenzará a parpadear rápidamente y se escuchará un tono que indica el modo de emparejamiento Bluetooth.
- Active la función Bluetooth en su smartphone.
- Seleccione el nombre del altavoz en la lista: Cubitt Power Mini Speaker. Una vez emparejado con éxito, se escuchará un sonido. Presione reproducir para iniciar la música.
- El altavoz se apagará automáticamente si no se conecta por Bluetooth en 15 minutos.

5. MUSIC CONTROL

- **Reproducir/Pausar:** Presione brevemente para iniciar, pausar o reanudar la música.
- **Llamadas:** Presione brevemente para contestar o finalizar llamadas entrantes.
- **Restablecer:** Mantenga presionado el botón Reproducir/Pausar durante 8 segundos.
- **Pista siguiente:** Durante la reproducción, mantenga presionado el botón (+) durante 3 segundos.
- **Pista anterior:** Durante la reproducción, mantenga presionado el botón (-) durante 3 segundos.
- **Subir volumen:** Presione brevemente el botón (+).
- **Bajar volumen:** Presione brevemente el botón (-).

6. MANTENIMIENTO Y LIMPIEZA

- Puede ser necesario limpiar el dispositivo regularmente.
 - Limpie con un paño suave y húmedo.
 - No use disolventes, productos químicos o líquidos abrasivos que contengan alcohol, amoníaco u otras sustancias.
- ADVERTENCIA:** No sumerja nunca el dispositivo en agua ni en ningún otro líquido.