


Function Introduction



- Find Items - Click "Play Sound" to make your Item Locator beep when it is nearby.
- Find your Item Locator's location - Your Item Locator's last known location will appear on the map as emoji you choose during set-up, tap "Directions" to navigate to the last known location.



Function Introduction

- Enable the "Notify When Found" toggle, when your Item location is seen by another "Find My" enabled device, you will receive a notification of its updated location.
- Enable the "Notify When Left Behind" toggle, you will receive a notification when you leave your Item Locator behind and it is no longer in range of your device.

Note: "Notify When Found" can only be activated when your Item Locator is out of range.



Lost Mode

- When your item is lost under "Lost Mode", tap the "Enable" tab, a screen calling Lost Mode will pop up, tab "Continue". You can enter your phone number or email address and tap "Next".
- You may enter a message that will be shared with the person that finds your item. Tap "Activate" to enable "Lost Mode".

Note:

- When "Lost Mode" is enabled, "Notification When Found" is automatically enabled.
- When "Lost Mode" is enabled, your item is locked and cannot be paired to a new device.

Rename Item

- Name of the item can be renamed.

Rename Item

- Make sure "Lost Mode" is disabled and click "Remove Item". After selecting the option, the system will pop up "Remove Item?" and click "Remove" to remove the device.
- The item is now reset and ready to pair to a new device.

How to Disable

- Locate the button on the front of the device.
- Long press the function button three seconds until two beeps are heard. This will stop sharing the location of this item.

Factory Reset

- Press the button 4 times rapidly and then hold it a fifth time until you hear a ringing chime.
- A reset operation is required to enable the device to enter the pairing state again (synchronization of Find My also requires simultaneous unbinding) and rebind the new Apple ID account.
- Don't use abrasive cleaning solvents to clean the unit.
- Don't expose the unit to extremely high or low temperature as this will

System Requirements and Compatibility

- Apple ID
- iPhone and iPod touch models with iOS 14.5 or later.
- iPad models with iPadOS 14.5 or later.

About the Find My App

The Find My app makes it easy to keep track of your Apple devices—even if they are offline. You can also locate items using Smart Card or Find My technology. Plus, you can keep up with friends and family. And your privacy is protected every step of the way.

Links: <https://www.apple.com/icloud/find-my/>

Learn More

- This item can be located by its owner using the Find my app. For more information, follow the instructions below.
- Locate the button on the front of the device.
- Press the button twice. You will hear a confirmation sound.
- Tap "Continue On Website" for more information including any Lost Mode message from the owner.

How to Disable

- Locate the button on the front of the device.
- Long press the function button three seconds until two beeps are heard. This will stop sharing the location of this item.

Care and maintenance

- Read the following recommendations before using the unit. Following these you will be able to enjoy the product for many years.
- Don't expose the unit to liquid, moisture or humidity to avoid the product's internal circuit being affected.
- A reset operation is required to enable the device to enter the pairing state again (synchronization of Find My also requires simultaneous unbinding) and rebind the new Apple ID account.
- Don't use abrasive cleaning solvents to clean the unit.
- Don't expose the unit to extremely high or low temperature as this will

How can I prevent my device from being used for malicious tracking

When someone else's device mixes with your belongings, and tracks it over a period of time, you will be reminded in below two ways:

- If you have an iPhone, iPad, or iPod touch etc Apple device, you will get alerts on your Apple device. This feature is available on iOS or iPadOS 14.5 version or above.
- If someone else's device finds its way into your stuff, your iPhone will notice it is traveling with you and send you an alert. After a while, if you still have not find it, the item will start playing a sound to let you know where it is.

FCC Instructions

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the product.

NOTE: This product has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This product generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If the product does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the product and receiver.
- Connect the product into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Care and maintenance

Read the following recommendations before using the unit. Following these you will be able to enjoy the product for many years.

Limited Warranty

This manufacturer's product warranty extends to the original consumer purchaser of the product. Neither the retailer nor any other company involved in the sale or promotion of this product is a co-warrantor of this manufacturer's warranty.

WARRANTY PERFORMANCE: During the 90 day warranty period, a product with a defect will be either repaired or replaced with a reconditioned comparable model (at manufacturer's option). The repaired or replacement product will be in warranty for the balance of the 90 day warranty period and an additional one month period. No charge will be applicable for such repair or replacement.

NOTE: Manufacturer cannot assume responsibility for loss or damage during incoming shipment. As a precautionary measure, carefully package the product for shipment and insure it with the carrier. Be sure to enclose the following details with the product: your full name, return address and daytime phone number, a note describing the problem you experienced, a copy of your sales receipt or other proof of purchase to determine warranty status. C.O.D. shipments cannot be accepted.

WARRANTY COVERAGE: This product is warranted against defective materials or workmanship. This warranty is void if the product has been damaged by accident, in shipment, unreasonable use, misuse, neglect, improper service, commercial use, repairs by unauthorized personnel or other causes not arising out of defects in materials or workmanship. This warranty doesn't cover the following which may be supplied with this product, including but not limited to: LCD Screen, glass parts, lenses, bulbs etc. This warranty is effective only if the product is purchased and operated in USA and Canada, and does not extend to any units which have been used in violation of written instructions furnished by manufacturer or units which have been altered or modified or, to damaged products or parts thereof which have had the serial number removed, altered, defaced or rendered illegible.

WARRANTY DISCLAIMER: This warranty is in lieu of all warranties expressed or implied and no representative or person is authorized to assume for manufacturer any other liability in connection with the sale of our products. There shall be no claims for defects or failure under any theory of tort, contract, commercial law including but not limited to negligence, gross negligence, strict liability, breach of warranty and breach of contract. Under no circumstance will Manufacturer's / Distributor's maximum liability exceed the retail value of the product.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.