

Product Manual

<p>Power setup Press and hold the power button for more than 2 seconds, the screen will light up in the translation interface, and you can use it normally. Long press the power button for more than 2 seconds, the screen will turn off. If the power button does not select the shutdown icon, and the device will shut down.</p> <p>Restart Press and hold the power button for more than 2 seconds. The restart icon (the down icon) is displayed on the screen, Select the restart icon to restart the device.</p> <p>Return key Press the back key to return to the previous function.</p> <p>Volume To adjust the volume, click the side + button to increase the volume. Click the Side-Button to reduce the volume to the lowest or mute mode.</p> <p>VOCA key Press and hold the voice input key on the home left voice key corresponds to the language on the left of the home page, and the right voice key corresponds to the language on the right of the home page. Once the voice recognition starts, after releasing the hand, the voice is automatically converted into text. The system will automatically switch to the target language and played (the voice playback mode depends on the settings).</p> <p>TF card Can be expandable storage, support FAT32 format memory card, up to 128G memory card.</p> <p>Type-C interface Supports fast charging, data transmission, audio and video signal transmission.</p> <p>Reset key If your device has a serious malfunction or crashes, you can find a small hole on the side of the device, for a few need to electronic reset to insert it into the hole and press the reset button to meet the functions.</p>	<p>Battery charging and other operations When charging with a power adapter, the USB cable in the accessory for charging. Note: Do not charge with a power adapter with a connector or when charging with a computer.</p> <p>Network link Some applications need to be connected to the network. Click the main interface to set 1. start the WiFi function. Enter the WiFi connection interface, and then click the WiFi icon to connect. After the connection is successful, the WiFi icon will be displayed in the status bar, and you can use it freely.</p> <p>Equipment upgrade The device will be updated from time to time to fix your device cannot be updated, the possible reasons are as follows: 1. The current version is the latest version and there is no new upgrade package. 2. Check whether the network connection is normal, Only when the network connection is normal, the device can be updated. 3. Check the system memory, if the system memory is full, the device cannot be updated. 4. Sufficient power is required before the equipment upgrade. Do not perform any other operations that may affect the power system evaluation, interruption and upgrade failure.</p> <p>RF/SAR information Wireless communication equipment makers may have different SAR levels, and to ensure the safety and health of users, this equipment is designed and manufactured in accordance with radio exposure guidelines. The test range of the SAR is 10g, and the SAR value is the general public, 10g with 0.054W/kg. 10g of body tissue in average, after testing.</p> <p>Safety precautions Please do not use this product in high temperature or high humidity environments. - Remove or relocate the antenna. - Interfere or separation between the equipment and receiver. - Connect the equipment into an outlet on a circuit different from that to which the receiver is connected. - Consult the dealer or an experienced radio/TV technician for help. The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.</p>	<p>10 The number on this label indicates that the environmental protection use time of the product under normal use is 10 years, and the number is the number of the environmental protection life, and the number of the environmental protection use time is the number of the life.</p> <p>Product commitment This product complies with the requirements of the related laws and regulations of the European Union and the member states, including the requirements for the use of RoHS and the ban of substances in Electrical and Electronic Products and the Requirements for the Classification of Hazardous Substances in Electrical and Electronic Products. The number marked on the product will not loss or change under normal use of the corresponding product, and the use of the electronic information products by the general public will not cause any damage to the environment and the health of his personal life and property.</p> <p>Attention: Using the product will have an impact on the environment. Please respect it.</p> <p>Warranty card/Certificate of qualification Dear customer, thank you for buying our products. We offer a 1-year warranty for the product. Please read carefully and take good care of the warranty card.</p>	<p>name _____</p> <p>telephone _____</p> <p>Contact address _____</p> <p>SN number _____</p> <p>Fault description _____</p> <p>Purchase channel _____</p> <p>Order number _____</p> <p>I do not need after-sales service, please contact after-sales channel customer service in time. Please fill out this card in detail and return it with the product.</p>
---	--	---	---

FCC WARNING

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications.

However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception,

which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.



check

Customer service