



尺寸: 75*75mm



Package Contents



Product Overview



Touch Control Diagram

The touch area (MFB Touch Panel) is located in the upper part of earbuds handle.

(MFB) Touch Panel



Power ON / OFF

Power On
Auto Open the charging case and take out the earbuds to power on

Manually: Press and hold the MFB for 3s.



Pairing

1. Open the charging case, and take out the earbuds, earbuds will pair automatically.

2. One of the earbuds flashes blue and red, the another earbud light goes out.

2. Activate Bluetooth on the device, turn on Bluetooth, search for pairing name "HTT-11", and click on it.



Bluetooth Lost

1. Turn off mobile phone's Bluetooth, earbuds will enter the pairing mode and can pair with other devices.

2. If the connection range is exceeded, the earbuds will enter the back connection mode. No connection within 5 minutes, the earbuds will turn off.

Notes For Signal Transmission Distance (as illustrate)



Reset

If your earbuds accidentally only get one earbud to work, or fail to pair, please reset the earphone.

1. Delete all "HTT-11" Bluetooth records on the phone, and turn off Bluetooth.

2. Put earbuds into charging case, and then take out to pairing mode, tap L & R MFB 5 times simultaneously, hear "D-U" prompt voice to clear all pairing.

3. Put earbuds into charging case.



Touch Operation



Left Earbud

- 1x Play / Pause
Tap the MFB once
- 1x Answer the call
Tap the MFB once
- 2x Previous Track
Double tap the left MFB
- 2x End Call/Reject call
Double tap the MFB
- 3x Volume -
Triple tap the left MFB
- 4x Game mode
Four tap the MFB
- 1.5s Voice assistant
Press and hold the MFB for 1.5s



Touch Operation



Right Earbud

- 1x Play / Pause
Tap the MFB once
- 1x Answer the call
Tap the MFB once
- 2x Next Track
Double tap the right MFB
- 2x End Call/Reject call
Double tap the MFB
- 3x Volume +
Triple tap the right MFB
- 4x Game mode
Four tap the MFB
- 1.5s Voice assistant
Press and hold the MFB for 1.5s

Earbuds low battery alarm

When the battery power is low, every 1 minute voice reminder "Lower battery" and Red light double flashing, until the battery power is run out and turn off.



Charge your earbuds

Place your earbuds into the charging case and close the lid, earbuds automatically complete charge.



Product Parameter

Earbud(each)

Model Name: HTT-11
Bluetooth Version: V5.4
Speaker: 10mm

Speaker Range: 10m 3311 (with out obstacles)

Technology: HSP/HFP/A2DP/AVRCP

Frequency Range: 20Hz~20kHz

Weight: 3.4g

Size: 36*18*19mm

Charging Time: 0.5H

Battery Capacity: 40mAh

Play Music Time: 6H

Input: DC 5V ± 0.08A

Charging Case

Weight: 60g

Size: 54*54*30mm

Charging Time: 2H

Battery Capacity: 400mAh

Input: DC 5V ± 0.3A

Earbuds Warning

1. Please do not place the product in an environment where the temperature is too low (above 45°C or below 0°C).

2. Do not disassemble or repair the earbuds under any circumstances, if necessary, please send the product to the seller for repair.

3. Do not throw and drop the earbuds to avoid damage.

4. The earbuds and the BT devices will be disconnected if the distance between them is more than 10 meters.

5. Keep the device accessories away from children and pets.

6. Do not put the earbuds into the washing machine.

Battery Warning

1. The battery in the product may cause fire disaster or risk of chemical burning if mishandled.

2. Please charge with a rated voltage charger.

3. The discard of battery should obey local law, if possible please recycle it. Do not dispose it as household garbage, because it may cause a explosion.

4. Users are not allowed to take out or replace battery in the product unless there is a stipulation on user manual. It is very hazardous to do this, may cause a damage to product.

NOTE: This equipment has been tested and found to comply with the limits for a Class B device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.

- Increase the separation between the equipment and receiver.

- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: 2BONF-HTT-11

13