

尺寸: 75*75mm



HTT-15
USER MANUAL
True Wireless Stereo

Package Contents




Charging Case x 1PC
Earbuds x 1 Pair
Type-C Charging Cable x 1PC
User Manual x 1 PC

Product Overview




Charging Pin
Type-C Port
Ambient Noise Cancellation Mic
Hide LED Indicator
Microphone
Charging Pin

Touch Control Diagram




The touch area (MFB Touch Panel) is located in the upper part of earbuds handle. (MFB) Touch Panel

Wearing Earbuds




Note: The left earbud marked with L is worn in the left ear, and the right earbud marked with R is worn in the right ear.

Power ON/ OFF



Power on
Auto: Open the charging case and take out the earbuds to power on
Manually: Press and hold the MFB for 3s.
Open and take out the earbuds to power on
Power off
Auto: Put both earbuds in your charging case, Close the lid.
Manually: Press and hold the MFB for 5s.
Put earbuds to power off
Touch to turn off

Pairing



1. Open the charging case, and take out the earbud, earbud will pair automatically. One of the earbuds flashes blue and red, the another earbud light goes out.
2. Activate Bluetooth on the device, turn on Bluetooth, search for pairing name "HTT-15" and click on it.

Bluetooth Lost



1. Turn off mobile phone's Bluetooth, earbuds will enter the pairing mode and can pair with other devices.
2. If the connection range is exceeded, the earbuds will enter the back connection mode. No connection within 5 minutes, the earbuds will turn off.

Notes For Signal Transmission Distance (as illustrate)




Tip: Next use, Open the charging case, earbuds auto connect phone.
Single Mode: When on dual mode, put one earbud into the charging case, Only take one earbud out of the charging case and connect it.

C Reset

When earbuds accidentally only get one earbud to work, or fail to pair, please reset the earbuds.

1. Delete all "HTT-15" Bluetooth records on the phone, and turn off Bluetooth
2. Put earbuds into charging case, and then take out to pairing mode, tap L & R MFB 5 times simultaneously, hear "DU" prompt voice to clear all pairing.
3. Put earbuds into charging case.



Remove HTT-15 records
Put earbuds into charging case

Touch Operation



1x Tap / Pause: Tap the MFB once
2x Previous Track: Double tap the left MFB
3x Volume -: Triple tap the left MFB
4x Game mode: Four tap the MFB
1.5s Voice assistant: Press and hold the MFB for 1.5s

Touch Operation



1x Tap / Pause: Tap the MFB once
2x Next Track: Double tap the right MFB
3x Volume +: Triple tap the right MFB
4x Game mode: Four tap the MFB
1.5s Voice assistant: Press and hold the MFB for 1.5s

Earbuds low battery alarm



When the battery power is low, every 1 minute voice reminder "Lower battery" and Red light double flashing, until the battery power is run out and turn off.

Charge your earbuds



Place your earbuds into the charging case and close the lid, earbuds automatically complete charge.

Product Parameter

Earbud(each)

| | |
|--------------------|--------------------------------|
| Model Name: | HTT-15 |
| Bluetooth Version: | V5.4 |
| Speaker: | Ø13mm |
| Bluetooth Range: | 10m/ 33ft (with out obstacles) |
| Technology: | HSP/HFP/ A2DP/ AVRCP |
| Frequency Range: | 20Hz-20KHz |
| Weight: | 4g |
| Size: | 33*21*19mm |

Charging Case

| | |
|-------------------|--------------|
| Weight: | 34g |
| Size: | 54*46*27mm |
| Charging Time: | 2H |
| Battery Capacity: | 400mAh |
| Play Music Time: | 6H |
| Input: | DC 5V ±0.08A |

Earbuds Warning

1. Please do not place the product in an environment where the temperature is too high, too low, or too humid.
2. Do not dismantle, repair the earbuds under any circumstances, if necessary, please send the product to the seller for repair.
3. Do not throw and drop the earbuds to avoid damage.
4. The earbuds and the BT devices will be disconnected if the distance between them is more than 10 meters.
5. Keep the device and accessories away from children and pets.
6. Do not put the earbuds into the washing machine.

Battery Warning

1. The battery in the product may cause fire hazard or risk of chemical burning if mishandled.
2. Please charge with a rated voltage charger.
3. The disposal of battery should done carefully, if possible please recycle it, Do not dispose it as household garbage, because it may cause a explosion.
4. Users are not allowed to take out or replace battery in the product unless there is a stipulation on user manual. It is very hazardous to do this, may cause a damage to product.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different than that to which the receiver is connected.
- Consult an experienced radio/TV technician for help.
Changer or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

FCC ID: 2BONF-HTT-15