



HTT-17

USER MANUAL

True Wireless Stereo

Charging Case × 1PC

Earbuds × 3 Pair

Type- C Charging Cable × 1PC

User Manual × 1 PC

The diagram illustrates the components of the charging case and the earbuds. The top part shows the open charging case with labels for the 'Type-C Port' (on the bottom lid), 'LED Indicator' (on the bottom lid), 'Charging Pin' (on the interior of the lid), and 'Ambient Noise Cancellation Mic' (on the interior of the lid). The bottom part shows the earbuds with labels for the 'Touch Area (MFB)' (on the side of the earbud), 'Mic' (on the side of the earbud), and 'Charging Pin' (on the bottom of the earbud).

(MFB)
Touch Panel

Wearing Earbuds

Note: The left earbud marked with L is worn in the left ear, and the right earbud marked with R is worn in the right ear.

Open cover and take out the earbuds to power on

Touch to turn on

Power off

Auto: Place both Earbud in your charging case, Close the lid.

Manually: Press and hold the MFB for 5s.

Touch to turn off

Diagram illustrating the connection process:

- The earbud case is open, and the earbuds are shown connecting to the smartphone.
- The smartphone screen displays the Bluetooth settings, showing the earbuds as available devices.

Diagram illustrating the effect of signal strength on NFC communication:


- Top scenario: Signal strength $\leq 10\text{m}$ works normal. The smartphone successfully connects to the NFC tag.
- Bottom scenario: Signal strength $\geq 10\text{m}$ will be interrupted. The signal is shown as interrupted (red X), indicating a failed connection.








Remove HTTP-17 records

Tap L&R 5 times simultaneously

Put earbuds into charging case

Left Earbud



-  1x Play / Pause
Tap the MFB once
-  2x Previous Track
Double tap the left MFB
-  3x Volume -
Triple tap the left MFB
-  4x Game mode
Four tap the MFB
-  1.5s Voice assistant
Press and hold the MFB for 1.5s
-  1x Answer the call
Tap the MFB once
-  2x End Call /Reject call
Double tap the MFB

The diagram shows a right earbud with a touch-sensitive surface. A hand is shown tapping the earbud. Below the earbud, there are two columns of touch controls, each with an icon, a tap count, and a description.

Icon	Tap Count	Action
Play/Pause	1x	Play / Pause
Tap		Tap the MFB once
Next Track	2x	Next Track
Double Tap		Double tap the right MFB
Volume Up	3x	Volume +
Triple Tap		Triple tap the right MFB
Game Mode	4x	Game mode
Four Tap		Four tap the MFB
Voice Assistant	1.5s	Voice assistant
Press and Hold		Press and hold the MFB for 1.5s

Lower battery

Lower battery

Charge your earbuds

Place your earbuds in the charging case and close the lid, earbuds automatically complete charge.

The diagram illustrates the process of charging the earbuds. It starts with a hand placing an earbud into the open charging case. The case is then closed. Finally, the case is shown with a charging indicator light, indicating that the earbuds are charging.

Charging Case	
Weight:	41.88g
Size:	56.5*31.3mm
Charging Time:	2H
Battery Capacity:	400mAh
Input:	DC 5V \equiv 0.3A

1. The battery in the product may cause fire disaster or risk of chemical burning if mishandled.
2. Please charge with a rated voltage charger.
3. The discard of battery should obey local law, if possible please recycle it. Do not dispose it as household garbage, because it may cause a explosion.
4. Users are not allowed to take out or replace battery in the product unless there is a stipulation on user manual. It is very hazardous to do this, may cause a damage to product.



FCC ID: 2BONF-HTT-17