

LED 随贴屏



使用说明书

全彩LED屏/自定义编辑/海量素材

1. 远程控制功能说明




2.应用下载

- 请在APP Store或者Google Play搜索“Pixel Glow”进行下载，或者扫描下方二维码，选择对应的平台下载。



扫码下载

2. 应用下载



- 如果你没有APP Store或
Google Play, 请点击第三个
从本地服务器直接下载。


3.应用安装

下载安装完成后,打开APP请同意所有请求的权限

否则可能设备无法正常使用



4.连接蓝牙设备



- 请同意所有权限选项
- 点击此区域, 添加蓝牙设备
- 若安卓无法搜索到蓝牙, 请检查手机是否打开定位


5.主界面介绍



6.播放设置



7.个人中心




▪ 检测APP更新

▪ 清除APP缓存


存数据

▪ 用户登录与注册


▪ 《用户协议》《隐私政策》《免责声明》
▪ 切换语言



8. 素材广场



8. 素材广场




- 直接在设备播放



- 下载到本地图库

- 添加到播放列表



11.文字编辑




12. 图片

选择手机上的照片或视频，
裁剪出相应大小


跳转到涂鸦/动画界面进行
二次创作



13.涂鸦



选择手机相册图片/拍照



撤销/恢复


选择文字
颜色

保存/播放涂鸦素材

工具栏

画笔	图形
橡皮擦	清除画布
镜像对称作画	
关闭工具栏	播放效果
调整图象位置	放大画板

14. 动画




- 编辑帧 ←
- 预览效果 →
- 播放速度 →
- 插入帧 →
- 拍照/图片 →
- 保存/播放动画素材 →


3. 应用安装



9.我的作品




15.拍照



通过相机拍摄图片后，跳转到
涂鸦界面进行二次创作

10.遥控器




遥控器开关

16. 图文组合



16. 图文组合



17. 注意事项

1. 屏幕存放时, 可将屏幕正面内弯折放, 但要避免弯曲过度, 请勿将正面向外过度外卷, 容易导致屏幕胶面裂开或者出现线路断裂。



2. 正常放置时, 请勿用重物压屏幕。



3. 请将本产品远离儿童, 以防儿童误食。

18.关于USB接口说明

推荐使用	安卓手机原装充电器	功能正常
	移动电源	功能正常
	车载USB接口5V/2A	功能正常
	车载充电器5V/2A	功能正常
可使用	USB电源排插	某些内容显示会熄屏、蓝牙连接错误、颜色偏黄
	苹果手机充电器	
请勿使用	电脑、电视机USB接口	1.某些内容会熄屏、蓝牙连接错误、颜色偏黄
	汽车U盘接口	2.可能会损坏USB接口、或电压不符 3.请勿使用低于5V/2A的USB接口
	非标手机充电器	1.烧坏芯片、永久性损坏屏幕
	改装USB接口	2.发热、起火等风险

温馨提示：

- 1.在使用过程中出现任何异常现象，均可能与USB接口选择错误有关。
- 2.若仍然无法解决问题，请联系客服人员

警告:此设备符合FCC(联邦电信委员会)的第15条规则。它的操作受以下两个条件约束:

- (1).此设备可能不会产生有害干扰;
- (2)本设备必须允许接受任何接收到的干扰,包括可能导致意外操作的干扰。

未经合规责任方明确批准的变更或修改可能会使用户失去操作设备的权限。

注:根据美国联邦通信委员会规则第15部分的规定,该设备经过测试,符合B类数字设备的限制。这些限制旨在提供合理的保护,防止住宅安装中的有害干扰。该设备产生、使用并可辐射射频能量,如果不按照说明安装和使用,可能会对无线电通信造成有害干扰。然而不能保证在特定的安装中不会发生干扰。如果该设备确实对无线电或电视接收造成有害干扰,可以通过关闭和打开设备来确定,则鼓励用户尝试通过以下一种或多种措施来纠正干扰:

- 调整接收天线的方向或位置。
- 增加设备与接收器之间的距离
- 将设备连接到与接收器连接的电路不同的插座上。
- 向经销商或有经验的无线电/电视技术人员寻求帮助

注意:此设备及其天线不得与任何其他天线或发射器一起放置或操作射频暴露声明为遵守FCC的射频暴露指南,本设备应安装和操作本设备时,应与人体散热器保持至少20厘米的距离。本设备及其天线不得与任何其他天线或发射器共置或一起使用。

a)声明“请立即根据当地法规回收或处理废旧电池,并远离儿童。

请勿将电池丢弃在家庭垃圾中或焚烧。

b)声明“即使是废旧电池也可能导致严重伤害或死亡。

c)声明“请致电当地毒物控制中心获取治疗信息。”

d)指示兼容电池类型声明(例如,LR44、CR2032)。(LR44、CR2032)。(LR44、CR2032)。

e)指示标称电池电压的声明。3.7v

f)声明“不可充电电池不能充电。

g)声明“请勿强行放电、充电、拆卸、加热至(制造商指定的温度等级) 以上或焚烧。

这样做可能会因排气、泄漏或爆炸而导致化学灼伤,从而造成伤害。

a)“确保电池按照极性(+和-)正确安装。”

b)“请勿混用新旧电池、不同品牌或类型的电池,例如碱性电池、碳锌电池或可充电电池。

c)“根据当地法规,从长期未使用的设备上取出并立即回收或处置电池。

d)“始终完全固定电池仓。”如果电池仓无法牢固关闭,请停止使用该产品,取出电池,并将其放在儿童接触不到的地方。”

Flex Matrix LED



User Manual

Full color LED screen/Custom editing/Extensive Media Library

1. Remote Control



2. Download APP

- Download on the App Store or Google Play by searching for 'Pixely Glow,' or scan the QR code below to download for your platform.



Scan to Download

2. Download APP

- If you don't have access to the App Store or Google Play, click the third option to download directly from our local server.




3. Install

- After installation, please grant all requested permissions when opening the app
- otherwise some features may not work properly




4. Connect Bluetooth Device




- Please grant all permission requests
- Tap the area to add a Bluetooth device
- If Android cannot detect Bluetooth, please verify your phone's location services are enabled

5. Main Interface Overview




6. Playback Settings





- Brightness Adjustment
- Playback Speed
- Display Rotation
- Flip Effect

7.Account




- Sign In / Sign Up
- "Terms of Service"
"Privacy Policy"
"Disclaimer"
- Check for
Updates
- Clear App
Data
- Change Language
- Logout

8. Gallery




8. Gallery



- Save to Local Gallery
- Add to Playlist
- Play on Device




11.Text




- Text Display Effect
- Text Animation
- Enter Text
- Text Coloring
- Border Effects
- Typography Settings
- Save to Library | Play Now

12. Picture



- Select photos or videos from your phone and crop them to the desired



- Go to Doodle/Animation mode for editing





13.Drawing



- Select from photo library / Take a photo
- Undo/Redo
- Tools
 - Brush
 - Eraser
 - Shapes
 - Clear Canvas
 - Mirror Drawing
 - Toggle Toolbar
 - Play Preview
 - Adjust Alignment
 - Zoom Canvas


14.Animation



3. Install




9. My Creations




- Library
- Preset work
- Playlist

15. Take a Photo




After taking a photo with the camera, jump to the doodle interface for secondary creation.

10. Romote Control




Power Switch

16.Image-Text



16. Image-Text



17.Attentions

1. When the screen is stored, the front of the screen can be bent inside, but to avoid excessive bending, do not over-roll the front of the screen, which is easy to cause the screen rubber surface to crack or the line to break.



2. When normally placed, do not press the screen with heavy objects.



3. Keep this product away from children to prevent accidental ingestion.

18.USB Interface Selection

Recommended	Original Android Phone Charger	OK
	Power Bank	OK
	Vehicle USB Interface 5V/2A Vehicle Charger 5V/2A	OK
Normal Use	Power Strip USB	Some content displays may cause screen shutdown,Bluetooth connection errors,or a yellowish color
	IPhone Charger	
Do not Use	Computer/TV USB	1. Some content will turn off the screen, the Bluetooth connection is wrong, and the color is yellow. 2. It will cause damage to the USB interface, or the voltage does not match. 3. Do not use USB interface below 5V/2A.
	Car U Disk Interface	1. Burn out the chip and permanently damage the screen 2. Heat, fire and other risks
	Non-Standard Phone Charger	1. Burn out the chip and permanently damage the screen 2. Heat, fire and other risks
	Modify USB interface	1. Burn out the chip and permanently damage the screen 2. Heat, fire and other risks

Reminder:

1. Any abnormal phenomena that occur during use maybe related to incorrect selection of the USB interface.
2. If the problem still cannot be resolved, please contact customer service.

Warning:

This device complies with Part 15 of the FCC Rules, Operation is subject to the following two conditions:

(1)This device may not cause harmful interference, and

(2)This device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-- Reorient or relocate the receiving antenna.

-- Increase the separation between the equipment and receiver

-- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected

-- Consult the dealer or an experienced radio/TV technician for help

NOTE: This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter RF Exposure Statement

To maintain compliance with FCC's RF Exposure guidelines, this equipment should be installed and operated with minimum distance of 20cm the radiator your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna nr transmitter

- a)The statement "Remove and immediately recycle or dispose of used batteries according to local regulations and keep away from children. Do NOT dispose of batteries in household trash or incinerate."
- b)The statement "Even used batteries may cause severe injury or death."
- c)The statement "Call a local poison control center for treatment information."
- d)A statement indicating the compatible battery type (e.g., LR44, CR2032). (LR44,CR2032).(LR44, CR2032).
- e)A statement indicating the nominal battery voltage. 3.7v
- f)The statement "Non-rechargeable batteries are not to be recharged."
- g)The statement "Do not force discharge, recharge, disassemble, heat above (manufacturer 's specified temperature rating)or incinerate. Doing so may result in injury due to venting, leakage or explosion resulting in chemical burns."

- a)The statement "Ensure the batteries are installed correctly according to polarity (+ and -)."
- b)The statement "Do not mix old and new batteries, different brands or types of batteries, such as alkaline, carbon-zinc,or rechargeable batteries."
- c)The statement "Remove and immediately recycle or dispose of batteries from equipment not used for an extended period of time according to local regulations.
- d)The statement "Always completely secure the battery compartment. if the battery compartment does not close securely,stop using the product, remove the batteries, and keep them away from children."

