

User Manual



Package Content

Single Unit	Combo Pack	Full Set
• 1 x Wireless Headset	• 1 x Wireless Headset	• 2 x Wireless Headsets
• 1 x Charging Cable	• 1 x U7 Transmitter	• 1 x U7 Transmitter
• 1 x User Manual	• 1 x Charging Cable	• 2 x Charging Cables
	• 1 x User Manual	• 1 x User Manual

Product Features

Bluetooth Mode: Answer, hang up, or reject calls, and listen to music on your device.

Music Mode: Supports local audio file playback via the built-in TF card.

Team Mode: While most wireless headphones on the market offer basic features like Bluetooth and music modes, the M11 wireless headphones not only include these two functions but also add an innovative feature: Team Mode. This unique feature allows multiple users to share audio in quiet environments without disturbing others. It's perfect for group activities such as TV watching, video conferencing, seminars, group training, collaborative work, community events, product launch conferences, speeches, and more.

Recording: Supports both phone call recording and music mode playback recording.

Lightweight: Designed according to ergonomics, providing a comfortable fit that stays secure during sports activities.

Product Specifications

Bluetooth Version	V5.3
Bluetooth Protocols	HSP, HFP, A2DP, AVRCP
Connection Range	≤12 meters (Approx 39 feet)
Battery Type	3.8V, 100mAh Polymer Battery
Water Resistance	IPX4
Built-in TF Card Capacity	512MB
Audio File Format (in Music Mode)	MP3, FLAC, WAV, WMA
Music Time	Approx 6 hours (at medium volume)
Talking Time	Approx 6 hours (at medium volume)
Standby Time	Approx 80 hours
Charging Time	Approx 1 hour 20 minutes (0%-100%)
Charging Port	Charging / File Transfer
Operating Voltage	3.3V~4.2V
Operating Temperature	0°C~40°C (32°F~104°F)
Rate Power	18mW~25mW
Transmitter Range	≤50 meters (164 feet, obstacle-free) / 20 meters (66 feet, with obstacles)
Compatible Devices	Bluetooth-enabled devices, requiring iOS/Android 4.0 or later, or Windows

How to wear



Product Overview




①Power Button

②Mode Button

③Speaker

④Magnetic Charging Port

⑤Microphone



Bluetooth Mode

Start to pair the headphones with your Bluetooth devices.

Step 1: Long press the ①power button. Voice prompt: "Power on".

Step 2: Long Press the ②mode button to switch mode until voice prompt: "Bluetooth mode, please press any button to enable Bluetooth".

Step 3: Press either button ① or ② once to activate pairing. Open your device's Bluetooth settings, search for device "M11", and select to pair.

Step 4: Voice prompt "Connected" indicates successful pairing. If not, please long press the ①power button and ②mode button simultaneously to reset Bluetooth pairing process, then repeat previous operation.

Manage your calls and music

Task	Operation
Answer call	Single click ①power button or ②mode button
Hang up call/Reject call	Long Press ①power button or ②mode button
Play or pause music	Triple click ②mode button
Next track	Single click ①power button
Previous track	Single click ②mode button
Adjust volume +	Double click ①power button
Adjust volume -	Double click ②mode button

Music Mode

Music Download

Step 1: Long press the ①power button to turn off the headphones.

Step 2: Connect to computer via the charging cable and wait "Removable Disk" prompt appears.

Step 3: Transfer audio files to removable disk.

Step 4: Safely eject disk after transfer files.

Tips: If the file transfer fails, please check the remaining disk space.

Music Playback

Step 1: Long press the ①power button to turn on the headphones.

Step 2: Long press the ②mode button to switch to music mode, the audio files will play automatically.

Recording

Step 1: Triple click the ①power button to start recording.

Step 2: Triple click the ①power button to stop recording.

Step 3: The recorded audio files are saved in the headphones' internal storage. Please connect the headphones to your computer via the charging cable and access the "REC" folder in the "Removable Disk".

Tips: If the recording fails, please check the remaining disk space (at least 50MB available).

Team Mode

Simply plug the transmitter into the device's interface for instant use (iOS/Android 4.0 or later, or Windows).

If team mode doesn't work, please follow the steps below to reset.

Step 1: Insert transmitter into USB port (white LED lights up).

Step 2: Long press transmitter's "M" button for 5 seconds until white LED blinks twice per second.

Step 3: Long press the ②mode button to switch mode.
Voice prompt: "Team mode".

Step 4: Click the ②mode button four times quickly. Voice prompt: "Team up".

Step 5: Voice prompt "Team mode successfully", the process is complete.
If not, please repeat the previous steps.

If you have multiple M11 headphones to team up with one transmitter, please follow the steps below:

Step 1: Insert the transmitter into the USB port (the white LED lights up).

Step 2: Long press the transmitter's "M" button for 5 seconds until the white LED blinks twice per second.

Step 3: Long press the ②mode button on the multiple headphones to switch mode.
Voice prompt: "Team Mode".

Step 4: Quickly press the ②mode button on the multiple headphones four times.
Voice prompt: "Team up".

Step 5: Voice prompt "Team Mode successfully", the process is complete. If not, please repeat the previous steps.

Cautions

1. Please fully charge the device before first use.
2. Avoid using fast chargers. It is recommended to use a 5V/0.5A-1A charger.
3. Do not submerge the device in liquid.
4. Avoid using the device in environments exceeding 50°C / 122°F.
Low temperatures may reduce battery life by 20%.
5. Keep the magnetic charging port clean to prevent short circuits.
6. Avoid prolonged use at high volume to prevent hearing damage.

FAQ

Q1: How do I properly connect the magnetic charging cable to the headphones?

A: Bring the magnetic charging cable near the headphone's ④charging port, and it will automatically attach and align. Ensure the port is clean. The indicator light will turn red during charging.

Q2: How many headphones can be connected for shared audio playback in Team Mode?

A: The U7 transmitter supports connecting multiple M11 headphones simultaneously (with no limitation within a 50 meters/164 feet obstacle-free range), making it ideal for group activities such as watching movies, training, or collaborating.

Q3: Can the headphones be connected to both a phone and a computer simultaneously?

A: The M11 headphones do not support simultaneous connection to multiple devices. They can only be paired with one device at a time. You must disconnect the current device before pairing with another one.

Q4: Do the headphones easily fall off during exercise?

A: The headphones feature an ergonomic design that fits snugly to the ears, staying secure during exercise. They are lightweight and comfortable, making them perfect for running, gym workouts, cycling, weightlifting, and other activities.

Q5: How can you check if the headphones are fully charged?

A: The indicator light is red while charging and will turn off once fully charged.
The full charging time is approximately 1 hour and 20 minutes (0%-100%).

Q6: How do I properly clean the surface of the headphones?

A: Use a dry, soft cloth to wipe the outer casing and ear tips. Avoid alcohol or corrosive cleaning agents.

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a

Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation.

This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.

Contact Us

Email: amazon@eyotto.com

Website: www.eyotto.com