



# 80g书纸双面印刷

## 尺寸: 84.2\*124.2mm

 <p><b>SPECIFICATION</b></p> <p>Wireless: V 5.0 Sensitivity: 92dB Working range: 10m Speaker driver: 13mm Impedance: 32Ω Frequency: 20Hz - 20kHz Battery earbuds: 30 mAh</p> <p>Charging case: 230 mAh Standby time: 150 hours Charge time: 1.5 hours Working time: 5 hours Touch control - Type-C connector</p> <p><math>P_{RF}: 6 \text{ mW max}</math> <math>f: 2402 \div 2480 \text{ MHz}</math></p>	<p><b>UK USER MANUAL</b></p> <p><b>Charging the earbuds</b> Insert the earbuds into the charging case, the LED will light up. When charging is complete, it will turn off.</p> <p><b>Charging the case</b> <b>Charging via cable</b> Plug the Type C connector of the supplied cable into the Type C port on the case and the other end into a USB port. The LED on the case will flash and remain steady when charging is complete.</p> <p><b>Turning on the earbuds</b> Take the earbuds out of the charging case, they will automatically turn on and pair with each other. Or press both MLF buttons on the earbuds for 2 seconds.</p> <p><b>Turning off the earbuds</b> When you put the TWS earphones into the case, they will turn off automatically. Alternatively, press the MLF button on one of the earbuds for 5 seconds.</p> <p><b>Pairing with devices</b> 1. Take the earbuds out of the charging case: they will turn on and pair with each other automatically 2. Turn on Bluetooth on the device and search for "Migobuds" in the list of available devices, then select it. 3. After the connection is successful, start enjoying the music.</p> <table border="1" data-bbox="795 918 1306 1178"> <thead> <tr> <th>Action</th><th>Command</th><th>Key</th></tr> </thead> <tbody> <tr> <td>Play/pause music</td><td>1 tap</td><td>Left / right</td></tr> <tr> <td>Voice assistant</td><td>3 taps</td><td>Left / right</td></tr> <tr> <td>Previous track</td><td>2 seconds</td><td>Right</td></tr> <tr> <td>Next track</td><td>2 seconds</td><td>Left</td></tr> <tr> <td>Answer a call</td><td>1 tap</td><td>Left / right</td></tr> <tr> <td>End a call</td><td>1 tap</td><td>Left / right</td></tr> <tr> <td>Reject a call</td><td>2 seconds</td><td>Left / right</td></tr> <tr> <td>Recall last number</td><td>2 taps</td><td>Left / right</td></tr> </tbody> </table>	Action	Command	Key	Play/pause music	1 tap	Left / right	Voice assistant	3 taps	Left / right	Previous track	2 seconds	Right	Next track	2 seconds	Left	Answer a call	1 tap	Left / right	End a call	1 tap	Left / right	Reject a call	2 seconds	Left / right	Recall last number	2 taps	Left / right
Action	Command	Key																										
Play/pause music	1 tap	Left / right																										
Voice assistant	3 taps	Left / right																										
Previous track	2 seconds	Right																										
Next track	2 seconds	Left																										
Answer a call	1 tap	Left / right																										
End a call	1 tap	Left / right																										
Reject a call	2 seconds	Left / right																										
Recall last number	2 taps	Left / right																										
 <p><b>参数</b></p> <p>蓝牙版本: V5.0 灵敏度: 92dB 工作距离: 10米 扬声器: 13mm 阻抗: 32Ω 频率: 20Hz-20kHz 耳机电池: 30mAh</p> <p>充电仓电池: 230mAh 待机时间: 150小时 充电时间: 1.5小时 工作时间: 5小时 触控-Type-C接口</p> <p><math>P_{RF}: 6 \text{ mW max}</math> <math>f: 2402 \div 2480 \text{ MHz}</math></p>	<p><b>CN 说明书</b></p> <p><b>耳机充电</b> 耳机放入充电仓后, LED灯亮起。充满电后LED灯熄灭。</p> <p><b>充电仓充电</b> 充电仓充电, 插入TYPE-C充电, 充电仓充电是LED灯持续闪烁。充满电后LED灯常亮。</p> <p><b>耳机开机</b> 拿出耳机自动开机, 或者长按功能键2秒开机。</p> <p><b>耳机关机</b> 耳机放回充电仓自动关机, 或者长按功能键5秒关机。</p> <p><b>设备配对</b> 1.从充电仓拿出耳机, 耳机开机后左右耳自动配对。 2.打开设备蓝牙搜索, 连接蓝牙名称 "Migobuds"。 3.连接成功, 开始享受音乐。</p> <table border="1" data-bbox="795 1654 1306 1892"> <thead> <tr> <th>功能</th><th>操作</th><th>按键</th></tr> </thead> <tbody> <tr> <td>暂停/播放</td><td>按1下</td><td>左/右键</td></tr> <tr> <td>呼叫语音助手</td><td>按3下</td><td>左/右键</td></tr> <tr> <td>上一首</td><td>长按2秒</td><td>右键</td></tr> <tr> <td>下一首</td><td>长按2秒</td><td>左键</td></tr> <tr> <td>接听电话</td><td>按1下</td><td>左/右键</td></tr> <tr> <td>挂断电话</td><td>按1下</td><td>左/右键</td></tr> <tr> <td>拒绝来电</td><td>长按2秒</td><td>左/右键</td></tr> <tr> <td>回拨</td><td>按2下</td><td>左/右键</td></tr> </tbody> </table>	功能	操作	按键	暂停/播放	按1下	左/右键	呼叫语音助手	按3下	左/右键	上一首	长按2秒	右键	下一首	长按2秒	左键	接听电话	按1下	左/右键	挂断电话	按1下	左/右键	拒绝来电	长按2秒	左/右键	回拨	按2下	左/右键
功能	操作	按键																										
暂停/播放	按1下	左/右键																										
呼叫语音助手	按3下	左/右键																										
上一首	长按2秒	右键																										
下一首	长按2秒	左键																										
接听电话	按1下	左/右键																										
挂断电话	按1下	左/右键																										
拒绝来电	长按2秒	左/右键																										
回拨	按2下	左/右键																										

## FCC Statement

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

### RF Exposure Information

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.