

TARUIE AC REMOTE ユーザーマニ ア

TARUIE AC REMOTE ユーザーマニュアル

Step 1

電池を装着

* 赤ランプが点滅する



Step 2

R ボタンを 2 秒間押す

* 青ランプが点滅する



Step 3

(ペアリングモードに入る)

古いリモコンを TARUIE AC REMOTE の側面に向け IR 任意のボタンを押す

* 青ランプが点灯・消灯するとペアリング完了



Step 4

QR コードをスキャンする

スマートホームペアリングすると設定完了



TARUIE AC REMOTE 使用手冊

TARUIE AC REMOTE 使用手冊

Step 1

裝上電池

* 紅燈進行閃爍



Step 2

按下 R -2 秒

* 藍燈進行閃爍



Step 3

(進入配對模式)

將您的就遙控器對準側邊 IR 按下任一鍵

* 藍燈恆亮後熄滅即配對完成



Step 4

掃描 QRcode

進行智慧家庭配對即設定完成



TARUIE AC REMOTE user manual

FCC Warning:

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

FCC RF Radiation Exposure Statement:

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

TARUIE AC REMOTE user manual

Step 1 : Install battery in the product.



Step 2 : Press and hold the button for two seconds, then release.



Step 3 : To learn the signal, direct the remote control to the side of the TARUIE AC REMOTE. Then, press the power button on the remote control. The learning process is successful when the blue light turns off.



Step 4 : Use your phone to scan the QR code. When you add it into the APP, the setting is completed.

