

SAR Test Setup



Picture 1: Back Side, the distance from EUT to the bottom of the Phantom is 0mm




Picture 2: Back Side 2, the distance from EUT to the bottom of the Phantom is 0mm



Picture 3: Back Side 3, the distance from EUT to the bottom of the Phantom is 0mm




Picture 4: Front Side, the distance from EUT to the bottom of the Phantom is 0mm



Picture 5: Left Edge, the distance from EUT to the bottom of the Phantom is 0mm




Picture 6: Right Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 7: Top Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 8: Bottom Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 9: Back Side, the distance from EUT to the bottom of the Phantom is 0mm



Picture 10: Back Side 2, the distance from EUT to the bottom of the Phantom is 0mm



Picture 11: Back Side 3, the distance from EUT to the bottom of the Phantom is 0mm




Picture 12: Front Side, the distance from EUT to the bottom of the Phantom is 0mm




Picture 13: Left Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 14: Right Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 15: Top Edge, the distance from EUT to the bottom of the Phantom is 0mm



Picture 16: Bottom Edge, the distance from EUT to the bottom of the Phantom is 0mm