



Product Operation Manual

3+
AGES


Thank you for choosing our product! Please read this instruction manual carefully before using, as it contains all the informations you need to know about how to use this product correctly with fun.

Colors And Contents May Vary From Illustration.





REMOTELY OPERATED SUBMARINE ITEM No. : 333-JY25180B

Battery Installation



Replacing batteries of the transmitter




1. Take out the battery cover of R/C car, install 4x1.5V AA battery , fasten the cover,turn the switch to 'on'

2. Open the battery cover of transmitter, instal two 1.5V AAA batteries , close the cover.


3. support about 60 minutes playing.

The charging time is 2.5 hours and the remote control distance is 25 meters


The Basic Operation of The Products




The car has headlights, taillights, spray lights and spray functions, the car must add water to drive, when the water runs out, all functions stop, only idling sound.



The front and rear lights flash when the switch is turned on. The front and rear lights turn off after code matching, accompanied by idling sound effect. The front lights and spray lights turn on when moving forward, accompanied by throttle sound effect. The tail lights and spray lights turn on when moving backward, accompanied by throttle sound effect.



Press the button as shown in the above picture to move the car forward and backward.




press the steering button to drive the car turn left or right while going forward or backward at the same time




As shown in the above picture, press this button to accelerate



Press the button as shown in the above picture to imitate the sound of real car horns.



Press the button as shown in the above picture to activate the automatic parking function.



Press the button as shown in the above picture to play songs in the car.



Gas stations require a card to be inserted before use. After inserting the card, there are three levels of water addition to choose from: 30%, 60%, and 99%. Once selected, the corresponding capacity of water will be pumped out to complete the refueling process.

BATTERY SAFETY

- (1) The placement or replacement of batteries is to be performed by an adult.
- (2) Remove the rechargeable battery from the chassis before charging.
- (3) Always remove exhausted batteries from the car and the transmitter.
- (4) Make sure the main switch is set to OFF before installing the battery pack into the car body.
- (5) Batteries must be inserted with the correct polarity.
- (6) Non-chargeable batteries shall not be recharged.
- (7) Do not short-circuit the batteries.
- (8) Always remove the batteries from the car and the transmitter after playing.
- (9) Never throw the batteries into fire to avoid explosion or leakage.
- (10) Do not mix batteries from different producers or new and old batteries.
- (11) You should only use batteries of the same or equivalent types as recommended.
- (12) Check the batteries on a regular basis to avoid leakage.
- (13) Keep this manual well for future reference as it contains important information about this product.



FCC Compliance Statements

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.