

Tablet PC

Quick use guide

matters need attention

1. Note that a new battery will only perform at its best after two or three cycles of full charge and discharge
2. To prevent data loss, it is recommended that users regularly back up important data, especially before firmware upgrade or product delivery. We are not responsible for any loss caused by the loss of data.
3. This product is a high precision electronic product, please do not disassemble it by yourself.
4. Avoid strong beating, water droplets and splashing, collision of the product.
5. Avoid using this product in the following environments: high temperature, low pressure, low temperature, damp, dusty, strong magnetic field and long-term exposure to sunlight. We recommend that you use this product at altitudes below 3,000 meters, in environments ranging from 0° to 35°C, and humidity ranging from 5% to 95%.
6. Please use batteries, chargers and accessories permitted by the manufacturer. Any other type of accessories will violate the warranty regulations and may be dangerous.

Warm reminder

◆ The nominal service life of this product refers to the longest service life that can be achieved under the environment of minimum power consumption. Actual battery life may vary depending on usage and environment (e.g. WIFI, Bluetooth, screen brightness, Volume) and other factors, and there are subtle differences in individual products.

◆ The reasons for the difference between the nominal disk capacity and the actual disk capacity are as follows:

1. Errors caused by calculation algorithm: Hardware vendors is calculated according to $1\text{ MB} = 1000\text{ KB}$, and software is calculated according to $1\text{ MB} = 1024\text{ KB}$, such as hardware nominal 8 GB products, conversion software recognition capacity for $8 * 1000\text{ MB} * 1000\text{ KB} * 1000\text{ b} / 1024\text{ MB} / 1024\text{ KB} / 1024\text{ b}$ 7.45 GB material,

This results in a calculation error of 0.55GB, and the larger the capacity of the product, the larger the algorithm error.

2. The Android operating system occupies some disk space.

◆ The nominal battery capacity of this product is through the calculation of the actual charge in the process of charging and discharging, the use of third party tools to detect the battery capacity, due to current fluctuations, there will be a large error, Therefore, it is not used as a criterion.

First startup wizard

This wizard will help you quickly select the language, time zone, WiFi network, user and computer name and other information, you can follow the wizard prompts, user-friendly Settings, start your value experience.



Key definition

- Power key:.....
 - ◎ In the off state, long press the power button for 3 seconds to start up
 - ◎ In the startup state, short press the power button to turn off the screen and hibernate. When the screen needs to be activated, short press the power button again
 - ◎ In the startup state, long press for 3 seconds to enter the shutdown prompt interface, long press for 10 seconds to force power off
- Volume key: short press or long press, can increase the volume
- Volume reduction key: short press or long press, can reduce the volume

Charger adaptation requirements

- ◎ Charger adaptation please refer to the input voltage/current value on the back of the product you purchased.
- ◎ This product only supports the chargers with the above specifications, and the chargers must conform to Chinese national standards
- ◎ If the machine is not used for a long time, please charge the machine once every three months, and then shut it down after full charge.
- ◎ The machine placed for a long time needs to be precharged by the charger for more than 30 minutes before showing the charging state when it is used for the first time.

Virtual key bar

	HOME button	Click to return to the main interface
	Return key	Click to return to the upper-level interface
	Background key	Click to view, switch, close the background program
	Menu key	Click to bring up menu options
	Screen capture key	Click to save a picture of the current screen
	Volume plus key	Press or hold to increase the volume
	Volume reduction key	Short or long press to reduce the volume
		Pull down the notification bar
	User	Click to quickly switch to the current user
	Set	Click to quickly bring up the system Settings
	Battery	Tap to quickly bring up battery Settings
	Wi-Fi	Tap to quickly enable or disable Wi-Fi
	Bluetooth	Tap to quickly turn Bluetooth on or off
	Contextual mode	Click to quickly adjust the volume



Flight mode

Click to quickly turn on or off airplane mode



Automatic rotation
Location information

Tap to quickly turn on or off the lock screen orientation

Projection screen

Click to quickly enable or disable the location function

Click to quickly turn on or off the search wireless display device

Wi-Fi wireless connection

1. Tap the "Settings" icon to enter the Settings list screen. Tap and select "WLAN" or "Wi-Fi" to enter the Wi-Fi Settings menu.
2. Swipe the switch to enable the Wi-Fi function, and the system will automatically scan the Wi-Fi hot spot signal of the attachment;
3. Select and click the Wi-Fi signal that can be connected, enter the corresponding password, and click "Connect".

Card and mobile network connection

1. Insert the SIM card in the off state and power it into the system;
2. Click the "Settings" function icon to enter the setting list interface, and click and select the "Traffic Usage" menu:
3. Swipe the switch to open the "Mobile Data Network".
- 4, insert bayonet in the right shell of the white cover, buckle open the white cover can be installed card; Note: Chip facing down

Bluetooth connection

1. Click the "Settings" function icon to enter the Settings list interface, click and select the "Bluetooth" menu;
2. Swipe the switch to turn on the Bluetooth function, and the system will automatically scan the Bluetooth signal of the attachment;
3. Select and click the Bluetooth device that can be connected. In the "Bluetooth Pairing Request" displayed, click "Pairing".
4. When the other device is confirmed, the connection is successful.

Display setting

Click the "Settings" function icon to enter the Settings list interface, click and select the "Display" menu

- 1, brightness: swipe the progress bar can adjust the screen backlight display brightness;
2. wallpaper: You can set the desktop wallpaper display content;
3. Sleep: You can set the time when the system is not operating, and the system will automatically turn off the screen for sleep;
- 4, font size: can set the size of the system display font;
5. Automatic rotation: The river setting locks the current screen direction, or automatically rotates the screen direction according to the device direction

Sound setting

Click the "Settings" icon to enter the Settings list interface. Click and select the "Sound and Notification" menu

1. Volume: Swipe the progress bar to adjust the volume of media, alarm clock and bell;
2. Notification ringtone: You can set notification ringtone;
- 3, mobile phone ringtone: can set the ring tone;
4. Other tone: You can turn on or off the screen lock tone and touch the direction of the tone screen
- 5.

Battery status display

Click the "Settings" function icon to enter the Settings list interface, click and select the "Battery" menu,

You can view the battery usage

Electric quantity display switch: swiping switch can turn on or off the electric quantity percentage display effect.

can't turn it on, I can't charge it

1, there is a small hole next to the power button with a toothpick poke, and then long press the power button, ten seconds to start.

2, the tablet charge for more than 30 minutes, then press the boot.

Application management

Click the "Settings" function icon to enter the Settings list interface, click and select the "Application" menu,

You can uninstall an application. Clear default operations. Clear cache data.

1. Third-party applications: Uninstalls
2. System application: Non Uninstallable

user

Click the "Settings" function icon to enter the Settings list interface, click and select the "User" menu

1. Support multi-user login;
2. Each user can set his own personal application and content

Location information

Click the "Settings" icon to enter the Settings list interface. Click and select the "Location Information" menu.

1. Flick the switch to open or close the positioning function;
2. Click "Mode" to select the positioning method respectively.

Security setting

Click the "Settings" icon to enter the Settings list interface. Click and select the "Security" menu.

1. Screen lock mode: Sliding, pattern, PIN code, password screen lock mode can be selected respectively;
2. Unknown source: Flick the switch to set whether to allow the installation of local applications.

Language and input methods

Click the "Settings" function icon to enter the Settings list interface, click and select the "Language and Input method" menu.

1. Language: switchable system language;
2. Input method: You can set the default input method of the system and set the function of each input method.

Account management

Click the "Settings" function icon to enter the Settings list interface, click and select the "Account Management" menu

1. Add an account: You can add an account of the application program in the system;
2. Data synchronization and other management functions can be performed for existing accounts.

factory data reset

1. Click the "Settings" icon to enter the Settings list interface, click and select the "Backup and Reset" menu, and select "Factory Settings Restoration".
2. Restoring factory Settings will clear all user data (programs, local data, etc.). Please pay attention to backup.

Date and time

Click the "Settings" function icon to enter the Settings list interface, click and select the "Date and time" menu.

1, automatic date and time determination: swipe open function, can realize the system in the state of network connection,

Automatically synchronize date and time. Swipe close function, you can manually set the date and time;

2, automatically determine the time zone: swipe open function, can realize the system is connected to the network state,

Automatically synchronize time zones. Swipe close function, you can manually set the time zone;

3, use 24 hours format: swipe open function, can realize the time using 24 hours system display.

USB OTG function

USB OTG function can support the connection between this product and other mobile devices (U disk, mobile hard disk, 3G network card, mouse, keyboard, etc.) for data exchange.

1. To use the USB OTG function, the mobile device must be connected to the product through the OTG cable;

2. Using USB OTG function, the battery power of this product must be kept above 50%; Independent power supply device should be used for high-power mobile device connection.

FCC statement

This device complies with part 15 of the FCC rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Specific Absorption Rate (SAR) information:

This device meets the government's requirements for exposure to radio waves. The guidelines are based on standards that were developed by independent scientific organizations through periodic and thorough evaluation of scientific studies. The standards include a substantial safety margin designed to assure the safety of all persons regardless of age or health. FCC RF Exposure Information and Statement the SAR limit of USA (FCC) is 1.6 W/kg averaged over one gram of tissue. This device has also been tested against this SAR limit. This device was tested for typical body-worn operations with the back of the device kept 0mm from the body. To maintain compliance with FCC RF exposure requirements, use accessories that maintain a 0mm separation distance between the user's body and the back of the device. The use of belt clips, holsters and similar accessories should not contain metallic components in its assembly. The use of accessories that do not satisfy these requirements may not comply with FCC RF exposure requirements, and should be avoided.