

Product manual

Specification

Term	Description
Speaker Output	3W 4Ω
Speaker Size	205*51*51mm
Bluetooth Version	JL5.2
Frequency Resp.	20Hz-18KHz
SNR	65dB
Impedance	4ohm

Function Description



售后服务细则

一、用户自购买之日起，在正常使用的情况下产品若出现质量问题，我们将遵守《微型计算机商品修理更换退货责任规定》中的细则进行处理：

1. 整机一年内免费保修；
2. 售后服务方式：包换服务：包换期内的产品，若出现质量问题，用户可以到经销商处免费换新，（外观损坏作保修处理）；
3. 保修服务：保修期内的产品，若出现质量问题，用户可以到当地售后服务中心享受保修服务；
4. 维修服务：维修期内的产品，若出现质量问题，用户可以到当地售后服务中心委托经销商要求维修服务。

二、不能享受：“三包”的情况

- 1、购买日以购货发票为准（无购货发票和售后服务卡的，但能有效证明产品确属服务期内的，可以修理、换货、不能提供有效证明的，以生产日期为准）；

2、质量问题不包括用户个人对质、音色的主观异议；

3、包换、保修服务只限于一般使用下有效，一切人为损坏（如自行拆装、不适当的连接使用、接入不当的电源、未依说明书使用等）因运输及其他意外造成的损坏、自然灾害等不可抗力、售后服务细则的物品实物标识不相符的、未经公司认可之维修服务、包装等均不在包换、保修范围之内、维修服务适当收费。

4、保修服务不包括外壳、说明书、包装；

5、对停产型号产品的服务本公司公做功能性修复

（外观可能与原产品有异）

四、特别注意事项

1、要求服务时请携带售后服务卡及购机发票正本；

2、请妥善保存售后服务卡及购机发票；

3、售后服务卡不得涂改，否则作废。



技术参数

技术参数			
尺寸	205*51*51mm	喇叭规格	1.5寸
工作电压	5V	充电	DC 5V/1A-2A
功率	3W	蓝牙版本	杰理5.2

HOW TO USE

Operation manual while receiving the product make sure that it is unbroken and there are no freely moving objects inside the product.

Function description of power bank

The charging port of the speaker is both an input port and an output port.
1. When you need to charge the speaker, please use the standard USB charging cable Charging (the power bank cannot charge the speaker).
2. When you need a speaker as a power bank to charge your mobile phone, please use the standard TYPE C port cables charge the mobile phone.
3. If you need to charge the old iPhone, please use the Apple official Square TYPE C-head charging cable charging.

Description of the recording function

1. Recording: Insert the TF card and press 1 (mode switch key) to enter the recording. Recording mode, long press 3 (play key) to start recording Sound, press 1 (MODE key) to stop recording.

2. Recording playback: Press 1 (mode key) to switch to music playback mode. Type (Play by TF card), if there are more than one recording, it will loop Play, you can also press the upper and lower songs to switch content, or long press 3 (playKey) to delete the currently playing recording.

Radio function description

Long press 1 (3 seconds) to turn on, short press 1 (MODE key) to tune to radio Machine mode (FM mode), long press 3 (play/pause key) to automatically search Channel, automatically save after channel search, press 2 (previous key) 4 (next key) to switch channels.

Description of the indicator light

1. When it is not turned on and charged, there is a red light and a blue light. Flashing fully charged, a blue light and a green light stay on.
2. When the power bank discharges to the outside, there is a blue light that is always on. The blue light flashes.

Turn off the device each time, when it is not planned to use it for extended period of time.
Keep away from vibrations and mechanical stresses, which can cause mechanical damaging of the product.

In case of mechanical damage no warranties are provided.

Do not disassemble. This product does not contain parts that are entitled to self-sufficient repair.

Keep away from children under the age of 3. may contain small parts.

Do not use the product at temperatures below and above recommended temperatures (see the operation manual); under the conditions of humidity evaporation, as well as in hostile environment.

Do not use in the presence of visual damage. Do not use when the product is obviously defective.

Do not use the product for industrial, medical or manufacturing purposes.


While receiving the product make sure that it is unbroken and there are no freely moving objects inside the product.

Thank you for purchasing our product Bluetooth Speaker, please read this user manual carefully before using. Our company does not accept any responsibility for personal injury caused by improper use or products which have been damaged by negligence or willful actions.



Made In China

功能描述



充电宝功能描述

音箱充电口即是输入口也是输出口。
1. 需要给音箱充电时, 请用标配的USB充电线充电(充电宝无法给音箱充电)。

2. 需要音箱做充电宝给手机充电时, 请用标配的两头TYPE C口线给手机充电。

3. 如果需要给老款苹果手机充电, 请用苹果官方TYPE C头充电线充电。

录音功能描述

1. 录音：插入TF卡, 按1 (模式切换键) 进入录音模式(Recording mode), 长按3 (播放键) 开始录音, 按1 (MODE键) 停止录音。

2. 录音播放：按1 (MODE键) 切换到音乐播放模式 (Play by TF card), 如果有多段录音会循环播放, 也可以按上下曲切换内容, 也可长按3 (播放键) 删除当前播放的录音。

收音机功能描述

长按1 (3秒) 开机, 短按1 (MODE键) 调到收音机模式 (FM mode), 长按3 (播放/暂停键) 自动搜台, 搜台后自动保存, 按2 (上一曲) 4 (下一曲) 切换频道。

指示灯描述

1. 未开机: 充电时, 有一个红灯长亮, 一个蓝灯闪烁; 充满电: 一个蓝灯和绿灯长亮。

2. 充电宝对外放电时, 有一个蓝灯长亮, 一个蓝灯闪烁。

产品说明书

Product manual

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.
The device can be used in portable exposure condition.



MADE IN CHINA