


FUN 5





5按钮功能键：

1. 长按“中键”3秒打开5按钮功能，手机搜索 FUN 5 Box 点击配对并连接。
2. 新手机连接，需先在旧手机断开与FUN 5 Box 的蓝牙连接，新手机搜索 FUN 5 Box 点击配对并连接
3. 断开蓝牙连接后1分钟，5按钮功能自动关闭节省能耗；如需使用，请再次长按“中键”3秒打开，功能打开后会自动连接手机。

关于苹果ios设备：

使用苹果手机/平板时，请注意设置以下：

1. ios 版本14.8 以上
2. 辅助触控功能必须打开
ios 14.8以上版本需设置方可使用。

设置如下：

设置 --> 辅助功能 --> 触控 --> 辅助触控 --> 打开，屏幕出现圆点即可。



注：如无法正常操作，请调整第6步：调低跟踪灵敏度。
跟踪灵敏度调节后，需把“辅助触控”关闭后重新打开。

3. 以上2项如果确认OK, 还是不能正常使用请将手机重启一次。

安卓和鸿蒙系统手机, 蓝牙配对连接即可使用。

提示: 如因ios 系统升级造成本产品不能使用, 属不可抗力。

5按钮功能键	抖音/微信视频号	音乐播放	手机相机拍照
	● 按压 1 次 播放 / 暂停	/	/
	● 按压 2 次 点赞		
	● 按压 1 次 向上翻页	● 按压 2 次 音量增加	长按 2 秒 相机app打开时 拍照
	● 按压 2 次 音量增加		
	● 按压 1 次 向下翻页	● 按压 2 次 音量减小	长按 2 秒 相机app打开时 拍照
	● 按压 2 次 音量减小		
	● 按压 1 次 向左翻页	● 按压 2 次 上一歌曲	/
	● 按压 1 次 向右翻页	● 按压 2 次 下一歌曲	/

② 耳机使用说明

- 首次与新设备配对, 打开手机蓝牙搜索到“FUN 5”, 然后点击图标进行配对连接。
- 蓝牙自动连接: 配对成功后, 后续每次使用, 只需耳机开机就会自动连接。
- 耳机开机: 充电仓打开盖后, 耳机自动开机。
- 耳机关机: 耳机放入充电仓后关盖, 耳机自动关机。


	
音乐:播放 / 暂停 ● 点击2次	音乐:播放 / 暂停 ● 点击2次
音乐:上一曲 ● 点击3次	音乐:下一曲 ● 点击3次
电话:接听 ● 点击2次	电话:接听 ● 点击2次
电话:挂断 ● 点击2次	电话:挂断 ● 点击2次
电话来电:拒接 — 长按 2 秒	电话来电:拒接 — 长按 2 秒

③ 参数配置

蓝牙版本	5.4
通讯距离	≥ 10m
CODEC	SBC, ACC
Profile	A2DP, AVRCP, HFP, HSP
按键	充电仓:按钮, 耳机: 触摸控制
电池容量	耳机电池: 25 mAh x 2 , 充电仓电池: 180mAh
播放时间	音乐播放续航: 约 4 小时, 配合充电仓总续航: 约 20 小时
充电接口	Type-C
产品尺寸	60 x 22 x 45 mm
阻抗	32 Ω
产品重量	48 克
包装清单	耳机 x 2, 充电仓 x 1, 说明书 x 1

④ 注意事项

1. 耳机若未连接且无操作, 5分钟后将自动关机; 耳机重启: 放回充电仓再次取出;
2. 耳机放入充电仓不能识别时(耳机放入充电仓关盖后不能断开蓝牙连接), 请清洁耳机尾部2个金接触点;
3. 产品内置电池, 请勿暴力对待本产品, 远离高温高湿环境;
4. 远离WIFI、路由器、高频发射设备, 因可能影响本机的信号接收, 造成声音的暂停或断连;
5. 请在有效传输距离内使用本产品, 蓝牙设备与耳机之间有实体阻挡(如厚墙体), 将影响使用距离;
6. 使用过程若发现耳机没有声音, 无法开机, 可能是耳机没电(尽量避免低电量使用本产品), 此时需放回充电仓, 充满电后可继续使用;
7. 不使用蓝牙设备期间, 建议关闭耳机减少耗电, 或放回充电仓;
8. 请使用正规厂家认证的充电头、无线充电器;
9. 请在常温干燥环境下使用本产品, 勿投入水或其它液体中;
10. 长时间的充放电后, 电池效能会出现下降;
11. 请勿戳刺或焚烧, 此电池不含汞;
12. 不同人的佩戴适应性不同, 触碰或遇到耳机感应中断, 此时只需触摸即可重新播放(音乐);



5 button function :

1. Long press the "middle button" for 3 seconds to activate the 5 button function, search for FUN 5 Box on your phone, click on pairing and connect.
2. To connect a new phone, you need to first disconnect the Bluetooth connection from the FUN 5 Box on the old phone, search for FUN 5 Box on the new phone, click on pairing and connect.
3. After disconnecting the Bluetooth connection for 1 minute, the 5 button function will automatically turn off to save energy consumption; If you need to use it, please press and hold the "middle button" again for 3 seconds to turn it on. After the function is turned on, it will automatically connect to your phone

Regarding Apple iOS devices:


When using an iPhone/tablet, please note the following settings:

1. IOS version 14.8 or above
2. The auxiliary touch function must be turned on

IOS versions 14.8 and above require settings to use.

The settings are as follows:

Settings -->Accessibility -->Touch -->Assistive Touch -->Turn on, and a dot will appear on the screen.



Note: If normal operation is not possible, please adjust step 6: reduce tracking sensitivity.

After adjusting the tracking sensitivity, it is necessary to turn off the "AssistiveTouch" and then turn it back on.

3.If the above two items are confirmed to be OK but still cannot be used normally, please restart the phone once.

Android and HarmonyOS smartphones can be paired and connected via Bluetooth for use.

Tip: If this product cannot be used due to an iOS system upgrade, it is considered force majeure.

Button	Tiktok playing	Music playing	take photos
	<ul style="list-style-type: none">• Press 1 times PLAY / PAUSE• Press 2 times Tiktok likes it	/	/
	<ul style="list-style-type: none">• Press 1 times Page up• Press 2 times Volume up	<ul style="list-style-type: none">• Press 2 times Volume up	<ul style="list-style-type: none">• Long press 2s When the camera app is opened, take photos

Button	Tiktok playing	Music playing	take photos
	<ul style="list-style-type: none"> ● Press 1 times Page down ● Press 2 times Volume down 	<ul style="list-style-type: none"> ● Press 2 times Volume down 	<ul style="list-style-type: none"> ● Long press 2s When the camera app is opened, take photos
	<ul style="list-style-type: none"> ● Press 1 times Page left 	<ul style="list-style-type: none"> ● Press 2 times Prev song 	/
	<ul style="list-style-type: none"> ● Press 1 times Page right 	<ul style="list-style-type: none"> ● Press 2 times Next song 	/

2 How to use of earphone

1. For the first time pairing with a new device, open your phone's Bluetooth and search for "FUN 5", then click on the icon to pair and connect.
2. Bluetooth automatic connection: After successful pairing, For each subsequent use, Simply turn on the headphones and they will automatically connect.
3. Headphone power on: After opening the charging case cover, the headphones automatically turn on.
4. Headphone shutdown: After placing the headphones in the charging case and closing the cover, the headphones will automatically shut down.



Music: Play/Pause

- Click 2 times

Music: Previous song

- Click 3 times

Call: Answering

- Click 2 times

Call: Ending calls

- Click 2 times

Call: Rejecting calling

- Long press for 2 seconds

Music: Play/Pause

- Click 2 times

Music: Next song

- Click 3 times

Call: Answering

- Click 2 times

Call: Ending calls

- Click 2 times

Call: Rejecting calling

- Long press for 2 seconds

3 Technical specifications

Bluetooth version

5.4

Working distance

≥ 10m

CODEC	SBC, ACC
Profile	A2DP, AVRCP, HFP, HSP
Button	Earphone: Touch control, Charging case: Button
Battery capacity	Earphone battery: 25 mAh x 2, Charging case: 180 mAh
Playing time	Listening time: about 4h, Total endurance: about 20h
Charging type	Type-C
Dimensions	60 x 22 x 45 mm
Impedance	32 Ω
Weight	48 g
Packing list	Earphone x 2, Charging case x 1, Manual x 1,

④ Points for attention

1. If the earphones are not connected and there is no operation, they will automatically shut down after 5 minutes; Restart: Put the earphones into the charging case, close the cover, and then take them out.
2. The product is equipped with a built-in battery. Please do not treat this product with violence and stay away from high temperature and humidity environments.

3. Stay away from WIFI/routers/high-frequency transmitting devices, as it may affect the signal reception of the device, causing sound pauses or disconnections.
4. Please use this product within the effective transmission distance. If there is a physical obstruction (such as a thick wall) between the Bluetooth device and the earphones, it will affect the usage distance.
5. If you find that the earphones have no sound and cannot be turned on during use, it may be because the earphones are out of battery (try to avoid using this product at low battery levels). At this time, connect a charger to charge and fully charge it before continuing to use.
6. When not using Bluetooth devices, it is recommended to turn off the headphones to reduce power consumption.
7. Please use a certified charger from a reputable manufacturer to charge this product.
8. Please use this product in a dry environment at room temperature and do not put it into water or other liquids.
9. After prolonged charging and discharging, the battery efficiency will decrease.
10. Do not poke or burn, this battery does not contain mercury.
11. Different people have different wearing adaptability. When touching or encountering earphone playback interruption, just touch to replay (music).

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.