

AUTOMATIC CHICKEN COOP DOOR

Instructions for use

- Visualized & Programmable & Customized Light Sensitivity•



Introduction of functions:

Displayed as default

CLOCK 		LIGHT INTENSITY	LEVEL ANTI PINCH	
10:00 AM		99%	3	
MODE	OPEN	CLOSE		
 LIGHT	10%	2%		
 TIMER	6:00 AM	06:30 PM		

-  Charging
-  Fully charged
-  Switch modes
-  Light settings
-  Timer settings
-  Open
-  ON/OFF
-  Close

Press  for 3 seconds to switch on/off

Press  to set LIGHT & Press  to set TIMER

Press  for 3 seconds to set Time and Anti Pinch Level.  is plus,  is minus

Option 1: LIGHT (OPEN) and LIGHT (CLOSE)

Option 2: TIMER (OPEN) and TIMER (CLOSE)

Option 3: LIGHT (OPEN) and TIMER (CLOSE)

Option 4: TIMER (OPEN) and LIGHT (CLOSE)

After switching to the new mode, the door will immediately operate according to the new mode.

ANTI-PINCH LEVEL: 1 to 9.

The strength of the door opening and closing.
After 30 seconds, the door will close automatically.

 blinks after powering on. Please press any key on the remote control to match.

 is no longer blinking, then the match is successful.



FCC WARNING:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) this device may not cause harmful interference, and**
- (2) this device must accept any interference received, including interference that may cause undesired operation. Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.**

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.**
- Increase the separation between the equipment and receiver.**
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.**
- Consult the dealer or an experienced radio/TV technician for help. To maintain compliance with FCC's RF Exposure guidelines, This equipment should be installed and operated with minimum 0cm distance between the radiator and your body: Use only the supplied antenna.**

IC Caution:

English:

This device complies with Industry Canada licence-exempt RSS standard(s):

Operation is subject to the following two conditions:

- (1) This device may not cause interference, and**
 - (2) This device must accept any interference, including interference that may cause undesired operation of the device.**
- The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.**

French:

Le présent appareil est conforme aux CNR d'Industrie Canada applicables aux appareils radio exempts de licence.

L'exploitation est autorisée aux deux conditions suivantes:

- (1) l'appareil ne doit pas produire de brouillage, et**
 - (2) l'utilisateur de l'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.**
- Le matériel a été évalué pour répondre aux exigences générales d'exposition aux radiofréquences. Le dispositif peut être utilisé dans des conditions d'exposition portables illimitées.**