

{WV S0S0 a tQYtP

Mobile Phone Connection:

1. After removing the earbuds, turn on Bluetooth on your phone and search for devices. The pairing name will appear as: (SJQ-1).
2. Click to connect. (When removed, the earbuds' blue light flashes. After mutual connection between earbuds, a single earbud's blue light flashes. The light turns off once connected to the phone, with a voice prompt: "Connected").

Touch Controls:

1. Volume Control: Single-click the left earbud to increase volume, right earbud to decrease.
2. Play/Pause: Double-click the left or right earbud.
3. Previous/Next Track: Triple-click the left earbud for previous track, right earbud for next track.
4. Chinese/English Language Switch: Quadruple-click to toggle languages.
5. Voice Assistant: Press and hold for 3 seconds during standby or playback to activate.

Bluetooth Call Functions:

1. Single-click to answer/end a call.
2. Press and hold for 3 seconds to reject a call.

Additional Features:

Earbuds:

1. Single earbud can be used independently.
2. The phone can display the power level of the earbuds.
3. Power on/off prompts with voice notifications.
4. Low battery alerts with voice prompts.

Charging Case:

1. Functions: Flashlight, lyric sync display, timer, stopwatch, find earbuds, audio spatial settings, voice assistant, camera control, caller ID, theme/wallpaper customization, language settings.
2. Long-press the case button to pair earbuds.
3. Automatic UV sterilization when earbuds are stored and the case is closed.

Display Screen Functions:

1. Double-tap the screen to wake, swipe right to unlock.
2. **Camera Control:** Open the phone's camera app and tap the on-screen shutter button to take photos.
3. **Brightness Adjustment:** Use +/- buttons to adjust brightness.
4. **Flashlight Settings:** Tap the flashlight icon, select from 5 colors, swipe right to return.
5. **Alarm:** Set time via screen or manually with the "+" button.
6. **Stopwatch:** Tap to start timing. Tap the clock icon for split times. Swipe up to view details.
7. **Voice Assistant:** Works when earbuds are connected to the phone.
8. **Settings Menu:**
 - ① Screen Wake: Toggle on/off.
 - ② Language: Select preferred language.
 - ③ Themes: Choose and apply wallpapers.
 - ④ Sound: Enable/disable prompts.
 - ⑤ Reboot: Tap ✓ to restart the case.
 - ⑥ Factory Reset: Tap ✓ to reset.

- ⑦ Power Off: Tap ✓ to shut down. Press the reboot button for 3 seconds to turn on.
9. **Equalizer:** Available when connected to a phone. Select music modes for different sound profiles.
 10. **Find Earbuds:** If an earbud is lost, tap "L" (left) or "R" (right) to trigger a beep.
 11. **Menu Layout:** Choose from multiple interface styles.
 12. **Sound Effects:** Can select the sound effect according to your preference.
 13. **Music Mode:** Control playback (skip tracks, pause/play) and view lyrics via the case screen.
 14. **Ambient Sound:** Three modes available.



This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

FCC Radiation Exposure statement

The device has been evaluatec to meel general RF exposure requirement. The device can be used in portable exposure condition without restriction.