



BTQILEYOO T1 使用操作说明书

产品概览



重要提醒：

耳机安装前,请按快速手册指引连接手机,试听音效和音量。

如安装到头盔后,音效和音量有较大的差异,请调整喇叭在头盔内的位置。

开机/关机

双击切换中英文语音播报
(断开蓝牙)



开机提示音

长按3秒开/关机



LED灯长亮



LED灯熄灭

蓝牙配对



蓝牙等待配对状态：
蓝色指示灯快闪

蓝牙配对成功：
蓝色指示灯慢闪

充电模式



(在机器开机情况下,插入充电器充电,机器会自动关机,
此时如需开机,请重新长按开机关机键3秒开机)

充满灯灭

EQ音效功能

EQ音效模式键(默认自然模式)
(短按循环切换六种音效模式)



爵士音效模式	乡村音效模式
自然音效模式	摇滚音效模式
流行音效模式	古典音效模式

电话功能

双击切换手动/自动接听
(未连接蓝牙时)



(来电中)



(来电中)



接听



(来电中)



手动接听“短按”



接听



(来电中)



拒绝接听



(通话中)



结束通话



(去电时)



短按



取消去电

音乐功能



→
(音乐暂停时)



→
(音乐播放时)



→
暂停



→
(音乐播放时)



→
(音乐播放时)



→
长按音量减小



→
(音乐播放时)




→
(音乐播放时)



→
长按音量加大

产品重置



同时按下5秒
音量-键 音量+键

恢复出厂设置

开机在没连接蓝牙情况下,同时长按音量减和音量加键5S,指示灯快闪后,即恢复出厂设置,清除所有配对信息。

电话优先

开机后,机器连接上无线,无论机器处在哪个模式下,当机器来电或者去电,都会优先自动进入电话模式,挂断后恢复相应的模式。

语音助手



→
(再次短按退出语音助手)



唤醒语音助手

物品清单



T1主机*1



喇叭麦克风*1



夹式底座*1



魔术贴安装包*1



Type-C充电线*1



使用说明书*1

注意事项

- 1.请勿将产品投入明火中,避免发生爆炸;
- 2.请勿拆卸产品,避免产品电子器件损坏;
- 3.请勿靠近尖锐器物对产品造成损坏;
- 4.长时间不用,请放置干燥处;
- 5.使用无线设备前,请先将其充满电;
- 6.如果充电时红灯不亮,可能是电压过低。
- 7.为了延长内置聚合物电池的使用寿命,请每月至少为设备充电一次。

TI QUICK INSTRUCTION MANUAL

Product overview




Important Notice:


Before installing the headphones, follow the Quick Manual instructions to connect your phone and listen to the sound and volume. If there is a large difference in sound effect and volume after installing it on the helmet, please adjust the position of the speaker in the helmet.

Power on/off


Double-click the button to switch the Chinese and English voice broadcast (Disconnect Bluetooth)



Pairing




Charging mode




Phone features


Double-click to toggle manual auto answering
(When Bluetooth is not connected)




EQ Sound Mode



Voice assistant



Music features



Product Reset

Restore Factory Settings


Power on the device without connecting Bluetooth, press and hold the volume down and volume up buttons at the same time for 5S, after the indicator light blinks quickly, it will restore the factory settings and clear all the pairing information.



Phone Priority

After power on, the machine is connected to the wireless, no matter which mode the machine is in, when the machine calls or goes to the phone, it will be prioritized to automatically enter the phone mode, and hang up to restore the corresponding mode.

List of items



Notes

1. Please do not put the product into the open fire to avoid explosion.
2. Do not disassemble the product to avoid damage to the electronic devices;
3. Please do not close to sharp objects to cause damage to the product;
4. Please place it in a dry place if it is not used for a long time.
5. Before using the wireless device, please fully charge it first.
6. If the red light does not come on when charging, the voltage may be too low.
7. To extend the life of the built-in polymer battery, please charge the device at least once a month.

Instruction warning

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to correct the interference by one or more of the following measures.

- Reorient or relocate the receiving antenna
- Increase the separation between the equipment and receiver
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment. This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:
(1) this device may not cause harmful interference, and
(2) this device must accept any interference received, including interference that may cause undesired operation.