




# **The NJ27 Smart Watch User Manual**

# Catalogue

<b>Product composition</b>	2	<b>Alarm clock</b>	8
<b>Appearance and press-button</b>	2	<b>Music</b>	9
<b>Product features</b>	2	<b>Weather</b>	9
Preparation before use		<b>Photo</b>	9
<b>Battery charge</b>	2	<b>Find mobile phone</b>	9
operation declaration		<b>Stopwatch</b>	10
<b>Switch key</b>	3	<b>Timer</b>	10
<b>Menu quick key</b>	3	<b>The Voice Assistant</b>	10
<b>Main interface operating</b>		<b>Calculator</b>	10
<b>instructions</b>	3	<b>Subject switching of</b>	10
<b>Dial switch</b>	3	<b>Calendar</b>	10
<b>Paired connection</b>	4	<b>Game</b>	10
major function		frequently asked questions	
<b>Set</b>	4	<b>Not sure if the Bluetooth</b>	
<b>Call menu</b>	7	<b>connection is successful by</b>	11
<b>Notice</b>	7	<b>Multiple connection to Bluetooth</b>	
<b>Activity</b>	7	<b>always can not connect how to do</b>	
<b>Exercise</b>	7		11
<b>Heart rate</b>	7		
<b>Blood pressure</b>	8	<b>Failure to receive a message</b>	
<b>Blood oxygen</b>	8	<b>notification</b>	11
<b>Sleep</b>	8	<b>Warranty instructions for the</b>	
<b>Respiratory training</b>	8	<b>warranty</b>	11

**product formation:** ① Watch body ② wireless charger  
③ Table with ④ package insert

**Appearance and twist:**



**Product features:** •AMOLED-1.27inches, the resolution of 360\*360  
•Full touch screen      •Waterproof level IP67  
•Supports Bluetooth 5    •Battery capacity of 180mAh

**Battery charging:** Using wireless charging mode, support computer USB or mobile phone 5V standard charger, As shown in the figure below:




※Please use the charger that meets the international safety standards, and charge with other chargers Electricity, may appear slow charging, heating and other problems, please use carefully.  
※Magnetic suction charging head contains magnets inside, prohibit long time contact with high temperature, possible Demagnetization will occur.

**Switch key:** Under the shutdown state, long press automatically boot, boot and bright screen state, long press appears shutdown Tip;Press to realize the bright screen/off screen switch.

**Menu shortcut key:** press the screen directly when the screen is off, and press the screen directly Switch;rotate up and down to switch the current screen display style or function menu.

**Main interface operation instructions:** swipe left on the main interface to enter the shortcut function interface, and slide right to enter the common menu boundaryFace, slide into the shortcut Settings menu, slide up to enter the information viewing interface;



**Dial switch:** In the dial interface, rotate up and down to switch the menu shortcut (After connecting to the APP, you can download more and customize the personal dial style on the APP)



**Paired connection:** 1. Use the phone to download the APP **"RWFit"** to the phone and install it, two ways

- ①. IOS/Android mobile phone users: Scan the QR code through your mobile browser, or use WeChat Scan, open the interface, and select those in the interface Play/Android/IOS, and then use the mobile browser Open download;
- ②. Android mobile phone Google Play, and some mobile phones App Store search for **"RWFit"** download, iPhone You can search **"RWFit"** on App Store for download;




※Mobile phone system above android5.0, IOS9.0.

※The permissions during installation require all selective consent, otherwise it may affect the function make use of.


2. Connect Bluetooth, first open **"RWFit"** and open the mobile phone Bluetooth, RWFit APP will have a notification prompt, click "OK". Click "Scan the device" on the page of the APP device, search for the Bluetooth address or Bluetooth name of the device, and click to bind it (pop-up, please click all to allow the box). After successful binding, you can synchronize the mobile phone time and language. (Do not search for system Bluetooth)

※Some Android phones need to turn on the phone's GPS to find the Bluetooth name of the device.

**set up:** Click to enter, you can use: adjust the brightness, password, menu background, don't disturb mode Language switch, standby dial, raise the hand, bright screen, bright screen time, App Download, close Machine, restore the factory, restart, about.



**Adjust the brightness:** adjust the screen brightness;




**Password:** on/off screen save



**Menu background:** Set up the watch background map



**No disturbance mode:** turn on/off the no disturbance function, After opening, the incoming call will not vibrate, and the hand will not light the screen; the time period can be set.



**Language switching:** it can be switched on the device side; after connecting to the mobile APP, the language of the mobile phone can also be automatically synchronized.



**Standby dial:** click to select to open and select the number or pointer out screen dial



**Raise the hand bright screen:** default all day on, you can choose or automatically turn off this function at any time



**Screen time:** can be set for 1-20 seconds Bright screen length.



**App download:** use the mobile phone scan QR code, It will jump to RWFit APP for download




**Shutdown:** Enter can close the watch



**Restore factory:** what software problems, Restoring the factory settings can be resolved; meanwhile, it will be set If all the data are cleared, please click carefully.




**Restart:** Enter to restart the watch



**About:** View the relevant information about the device




**Call menu:** After connecting to the APP, you can call the phone through the watch, answer the call, check the call records and the contacts of the APP synchronization.



**Notification:** After connecting to the APP, you can receive the notification messages from the mobile phone.



**Activity:** Display the activity data.



**Movement:** equipment has a variety of movement mode can be movement:

click the movement icon, enter the movement list interface, click the corresponding movement icon can enter the movement, such as outdoor running, outdoor running, table tennis, walking, cycling, rope skipping, spinning movement mode, after completion, right click on the end button can end movement and save data, can enter the APP side view movement records

※Since the technical way of each movement mode is different, for more accurate counting, please do the corresponding operation



**Heart rate:** wear the wrist to maintain the correct measurement posture, enter the heart rate measurement interface, the device automatically starts, the value will be measured in about 25 seconds; (the heart rate automatic monitoring switch can be turned on

the APP, and the device will regularly collect your heart rate data, and synchronize the data to the APP)



**Blood pressure:** wear the wrist to maintain the correct measurement posture, enter the blood pressure measurement interface, the device automatically starts the measurement, and the value will be measured in about 30 seconds.



**Blood oxygen:** wear the wrist to maintain the correct measurement posture, enter the blood oxygen measurement interface, the device will automatically start the measurement, and the value will be measured in about 25 seconds;



**Sleep:** From 21:00 to 10:00 the next morning, the device will monitor your sleep status, record your sleep duration and quality, help you better adjust your schedule, improve the quality of sleep;


After getting up in the morning, walk a few steps to move the arm, about 3 minutes, let the device know that you get up, the device will quit the sleep monitoring mode, sleep data will be displayed on the device, connected to the APP can synchronize the sleep data of the device to the APP to view.



**Breathing training:** Click to select the appropriate training duration and training intensity, and click the start button for breathing training. Relaxation and relief of pressure;




**Alarm clock:** can set the alarm clock on the device end, to set the alarm clock time, vibration prompt, did not turn off the alarm clock, will be reminded again after 10 minutes. You can also set the alarm clock on the APP end.



**Music:** After connecting the APP, the watch can play the music on the phone, control the music pause and switch up and down music; pull down the main interface to enter the setting shortcut interface, click the audio Bluetooth button, open the media audio switch, connect the phone media audio, and play the phone music from the device end



**Weather:** After connecting to Bluetooth, the watch side can display the weather conditions for the same day and the next 4 days




**Take photos:** when the mobile phone does not lock the screen state, the device enters the Bluetooth to take photos, the mobile phone enters the camera interface, the device point to take photos, the photo exists on the mobile phone terminal;



**Find the mobile phone:** click on the APP terminal to find the device, the device will vibrate; if the device clicks on the mobile phone,


the mobile phone connected to the APP will ring the bell;



**Stopwatch:** click the start button to start the stopwatch, the upper button can be counted.



**Timer:** you can choose the time needed for timing;



**Voice assistant:** Click the voice assistant button to wake up the mobile phone voice assistant.



**counter:**



**Theme switching:** switch between different styles of themes;



## calendar:



## game:



## Frequently asked questions:

1. I wonder if the Bluetooth connection is successful?

A: When the device pulls down the status bar, the Bluetooth icon is white; when the Bluetooth icon is gray, the Bluetooth is not connected.

2. How to connect to Bluetooth for multiple times?

A: Because there is no uniformity in the Bluetooth protocol of each mobile phone brand, sometimes the Bluetooth connection between the mobile phone and the device is unstable. You can turn off the mobile phone Bluetooth and reconnect it again, or try to connect the device again after restoring the factory Settings.

3. What should I do if I fail to receive the message notice?

A: The device can only synchronize the notification function of the mobile phone, such as mobile phone call, QQ, wechat information reminder, etc. The mobile phone enters "Settings" → "Application Management", finds "Rights Management", and opens all of them. Enter the Notification Management again, find the RWFit APP, and open all permissions. Open "RWFit APP", → "Device" . → "Message Push", open the background operation authority, and enter the APP for selecting synchronization information notification, such as QQ, WeChat, etc

Tips: If the wechat computer version is online at the same time, the mobile terminal can not receive the letter notice. Some phones also need to add "RW Fit APP" to the white list to avoid being turned off when the battery is low.

## Warranty instructions

1. When the product is in normal use, if there are product quality problems caused by manufacturing, materials, design and other reasons, the motherboard will be free warranty, battery and charger for half a year from the date of purchase.

2. Free warranty is not provided for faults caused by personal users, as follows:
  - 1) Faults caused by unauthorized disassembly and modification of equipment.
  - 2) Failure caused by accidental falling during use.
  - 3) All artificial damage or due to the fault of a third party, misuse (such as: the main engine water, external force shock crack, scratch damage of peripheral parts, etc.), is not within the scope of the warranty.
3. When requiring free warranty, please must provide the warranty card filled with the purchase date and the purchase seal.

FCC Warning:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Caution: Any changes or modifications to this device not explicitly approved by manufacturer could void your authority to operate this equipment.

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.