


KVERG Massager QS-B User Manual



Thank you for choosing,
Please read the
INSTRUCTIONS FOR USE
carefully.

-1-


Product Description

This product has an elegant appearance and perfect touch. It has super strong vibration and multiple vibration modes. You will get vigorous sexual stimulation. Product safety and environmental protection are part of our design philosophy. We hope to provide the user with an excellent experience. It is destined to be an extraordinary product.

1. Battery: Rechargeable lithium battery
2. Material: High-Grade silicone + ABS
3. Vibration Noise: Around 50dB
4. Vibrating Mode: 8 different speeds and 20 vibration patterns
5. Water resistance
6. Size: 1.5*1.5*6 inch
7. Net Weight: 3.35oz/95g

Instruction

Vibration Speed
Vibration Patterns
Power On/Off




Charging Guide

- ① Put the DC charging plug into the hole in the motor part to charge. Then insert the USB charging plug into the USB port of your computer or other charger

①

-2-

- ② When product is charging, the LED will be flashing.



- ③ When a solid light appears, charging is complete.
Notes: When being charged, the toy must be in shutdown state and cannot be used.

Download and install "KVERG" APP

iOS/Android system: Scan the QR code below with your mobile phone, and follow the prompts to download and install the "KVERG" APP.



Language mode change


- ① Open the KVERG APP and log in with your personal information. Then, navigate to the "Me" page. Locate the "Switch Lang" option.



- ② Select the language mode you need. After making your selection, click "Save Settings" to complete the language

Device Connection

- ① Open the KVERG app and enter the "Control" page.




-3-

- ② On the "Control" page, click the "Add Device" option. The app will then display a page with instructions on what you need to do next.



- ③ Press and hold the power button "①" for 3 seconds, then press and hold the "Vibration Patterns" button "②" again for 3 seconds



- ④ When the word "Connected" is displayed on the connection page, it means that your product has been successfully connected to the app.

- ⑤ Finally, click the "Complete" button to finish the connection process. And you can press the green switch shortcut key to directly turn on our product

Notes:

1. Make sure your product is powered on (the product lights up) and within the effective range of the mobile device's Bluetooth function during the connection process.
2. If the connection fails, please check if the product is in the correct pairing mode and if your mobile device's Bluetooth is enabled. You can also try restarting both the app and the product and then attempt the connection again.


Usage Introduction

- ① After successfully connecting your device, click on the connected product in the app to enter the operation page.

- ② Power Control: On the operation page, the "On/Off" key is used to turn the product on or off. Simply click this key to start or stop the product.

- ③ Level Adjustment: Below the "On/Off" key, you'll find the "+" and "-" keys. These keys are used to adjust the level of our product. Press the "+" key to

increase the level and the "-" key to decrease it according to your needs.



- ④ Mode Selection: There are three curve-shaped buttons beneath the level adjustment keys. Each of these curve buttons corresponds to different sets of modes. Beneath each curve, there are multiple pre-set modes. You can directly select your preferred mode by clicking these buttons. There's no need to manually switch the product's mode via the switches on the product itself multiple times.

Notes:

1. Ensure that the product is powered on before making any adjustments.
2. If you encounter any issues during operation, try restarting the app and the product, then attempt the operation again.

Deleting Device Connection

- ① Navigate to the "Me" page within the KVERG app.



- ② On the "Me" page, locate and click the "Delete Device" option. This action will lead you to the device deletion page.

- ③ On the device deletion page, find and select the device you wish to remove from the app.



- ④ After selecting the appropriate device, click the red "Delete" button located at the bottom of the page. Once clicked, the device will be successfully deleted from the app.

Notes:

1. Deleting a device will remove all associated connection data and settings from the app. If you want to use the device again, you will need to go through the connection process once

more.
2. Ensure that you have correctly identified the device you want to delete before proceeding, as the deletion action is irreversible. If you accidentally delete a device, you can reconnect it following the device connection instructions provided earlier.

Contact Us for Support

If you have any questions regarding our product, please take the time to describe the issue in detail. When reaching out to us, be sure to include your order number, which is 112-xxxxxx - 7293071. This will help us better understand your situation and provide a more efficient solution. You can contact us at any time. Our customer service team is dedicated to addressing your concerns and is happy to assist you in resolving any problems you may face. We value your feedback and are committed to ensuring your satisfaction with our product and service.



Attention

1. Please charge the product properly in a safe place.
2. Water-based lube is suggested as lubricant. Do not apply massage oil or hand cream to the toy surface.
3. Stop using the product, if you feel uncomfortable or you find no longer smooth or has sharp edges.
4. Not recommended to use it below one meter in the water.
5. Please clean it before and after use with warm water and so (boiling water NOT allowed), or sometimes with detergent, disinfectant or 75% alcohol.
6. Keep it in cool and dry place. Avoid direct sunlight.
7. Keep it of children.
8. The product contains lithium battery. Please put in the recycling bin for disposal.



Made in China

-6-

Federal Communications Commission Notice

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement.

The device can be used in portable exposure condition without restriction.