

LED DOG TRAINING COLLAR

DO NOT use the dog training collar before reading the **entire** user manual and watching the video guide via this QR code:




User Manual


Package List




1 Remote Control



2 Receiver Collar




3 Charging Cable



4 Hand Strap



5 User Manual



6 Test Light Tool




7 Long Contact Point




8 Conductive Silicone Cap

Product Description

Remote Control






Screen Content



Product Description

Receiver



Important Safety Information

WARNING

This device is not for aggressive dogs. Do not use this product if your dog is aggressive or if your dog is prone to aggressive behavior. Aggressive dogs can cause severe injury and even death to their owner and others. If you are unsure whether this product is appropriate for your dog, please consult your veterinarian or a certified dogtrainer.

CAUTION

Please read the user manual carefully before using the training collar to avoid injury caused by improper use. The proper fit of the collar is important. A collar worn for too long or made too tight on the pet's neck may cause skin damage ranging from redness to pressure ulcers, which are commonly known as bed sores.

- Avoid leaving the receiver on the dog for more than 12 hours per day.
- When possible, reposition the receiver on your dog's neck every 1-2h.
- Check the fit to prevent excessive pressure; follow the instructions in this manual.
- Never connect a leash to the training collar as it will cause excessive pressure on the contacts.
- When using a separate collar for a leash, don't put pressure on the training collar.
- Wash the dog's neck area and the contacts of the collar weekly with a damp cloth.
- Check the contact area daily for signs of a rash or a sore.
- If a rash or sore is found, discontinue the use of the collar until the skin has healed.
- Don't use an adapter with an output greater than 5V1A to charge.
- Avoid contact with other metals while charging, as it may cause a short circuit.
- To avoid damage to the magnet, please do not attach the magnetic wire to another strong magnet.


CAUTION

- The safety of you and your dog is of utmost importance during on-leash training. Your dog should be on a strong leash, long enough for him/her to attempt to chase an object, but short enough for him/her not to reach a road or other unsafe area. You must also be physically strong enough to restrain your dog when he tries to chase.
- This pet training device is not a toy, please keep away from children.

Operating Guide


1 Charging the Remote and Receiver (~2h Charging Time):

When charging is completed, the green light will appear.
Charger takes approx. two hours respectively.



2 Wearing the Training Collar:

The contact points must have direct contact with the dog's skin on the underside of the neck. Check the tightness of the collar by inserting two fingers snugly between the collar and neck.



3 Strap can be cut to any length without affecting the LED functionality.



4 Turn the Receiver On and Off and manipulating the LED Mode:

Turn ON the Receiver: Hold the  button for 1 seconds.

Turn OFF the Receiver: Hold the  button for 3 seconds.


Button operation: Long press to turn on the power, press twice to turn on the LED flash mode, press again to convert to fast flash mode, press again to convert to steady light, press again to turn off the LED (at this time, the receiver is still turned on); press twice more to turn on the LED flash and enter into the next cycle, and long press the power button to turn off the receiver.



5 Turn Remote ON and OFF:


Security Keypad: Lock or unlock.

Screen Power Switch: On or off.



6 Beep Command:

Press the beep tone button to send a beep tone to the collar and adjust the volume between level 1-3. Press the beep button long to beep continuously, after 30 seconds it will stop beeping automatically and repeat the command when you press again.




7 Vibration Command:

Press the vibration button and the receiver will vibrate once.

Press the vibration adjustment button on the side of the remote to adjust the vibration between level 1-9.

Press the vibrate button long to vibrate continuously for 15 vibrations in 30 seconds. Press again to repeat the command.




8 Electric Shock Sequence and Level Adjustment:

Press the shock mode button for the currently selected level of static stimulation to the collar. Press the mode gear adjustment knob down once and turn the knob clockwise to adjust the shock intensity between level 1-99.


Press the shock boost button for a 20% increase in static stimulation what the currently selected level.

Press the shock button long to continue to shock for 3 cycles before automatically stopping. Press again to repeat the command.




9 LED Light:

Press the LED mode button to switch between constant light/slow flash/fast flash. Press the mode gear adjustment knob down once and turn clockwise to adjust the current strip brightness between level 1-9.




10 Switching Between Channels/Collars:

One remote can connect to up to 4 collars at the same time, allowing you to train 4 dogs at the same time. Press the channel button to switch between channels/collars.



11 Mode Gear Adjustment Knob for Electric Shock / Beep / Vibration / LED Strip:

Press the mode gear adjustment knob once to adjust the gear and press the knob continuously to switch between the electric shock / beep / vibration / LED strip. Press the knob once to enter the gear adjustment mode and rotate 1 grid clockwise to increases by 1 level. Rotate knob 1 grid counterclockwise to decrease the gear by 1 level. The knob can rotate 360 degrees.



Product Features



3 Training Modes (Beep, Vibration and Shock)



3 beep tone levels, 9 vibration levels and 99 static stimulation levels



Lightweight design for more comfort



Receiver collar is IPX8 waterproof, remote is IPX4 waterproof



Remote range is 4,200 feet / 1,280 meters



2-hour rapid charging lithium polymer battery



Eye protection digital display



Supports 4 receiver collars with 1 remote (train 4 dogs at the same time using different settings)




Magnetic charging port

Use of the Test Light Tool

A: Electric shock test

1. Make sure the remote and receiver collar is on.
2. Hold the test light tool contacts to the contact points.
3. Press a shock button on the remote and look for the test light to light up.




B: As a tool to tighten or loosen the contact points

For dogs with shorter coats, use 2pcs shorter contact points.

For dogs with thicker coats, use 2pcs longer contact points.

Install the conductive Silicone onto the contact point to make it softer. It may be better for your dog's skin.



Training Tips


1. Do not use the device on dogs aged below 6-month old, pregnant, easily frightened, aggressive, in heat or in any health conditions.
2. Reward your dog with food or treats as this will usually help to achieve the best training result.
3. Use verbal commands first and supplement with a corrective stimulus only as needed. Be consistent with your verbal commands and use the same words each time. Work with your pet on one behavior at a time to avoid confusion and frustration.
4. Use as little stimulus as possible and only to reinforce verbal commands when necessary. Do not over correct your dog.
5. For example, use the beep sound as warning by pressing the beep button.
The dog will become conditioned to the beep preceding the corrective stimulus and will soon learn to recognize the beep as a warning along with your verbal command.
6. Do not rely on this product solely to train your dog. Some dogs will not respond to this product. We cannot guarantee the effectiveness of this device on your dog.
If your dog shows signs of growling, biting or aggression while using the collar, discontinue use immediately and contact a professional trainer for advice.
7. It is recommended to train one dog at a time in a distraction-free environment, both to increase efficiency and to avoid temptation or distraction from other dogs.

Pairing Instructions

(Note: You can skip this step as the device is paired at the factory.)

Pairing the remote with the receiver:

1. Make sure the receiver is turned off.
2. Press and hold the receiver switch for 6 seconds until the green light blinks rapidly.
3. Press the channel key to control the channel.
4. Press the remote control pairing button to pair the receiver.
5. Pairing is successful: the receiver beeps and the green light stops flashing.



Questions & Answers

Can I train my four dogs at the same time?

Answer: Yes, the remote control can pair with up to four collars for control. However, it is recommended to start by training one dog at a time in a distraction-free environment, both to increase efficiency and to avoid temptation or distraction from other dogs.

My dog has thick long hair will the probes be long enough?

Answer: Yes, the collar come with 2 sets of silicone protective covers and metal probes, a short one suited for short-haired dogs, and a longer one for long-haired dogs. Please make sure the metal probe is in contact with the dog's neck when wearing the collar.


What exactly does the security lock function do?

Answer: The security lock function protects dogs from accidental commands whether you keep the remote in your pocket or backpack.


Troubleshooting

1. My pet is not responding when I press a beep vibration or static button.

- Check if the receiver collar is ON.




- Check if the battery is low on either the remote or receiver collar.



The red light is always on when the battery is low.

c) Test the receiver collar with the test light to confirm if the shock functions normally.



- d) Increase the correction level. Refer to "Find the Best Stimulation Level For Your Dog".
- e) Make sure the receiver collar's contact points are placed snugly against your pet's skin.




2. Fail to pair receiver collar with remote.

Ensure the receiver collar is connected to a power source (charging mode can only be activated while charging). You must hold the channel switch for more than 6 seconds, if not, matching will fail. If the problem persists after attempting the above, please contact us for assistance.


Press and hold 6 seconds




3. Remote/receiver does not response.



- Verify if the battery of the remote is fully charged.



- Verify that the training collar has been paired.



Operating Environment & Maintenance

Do not use the product in the circumstances below:

1. Do not operate the devices in temperatures of 104°F and above, as doing so will decrease the performance of the batteries.
2. Do not use the set in places with strong electromagnetic interference.
This will greatly compromise the performance of the product.
3. Avoid dropping the devices on a hard surface or inflicting excessive force on them.
4. Avoid using the devices in an environment flooded with corrosive chemicals as this may lead to color degrading, deforming or cracking of the exterior of the devices.

Maintenance:

1. When not in use, please wipe clean both the remote and receiver collar with a damp soft cloth using mild detergent. Turn off the remote, lock the keypad and store the set in a cool, dry place. Do not use hard brushes which may scratch the surface of the device.

Note: Do not submerge the receiver collar into water for a long period of time.

2. Before charging the receiver, if there is water stain on the charging port, please dry it before charging.
3. If the Remote falls into the water, pick it up immediately and turn off the power. Dry it with a cloth as much as you can and let it out to dry. It should resume functioning normally once the moisture has dried.

Additional Information About the Product

1. Do not immerse the receiver collar in water for a long period of time. The receiver collar is IPX8 waterproof and can be placed in 1 meter of water and soaked for 30 minutes without having the functionality be affected.
2. Please use the remote control and the receiver from the complete set.
Do not attempt to use other products to pair with the receiver.
3. If you want to test the product, please use professional testing apparatus.
Do not test with hands to avoid accidental injury.
4. If you find water at the charging port, please wipe it dry before charging.
5. Beware of interference from the environment, it can cause the product not to work

properly. For example, places with high voltage facilities, communication towers, thunderstorms, large buildings, and strong electromagnetic interference may impact the functionality of the product.

6. The included collar is a basic accessory and is not necessarily suitable for all types of dog breeds. Any collar not wider than 24mm and not thicker than 5mm, made of soft material, can be a replacement for the current collar.

Your Responsibility To Your Dog

1. The receiver collar is not a regular collar and is not recommended to put on a leash to walk your dog. Doing so may hurt your dog when pulling due to protruding electrodes on the receiver collar
2. Do not put the collar on for over 12 hours as it may cause rashes or discomfort to your dog's skin.
3. Do not allow children, or anyone who has not been trained on how to use this training collar to handle this training kit.
4. Static stimulation is not a pleasant experience for any dog and punishment is a harsh way to train a dog. Encourage wanted behavior with verbal commands, food and treats first.

Reference Weight for Dogs

Large Dog: height above 24 inches, weight above 88 lbs

Medium Dog: height 16-24 inches, weight 24.2-66 lbs

Small Dog: height 10-16 inches, weight 8.8-22 lbs

Mini Dog: height under 10 inches, weight under 8.8 lbs

Terms of Use & Limitation of Liability

1. Use of this product means you accept all the terms and conditions.
2. This product is a professional dog training device. You are not recommended using this product if your dog is less than 8 lbs in weight. If you're not sure whether the product is suitable for your pet dog, please consult a professional dog trainer or contact us for assistance.
3. This product is a professional dog training device and should not be used for

other purposes. Please do not violate local laws by using this product.

4. We bear no liability for any direct or indirect losses caused by use or misuse of this product; all risks in using this product shall be borne by the user.

5. Please contact the dealer for parts warranty, returns or exchanges.

We provide only technical support.

6. We reserve the right to alter the terms, conditions, and notices of this product offered.

FCC Statement

This device complies with part 15 of the FCC Rules.

Operation is subject to the following two conditions:

1. This device may not cause harmful interference.
2. This device must accept any interference received, including interference that may cause undesired operation.

Warning: Changes or modifications not expressly approved, by the party responsible for compliance could void the user's authority to operate the equipment.

NOTE: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a specific installation. If interference does occur to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- a) Increase the separation between the equipment and the receiver.
- b) Connect the equipment to an outlet on a circuit different from that to which the receiver is connected.
- c) Consult customer care, the dealer, or an experienced radio / TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 0cm between the radiator and your body.

Product Specification

Model	DC-001
Receiver's Casing	IPX8
Remote's Casing	IPX4
Remote / Receiver's Battery	300mAh
Remote / Receiver's Charging Time	2 Hours
Remote / Receiver's Standby Time	Remote 45 days Receiver 35 days
Remote to Receiver's Signal Range Distance	4,200FT / 1,280m
Max Supported Quantity	4 Receivers

Reference Size for Different Dogs

Size	Neck(in)	Chest Measurement(in)	Back Length(in)
Mini	7.8-8.6	9.8-11.8	7.5
Small	7.8-9.5	11.4-14.2	9
Medium	9-11	13.7-16.5	11
Large	>=10.6	>=16.2	>=12.2

Warranty and repair information

1-Year Warranty

The original purchaser for this unit is provided with 1-YEAR WARRANTY.

The warranty begins from the date of purchase. For the first year, coverage is for both parts and labor on warranty repair services, but the return postage is for the buyer's account. Accessories such as chargers, straps, and batteries are covered for the first year only. When the warranty expires, customers will need to purchase parts and repairs at their own expense.

Won't Qualify for 1-Year Warranty

1. We do not offer a warranty for products that have been bought secondhand or as resold products.
2. Manual damage or loss is not covered by the warranty.
3. Any water damage on the water resistant transmitters and the water resistant receivers of our product series will not be covered.
4. The warranty is void if the unit has been altered or an unauthorized person who attempts to repair work has damaged the unit.
5. Replacement of batteries is not recommended during the warranty period.

If the customer chooses to replace the batteries, any damage to the unit during the change-out by the owner will make the warranty void.