



SMART WATCH

User manual



Smart watch

Quikc Start Guide




-Use the watch for the first time, to ensure that the watch power is sufficient, if low electricity can not be turned on, please give the watch full charge, charging for about 2 hours.
-Make sure the charging needle on the charging cable is properly installed on the back of the smartwatch, then plug the other end of the subscriber cable into the power supply.

Function

Dial
Press and hold on the watch face screen to replace the watch face.



Pedometer
The watch automatically records your daily activities. Click the touch screen to see more detailed data.



Heart rate/Blood oxygen
Enter the heart rate/oxygen interface, the watch will automatically test your heart rate/oxygen, slide right to exit.

Sports details
To pause or end the motion, swipe the screen right to pause or end the current motion.
* Note: If the exercise is short, the data will not be saved.

Sleep monitoring
When the watch generates sleep data, the interface displays the sleep data at this time.
When sleep is over, the watch will display your total sleep, light sleep and deep sleep time in the sleep interface. After syncing with the APP, you can view a more detailed sleep report.



Weather
After connecting 'app' and enabling the location permission, the weather will be automatically pushed to the watch.



Stopwatch
Locate the stopwatch in the menu screen. Click to enter the timing page, click Start to start the timing, swipe right to exit.



Sedentary reminder
On this page, turn on or off the sedentary reminder feature that you set up in the application.



Take pictures remotely
The device can be used as a remote control for camera functions on mobile phones.
In the app, click 'Take Photo' and your watch will display a camera icon. Tap to capture your photo.



Music control
Click the music function icon to enter the music playback interface. You can control the music playback of the phone in the music interface. You can select the last/next song or play/pause a song.



About offline map updates
Use the USB charging cable to connect the watch to the computer. When the watch pops up the connection method, select the option below to complete the connection and update the map.



Warranty policy

Thank you for purchasing the product. When you experience any non-human damage performance failure during the use of the product, you can enjoy the "guaranteed repair, return and replacement" (referred to as "three guarantees") service of Busee. promise.

In order to protect your rights and interests, please keep the three-guarantee certificate and the issued invoice properly after purchasing the Busee product. The validity period of the three guarantees of the product will be calculated from the date you receive the product (hereinafter referred to as "receipt"), and the validity period of the three guarantees of the product is 12 months.

Three Guarantees Service Content

1. Within 7 days from the date of receipt, to ensure that the received goods are in good condition, the product packaging and accessories are complete, and there is no performance failure caused by artificial damage, the payment for the goods can be refunded at one time according to the invoice price, or the products of the same model and specification can be replaced, or free maintenance.

2. From the 8th day to the 15th day from the date of receipt, if the product has a performance failure that is not damaged by human beings, the product of the same model and specification can be replaced. Product replacement is the responsibility of the seller.

3. Within the validity period of the Three Guarantees, if the product still cannot be used normally after two product replacements, and confirmed by the Busee noise test, you can choose to repair or replace the same model and the same specification with the valid replacement record provided by the seller in the Three Guarantees. product. Product replacement is the responsibility of the seller.

How to Get Three Guarantees Service

In order to ensure your legitimate rights and interests, you need to go to the seller of to enjoy the three-guarantee service.

When you request the Three Guarantees service, you need to provide:

1. The original of the purchased product;
2. The original invoice when purchasing the product or the proof of purchase record from the seller;
3. A valid three-guarantee certificate.

Circumstances that are not covered by the warranty service

The product exceeds the validity period of three packs;
There is no Three Guarantees certificate and valid invoice, and it is impossible to prove that the purchased products are within the validity period of the Three Guarantees;

Warranty Card

Product name and model:	Serial number:
username:	Purchase date:
contact number:	Delivery date:
Address (including zip code):	Invoice number:


Sales unit name:
Sales unit address (including zip code):
Sales unit telephone:

*The above information is filled by the seller

Install the "APP" app on your phone.
Scan the QR code below to install the APP and install the APP
With any browser can scan code directly download.



-Turn on Bluetooth on your smartphone, then open the APP app on your phone.
-Click 'Connect Device' on the APP device interface, the search interface will appear. Select the corresponding Bluetooth name of the watch to connect. (You can directly click Unbind on the device page to unbind.)



Sports

Press the function 'Sport' to enter multi-sport mode. The smartwatch features 14 exercise modes: walking, running, indoor running, climbing, cycling, swimming, badminton, stairs, ellipse, paddling, jumping rope, golf, other exercises and yoga. Choose one of them and do some exercises. The smartwatch will record your movement data. When you finish the exercise, swipe right to stop the exercise and save the exercise data. If you have connected your smartwatch to the APP via Bluetooth, you can view your exercise data in the app.



GPS Sport

Only walking, running, climbing and cycling have GPS function. When the selected sport has GPS function, the positioning will take about 1 minute. If the positioning is unsuccessful, please go to an open place. When the location is successful, the motion trajectory can be viewed on the APP.



If you do not wait for positioning, you can also directly enter the motion. If positioning is unsuccessful, no trajectory is generated.

Information

After the APP is connected to enable message push, unread messages will be displayed in the message interface. Swipe up and down to view the information list, and click the information list to enter the information details.



Alarm clock

Click on the "Alarm" screen to add an alarm clock. Click on the corresponding alarm clock to enter the page for editing the alarm clock. When the alarm clock is set, the watch will vibrate.



Altitude barometer

Click the barometric altitude function icon to enter the interface. Altitude can be calibrated and current barometric pressure can be viewed.



Compass

Click the compass function icon to enter the interface, and calibrate the compass according to the figure-of-eight direction.



Find phone

Once the app is connected, click the find phone feature in the dropdown or settings and the phone will ring/vibrate.




Set up

In the "Settings" interface, you can set a variety of Settings for the watch, including finding phone, screen brightness, screen duration, language, reset, shutdown, and system.



System

Select the "System" function to view the Bluetooth name and firmware version information of the watch.



The warranty certificate does not match the product model identification or the warranty certificate has been altered;
Damage caused by not using, maintaining and maintaining according to the requirements of the "Instruction Manual", or using non-original accessories
Unauthorized repair, alteration, misuse, bump, drop, crush, liquid entry: corrosion;
Teating, altering or illegible product labels, seals and serial numbers (SN):
Damage caused by force majeure such as flood, fire, lightning strike;
Defects due to normal wear or normal aging of the product;
Busee products not sold in mainland China.
Paid service guarantee
If the product does not meet the warranty conditions and needs to be charged, We will calculate the appropriate maintenance fee according to the cost of parts and labor, and propose a suitable maintenance quotation to you, after obtaining your consent and paying the fee for your product. Provide maintenance services.
This policy is formulated in strict accordance with the Consumer Protection Law and the Product Quality Law of the People's Republic of China.
About waterproofing instructions
The water resistance of this product is not permanent and may diminish over time. It can be used when washing hands, raining, and swimming in shallow waters, but it does not support hot showers, diving, diving, surfing, and other use scenarios. Hands should not be in contact with seawater, acidic and alkaline solutions, chemical reagents and other liquids with high rot touch that may cause the watch to not work properly, if accidentally touched, please rise with plenty of water and wipe it clean with a clean rag.
The following conditions may affect the water resistance of the watch and should be avoided when using it:
1. The watch is dropped, collided, or otherwise subjected to a crash.
2. Clean the watch with detergents such as soapy water, body soap, detergent, lotion, etc.
Residual chemicals can irritate the skin and decay devices.
3. Take hot baths, steam rooms and other high-temperature and high-humidity scenes.

SMART WATCH

User manual

The pictures are for reference only. Products (including but not limited to color, size, screen display, etc.) shall prevail in kind
* This product is not a medical device, and the data provided are for reference only and shall not be used as a basis for diagnosis and treatment

FCC Statement

This device complies with Part 15 of the FCC rules. Operation is subject to the following two conditions: 1) this device may not cause harmful interference, and 2) this device must accept any interference received, including interference that may cause undesired operation.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance could void the user’s authority to operate the equipment.

Radiation Exposure Statement

This device complies with RF radiation exposure limits set forth for an uncontrolled environment. The device can be used in portable exposure condition without restriction.