

正面

封面

折叠线

USER MANUAL

V1.2

Important safety notes!

Installation
To achieve the best effect, please use the projector in a darker room or draw the curtain. Be careful when use the projector. Any dropping or bump may lead to damaged parts, blurred images or display improperly.

Power Source
Please use the power cord to avoid excess use bending. Damaged power cord may cause electric shock and fire. Please be careful when using the machine. Falling or striking may damage components, blur images or display abnormally.

Cleaning
Unplug the power cord. Clean the cabinet regularly with a damp cloth. Neutral detergent can be used. Do not use strong detergents or solvents (such as alcohol, benzene, etc.) as they may damage the cabinet. Do not use water, gasoline or lens paper. Be careful not to scratch the lens. Please regularly use a soft brush to clean the air inlet filter, vent and loudspeaker of the machine, otherwise the vent will be blocked by dust accumulation, causing overheating of the machine, which will lead to machine failure.

High Temperature Attention
Do not disassemble the projector casually since there may be a risk of electric shock, which affects normal maintenance. Liquid or heavy objects should not be allowed to put on the machine.

Suitable for areas below 2000m altitude.

Please use in an ambient temperature of 0-35 degrees Celsius.

Projection Distance

Projection size
Referring to the data in the following table, place the projector at the required distance from the projection screen according to the preset image size.
During installation, place the projector on a solid, smooth countertop or install on the ceiling. The area around the fuselage should be well ventilated. Do not cover or block the vents. Within 30cm distance of the vents, there should be no any shielding objects.

Projection size(inch)	Projection distance(meter)
60	1.66
80	2.17
100	2.69

Note: The projection sizes and distance is for your reference.

Installation methods
Depending on your use environment and requirements, the projector can be hung forward with a special hanger on the ceiling or placed on a smooth desktop and projected forward onto the screen. Of course, you can also use other ways to install the projector according to the following legend:

Bracket lifting positive projection

Bracket lifting back projection

Trolley placement positive projector

Trolley placement back projector

* In the projection setting interface, select "Projection" to switch

1. When using the lifting method, the projector should not rise above the upper edge of the screen, otherwise, it will affect the effect of the image. Please refer to the image size table.
2. Be sure to install the projector on the symmetrical axis line on the left and right sides of the screen to avoid causing trapezoidal distortion on the left and right sides of the image

Keystone
When the projector raises / lowers or side projection, the image will deform and distortion. You can select "SETTING" and PROJECTOR, then enter the correction in "4-point Trapezoid" or "4-side Trapezoid".

Power on
Connect the power cord to the projector and press the OK button for 3 seconds; or press the remote control at the front / rear infrared window and press the "↑" power button to start the device. Shutdown: Press the power button for 3 seconds, then from the remote control at the front / rear infrared window of the body, press "C" to select the shutdown after shutdown.

Image correction
Focus regulation
The image will automatically focus after power on or moving the projector. If the automatic focus does not reach the clearest state of the image, please press the remote control "F+" and "T-" keys to fine-tune until the image is adjusted to the clearest effect. You can enter SETTING to close Autofocus function, select PROJECTOR, select Auto Focus off.

Interface operation instructions

How to go to the Source selection
Go to the home page, press the source selection button " " on the remote control, select the required signal source channel, such as "HDMI", "USB", and press the OK key of the remote control to enter the corresponding signal source state.

How to connect WiFi
Enter the main interface, SETTING, ENTWORK-WiFi find the network you want to connect to and press Confirm. Enter the password via the virtual keyboard and confirm the connection.

How to play U-disk
Connect the USB with projector, press on the remote, Enter the USB page, select Picture, Audio, Video, Store.

How to mirror with your iPhone
1. The projector and your iPhone connect with same WiFi.
2. Projector: Enter to the APPS to find "AirScreen" or "Whale TV".
3. iPhone: Find mirroring function on your iPhone and connect with the projector.

How to use Bluetooth
Enter the SETTING page, select "BLUETOOTH", Search and select the Bluetooth that you need to pair with.

How to Miracast with your Android Phone
1. Projector page select "Miracast"
2. Android phone: Enter the Setting page to select mirroring function, connect with the projector.

Dust cleaning
1. Clean the dust filter once every three months and replace the dust filter once every six months.
2. Cleaning steps: shut off the projector, disconnect the power cord, remove the dust net from the side of the fuse age, blow the dust with the air duct, remove the dust and then install it into the projector. If the dust net is removed, a new dust filter must be replaced.

Warning Statement
This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note:
This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to other devices. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to other devices, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:
-Reorient or relocate the receiving antenna.
-Increase the separation between the equipment and receiver.
-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
-Consult the dealer or an experienced radio/TV technician for help.

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator & your body.

封底

V1.2 料号: 3.03.02.0290

成品尺寸: 90*145 mm, 157g铜版纸彩印 折叠页