

Appendix D

Duty Cycle

Condition	Mode	Frequency (MHz)	Antenna	Duty Cycle (%)	Correction Factor (dB)	1/T (kHz)
NVNT	a	5180	Ant1	97.55	0.11	0.72
NVNT	a	5200	Ant1	97.55	0.11	0.72
NVNT	a	5240	Ant1	97.55	0.11	0.72
NVNT	a	5260	Ant1	97.55	0.11	0.72
NVNT	a	5300	Ant1	97.55	0.11	0.72
NVNT	a	5320	Ant1	97.55	0.11	0.72
NVNT	a	5745	Ant1	97.55	0.11	0.72
NVNT	a	5785	Ant1	97.55	0.11	0.72
NVNT	a	5825	Ant1	97.55	0.11	0.72
NVNT	n20	5180	Ant1	100	0	0
NVNT	n20	5200	Ant1	100	0	0
NVNT	n20	5240	Ant1	100	0	0
NVNT	n20	5260	Ant1	100	0	0
NVNT	n20	5300	Ant1	100	0	0
NVNT	n20	5320	Ant1	100	0	0
NVNT	n20	5745	Ant1	100	0	0
NVNT	n20	5785	Ant1	100	0	0
NVNT	n20	5825	Ant1	100	0	0
NVNT	n40	5190	Ant1	100	0	0
NVNT	n40	5230	Ant1	100	0	0
NVNT	n40	5270	Ant1	100	0	0
NVNT	n40	5310	Ant1	100	0	0
NVNT	n40	5755	Ant1	100	0	0
NVNT	n40	5795	Ant1	100	0	0
NVNT	ac20	5180	Ant1	100	0	0
NVNT	ac20	5200	Ant1	100	0	0
NVNT	ac20	5240	Ant1	100	0	0
NVNT	ac20	5260	Ant1	100	0	0
NVNT	ac20	5300	Ant1	100	0	0
NVNT	ac20	5320	Ant1	100	0	0
NVNT	ac20	5745	Ant1	100	0	0
NVNT	ac20	5785	Ant1	100	0	0
NVNT	ac20	5825	Ant1	100	0	0
NVNT	ac40	5190	Ant1	100	0	0
NVNT	ac40	5230	Ant1	100	0	0
NVNT	ac40	5270	Ant1	100	0	0




Report No.: AB25060001FW03


NVNT	ac40	5310	Ant1	100	0	0
NVNT	ac40	5755	Ant1	100	0	0
NVNT	ac40	5795	Ant1	100	0	0
NVNT	ac80	5210	Ant1	100	0	0
NVNT	ac80	5290	Ant1	100	0	0
NVNT	ac80	5775	Ant1	100	0	0

Test Graphs


Duty Cycle NVNT a 5180MHz Ant1




Duty Cycle NVNT a 5200MHz Ant1





Duty Cycle NVNT a 5240MHz Ant1




Duty Cycle NVNT a 5260MHz Ant1








Duty Cycle NVNT a 5745MHz Ant1




Duty Cycle NVNT a 5785MHz Ant1







Duty Cycle NVNT n20 5200MHz Ant1




Duty Cycle NVNT n20 5240MHz Ant1




Duty Cycle NVNT n20 5260MHz Ant1




Duty Cycle NVNT n20 5300MHz Ant1




Duty Cycle NVNT n20 5320MHz Ant1




Duty Cycle NVNT n20 5745MHz Ant1




Duty Cycle NVNT n20 5785MHz Ant1




Duty Cycle NVNT n20 5825MHz Ant1




Duty Cycle NVNT n40 5190MHz Ant1




Duty Cycle NVNT n40 5230MHz Ant1




Duty Cycle NVNT n40 5270MHz Ant1




Duty Cycle NVNT n40 5310MHz Ant1




Duty Cycle NVNT n40 5755MHz Ant1




Duty Cycle NVNT n40 5795MHz Ant1




Duty Cycle NVNT ac20 5180MHz Ant1




Duty Cycle NVNT ac20 5200MHz Ant1




Duty Cycle NVNT ac20 5240MHz Ant1



Duty Cycle NVNT ac20 5260MHz Ant1



Duty Cycle NVNT ac20 5300MHz Ant1



Duty Cycle NVNT ac20 5320MHz Ant1

