

# Antenna Instructions

1. The NFC PSSD antenna layout is on the PCB board. The coil size is 2.5\*3 cm and the operating frequency is 13.56 MHz. The antenna position is as shown in the figure.  
Antenna Type: PCB embedded antenna

