


# Mobile Smart Screen

ZPHD-0320



User Manual

# Foreword

Thank you for choosing a mobile smart screen!

Before starting up, please carefully read this user manual to understand the usage methods and precautions of this machine.

## warn

- . Only use the power adapter accessories provided by the original factory.
- . The gaps and openings on the machine are used for ventilation and heat dissipation. Do not block or cover these gaps and openings.
- . Do not use or store this machine in dusty, humid, or high-temperature environments.
- . When the machine malfunctions, please do not disassemble and repair it yourself. You need to contact the original factory or dealer for assistance.
- . Avoid stepping on power cords or power adapters to prevent potential hazards such as electrical leakage caused by line loss. If the wires of the power adapter are damaged, Do not continue to use, otherwise there may be danger.
- . Please unplug the power cord during thunderstorms or when the device is not in use for a long time.
- . When using, please do not place the machine on the edge of a table or in a place that is easily accessible to children, to avoid the machine being dropped or injuring children.
- . During transportation, do not forcefully squeeze the display screen, and do not use sharp objects or hard objects to damage the display screen, in order to avoid damage to the display screen.
- . cleaner to clean the machine. Do not use any type of solvent, such as alcohol or gasolineOil, otherwise it may damage the surface treatment layer.
- . Children must be made aware of the dangers of climbing this product, as falling or tipping it can cause serious personal injury. . Do not place the product Placed in an unstable or tilted position.
- . Be sure to promptly organize the cables connected to the product to avoid tripping, pulling, or grabbing.



Do not use under humid and high humidity conditions

Attention: If consumers use a power adapter for charging, they should purchase a matching device to obtain CCC certification  
A power adapter that meets the standard requirements.

# Mobile Smart Screen


- It is different from traditional screens or televisions, with a screen size ranging from 22 to 32 inches. It has a touch screen, a built-in stand, and support for multiple angle adjustments. The bottom comes with a lightweight design. The sound wheel is movable for use, with a built-in battery of a certain capacity for endurance, and has a unique feature. A home device with a built-in system kernel and intelligent operating system that supports third-party app installation.
- Large screen touch: Provides a more immersive experience for watching movies, learning, fitness, and more.
- Flexible movement: The bottom comes with a pulley, making it easy to move to any corner of the home.
- Adjustable angle: The bracket supports multiple angle adjustments and height adjustments, meeting various needs. The usage requirements in the same scenario.
- Strong battery life: Built in large capacity battery, can be used for a long time without a charger.
- Intelligent system: equipped with Android intelligent operating system, supporting third-party app installation, rich and diverse functions.

## Product specifications


Central Processing Unit	MTK 6769 octa core 2 * A75 up to 2.0GHz + 6*A55 up to 1.8Ghz
RAM	8GB
Hard disk	128G
Operating System	Android
Screen size	31.5 inches
Resolution	1080x1920 HD
Contact point	10 point capacitive touch screen
Proportion	16: 9
Wi-Fi	support
Multiple contact points	10
Brightness	250–300cd/m <sup>2</sup>
Color gamut	100%SRGB
Refresh rate	60HZ
Microphone input	Support external microphone input
USB interface	Supports full functionality (excluding charging function)
Camera	Built in MIPI camera
Button	Power
Gravity Sensor	Support 90 °
Speaker	Bulidin 8Ω 5W*2
Microphone	Noise reduction MIC
Power supply	12V
The power adapter	12V 6A
Bench	Removable base, 360 ° rotation adjustment
Operation temperature	0~50°C

## Touch Screen


It adopts tempered glass G+G capacitor full HD ten point capacitive touch LCD screen, which is sturdy Hard and wear-resistant, corrosion-resistant, high transparency, smooth handling, high reliability To maintain screen touch sensitivity, please keep the screen clean



## Attachment



Monitor/Stand



Tray



Screw



User's manual



The power adapter



CR-V



Remote Control/Flying Mouse



If any of the above issues are missing, please contact the product distributor.

Note: Please refer to the actual configuration for specific attachments. Please keep all packaging materials for future removal.

# Product installation

When installing and assembling the product, please make sure to tighten the fixing screws. The bracket. Falling brackets may cause product damage or personal injury.

- The product has a certain weight, and at least two people should cooperate in assembling it when unpacking and installing.
- Do not use foreign objects (oil, grease, etc.). On the screws during product assembly.
- After the product is installed, do not remove the cable bracket and screws.
- For daily use, please ensure that the product moves upright. If the product is excessively tilted, there is a risk of flipping, leading to product failure or personal injury.



1. Align the column with the circular base at the hole position, add screws and use a hex wrench to install, and prepare 4 fixing screws, Insert the power supply line on the base into the DC hole on the column to complete the installation.


2. Fix on the pillar  
Built in hexagonal screw reverse time  
Loosen the needle direction  
3-4 turns, Unlock up and down free hovering Location.

3. Remove and install the tray  
Under the pillar, cooperate  
Hexagonal wrench and 2 self  
tapping screws Screw fixation.

4. Insert the charger into the circle On the base, press and hold again Self resetting on the back of the monitor Simply turn on and off the device

# Battery level description

This product bracket contains a built-in rechargeable battery that can be used for a period of time without connecting to other power sources, resulting in low battery consumption. After that, you can connect a charger to charge the battery. When the charger is inserted into the DC port of the bracket, the power indicator light will flash, and it will follow the battery. The battery level increases until it is fully charged, and the power indicator light shows 4 bars of constant brightness, indicating that the battery is fully charged. Remove the charger.



4 grid lights always on, fully charged

After unplugging the charger, the battery supplies power to the bracket

Flashing below 5% battery level

Insert charger to charge battery and power bracket

## ⚠ Attention:

While charging, use the product for about 6 hours to fully charge it. Turn off the product and charge it for about 6 hours to fully charge it. After fully charging, the device has a battery life of about 6-8 hours.

The increase in product usage time results in a proportional decrease in battery life and endurance.

To extend the battery life, it is recommended to charge the battery after a period of use. After the battery is fully charged, unplug the charger and do not let the battery remain fully charged. The battery should not be charged in extreme environments.

※ The standard usage time in the manual is based on the laboratory test data of our company, and the actual time may vary depending on the usage

⚠ Attention: It is strictly prohibited for users to replace or disassemble battery packs without authorization, in order to avoid improper installation or use of batteries of the wrong model. Causing the risk of complete machine explosion. If necessary, please contact official customer service to handle related issues.

Matters needing attention:

1. Before using this product, please carefully read all instructions.
2. When cleaning the mobile screen, please unplug the power cord and turn off the power switch. Do not use liquid detergent or spray cleaner. Wipe the screen with a soft damp cloth. If it is still not clean, please use LCD screen cleaner.
3. Do not use accessories that are not recommended by the manufacturer, as it may cause danger.
4. When unplugging the power cable from the power interface or adapter, please hold down the power plug. Do not directly pull or unplug the power cord.
5. This mobile monitor can only be operated using the type of power supply indicated on its nameplate. If you have any questions about the type of power supply you are using, please consult your mobile monitor dealer or local power supply bureau.
6. Due to high voltage or other hazards when opening or moving the chassis, please do not repair it yourself. Please contact us for assistance. Qualified maintenance personnel conduct comprehensive repairs.
7. When the following situations occur, first unplug the power plug or battery from the bottom battery assembly from the socket Source plug and contact qualified maintenance personnel for repair:
  - a. The power cord or plug is damaged or worn.
  - b. The monitor has detached or the casing is damaged.
  - c. When there is a clear abnormality displayed, it indicates the need for repair.
8. Please place the monitor in a well ventilated environment, away from strong light, high temperature, or high humidity.
9. Please store the display screen at room temperature between 0 ° C and 40 ° C. Exceeding this range may affect

Normal use.

Safety reminder! (Stability hazard)

The monitor may fall, causing serious personal injury. Many injuries, especially among children, can be avoided by taking simple preventive measures, such as:

- Please use the cabinet, rack, or installation method recommended by the monitor manufacturer.
- Please use a safe support option

Furniture supporting the monitor.

-Please educate children about the dangers of climbing up furniture to enter the monitor or its control device.

-Be sure to prevent wires and cables connected to the monitor from tripping, pulling down, or getting tangled.

-Do not place the monitor in an unstable or tilted position.

-If you want to place the monitor on higher furniture such as cabinets or bookshelves, you must ensure that

Place the base and monitor on a suitable support point.

-Do not place the monitor on cloth or other objects between the monitor and the accompanying furniture.

-Do not place toys, remote controls, or other objects that may entice children to climb onto the monitor or place it on furniture

Product. In order to preserve and relocate existing displays, the same preventive measures as mentioned above should be taken.

# Declaration of Toxic and Harmful Substances in Electronic Information Products

Part number	Toxic and harmful substances or elements					
	lead (Pb)	mercury (Hg)	Pickaxe (Cd)	Six Price Inscription (Cr <sup>6+</sup> )	Duo Mo Lian Stupid (PBB)	DuoMo Diphenic Acid (PBDE)
Attachment	×	○	○	○	○	○
Plastic shell	○	○	○	○	○	○
Metal structural components	○	○	○	○	○	○
PCB motherboard	○	○	○	○	○	○
LCD display screen	○	○	○	○	○	○
Polymer button battery	○	○	○	○	○	○
Touch screen	○	○	○	○	○	○
Speaker	○	○	○	○	○	○
package	○	○	○	○	○	○

○: Indicates that the content of the toxic and harmful substance in all homogeneous materials of the component is within GB/T26572-Limit requirements stipulated in 2011 Within

×: indicates that the content of the toxic and harmful substance in at least one homogeneous material of the component exceeds The limit requirements specified in GB/T26572-2011.

Note: 1. This product is produced according to environmentally friendly design and lead-free production process, and complies with EU ROHS requirements.

2. The toxic and harmful substances marked with "x" in the table are mainly due to the current level of technology This product contains rechargeable button batteries and is strictly prohibited from being disassembled Impact, squeeze, or throw into fire. Serious swelling has occurred, please do not continue to use. Do not place in high temperature environments.

3. Circuit board components: including printed circuit boards and their components, electronic components, solder joints, etc;

4. Depending on the product model, the product you purchased may not contain all of the above components.

The product has an environmentally friendly usage period of 10 years and is labeled as shown in the left picture,

Some replaceable components may have a different environmentally friendly usage period affixed to their body. This environmental protection usage period only applies to products working under normal usage conditions.



## **FCC Statement**

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

To assure continued compliance, any changes or modifications not expressly approved by the party.

Responsible for compliance could void the user's authority to operate this equipment. (Example- use only shielded interface cables when connecting to computer or peripheral devices).

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

- (1) This device may not cause harmful interference, and
- (2) This device must accept any interference received, including interference that may cause undesired operation.

### **FCC Radiation Exposure Statement:**

The equipment complies with FCC Radiation exposure limits set forth for uncontrolled environment. This equipment should be installed and operated with minimum distance 20cm between the radiator and your body.

# Warranty policy



## Warranty Statement

1. One year free warranty from the date of purchase or as agreed in the contract.
2. The following situations are not within the scope of free warranty services:
  - Malfunctions and damages caused by human or natural disasters.
  - Due to not following the instructions and precautions stated in the user manual Malfunctions caused by work. Malfunctions caused by users dismantling the device themselves.
3. The scope of responsibility of this warranty card is limited to the repair of the product and does not assume any other responsibilities What responsibility.
4. If there are any unclear areas regarding the maintenance and guarantee of this machine after the warranty period, please Call our company's customer service hotline for consultation.

# Warranty Card

Customer		Phone	
Address			
Model			
Serial No			
Purchasing date			

\* Please keep this card properly as proof of maintenance