





<h1>Smart glasses</h1> <h2>智能眼镜</h2>	<p> Switch on/off</p> <p> Right touch Left touch</p> <p>Power on: After wearing glasses, the induction will automatically turn on. Power off: Press and hold the left/right touch key for 5 seconds (Note: If it doesn't turn on when you wear it, please take it off and wear it again. Wearing Please keep the lens legs dry and tidy when wearing, if sweat will affect the switching off effect. If the power is lower than 3.1V, it will turn off automatically.)</p> <p> 开关机</p> <p> 右键触摸 左键触摸</p> <p>开机:眼镜佩戴后感应自动开机 关机:长按左/右触摸键5秒 (注:如佩戴上不开机,请摘下重新佩戴。佩戴时镜腿请保持干燥整洁,如有汗水会影响开关机效果,电量低于3.1V自动关机)</p>	<p> Pairing of both arms</p> <p></p> <p>After the smart glasses are turned on, open the Bluetooth of your cell phone, search for the device name G06 and connect it (Note: Smart glasses charging automatically shut down; Android devices Bluetooth search when the individual icons are not the same, please refer to the model number)</p>	<p> Pairing</p> <p></p> <p></p>	<p> Phone</p> <p> Right touch Left touch</p> <p>Incoming call answer/hang up: touch key (left or right) 1 click Rejecting a call: Long press the touch key (left or right) for 1.5 seconds (Note: In music mode, priority is given to incoming calls. Adjustable during a call Volume Press and hold the right slide bar to slide forward to adjust the volume up, slide backward to adjust the volume down. Adjust volume by sliding the right side slider forward to adjust loud volume, and backward to adjust small volume)</p> <p> 电话</p> <p> 右键触摸 左键触摸</p> <p>来电接听/挂断:触摸键(左或右)点击1下 拒接电话:长按触摸键(左或右)1.5秒 (注:音乐模式下,优先进入来电。通话中可调节音量按住右侧滑动条往前滑可调大音量,往后滑可调小音量)</p>	<p> Music</p> <p> Right touch Left touch</p> <p>Music pause/play: touch key (left or right) 1 click Music switching: Double-click the left touch key to switch to the previous song Double-tap the right touch key to switch to the next song</p> <p> 音乐</p> <p> 右键触摸 左键触摸</p> <p>音乐暂停/播放:触摸键(左或右)点击1下 音乐切换:双击左触摸键,切换上一曲 双击右触摸键,切换下一曲</p>	<p> Remote control Take photos</p> <p> Right touch Left touch</p> <p>Remote control photo taking: first open the camera in the cell phone and Press and hold the right touch button for 2 seconds to take a picture remotely. (Note: in non-call/non-music state)</p>	<p> Wake up voice assistant</p> <p> Right touch Left touch</p> <p>Wake up the voice assistant: Long press the left touch key for 2 seconds</p>	<p> Volume</p> <p> Right touch Left touch</p> <p>Volume down: press and hold the right slider back Volume up: press and hold the right slider and slide forward. (Note: Music volume can also be adjusted on the phone)</p>	<p> Charge</p> <p></p> <p>Magnetic charging: Orange light is always on when charging, and when fully charged The green light will be on for 1 minute and then turn off. (Note: the glasses will be turned off automatically when charging)</p> <p> 右键触摸 左键触摸</p> <p>音量滑动键</p> <p>音量减少:按住右侧滑动条往后滑 音量增加:按住右侧滑动条往前滑 (注:音乐音量大小也可以在手机上调节)</p> <p></p> <p>磁吸式充电:充电时显示橙灯常亮,充满后绿灯常亮1分钟后熄灭 (注:充电状态下,眼镜会自动关机)</p>
--------------------------------------	--	---	--	---	--	--	---	--	---

FCC Caution:

This device complies with part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Any Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

Note: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

-Reorient or relocate the receiving antenna.

-Increase the separation between the equipment and receiver.

-Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.

-Consult the dealer or an experienced radio/TV technician for help.

The device has been evaluated to meet general RF exposure requirement. The device can be used in portable exposure condition without restriction.