SMART EYEWEAR Quick guide | 快速指南 秒开机,提示音"开机"。 左右镜腿自动配对,双腿蓝灯闪烁,配对完成灯熄

SMART EYEWEAR

使用说明 Instructions

立体声功能的蓝牙眼镜,操作简便,便于携带。 镜腿颜色 黑色 镜片材质 AC/PC/ 偏光 / 其它 * 采用中科蓝讯芯片,兼容主流品牌手机和平板电脑等蓝牙设备。

首先对您使用本公司的产品表示感谢!在使用之前请先阅读此 说明书,正确使用此产品。为了更好的服务,本用户手册的内容可 能变更。因为产品的性能和功能而发生的变更,将不做另行通知。

包装清单 ①智能音频眼镜/ ③质感上下盖纸盒/ ⑤产品使用说明书√

SZ-2503 EYEWEAR 开放式定向音频智能眼镜,本产品是具有



磁吸充电口

出音孔

●支持 Ap 音频解码技术,达到 CD 级音质。

左右双喇叭,定向播放,真正的立体声音效。

操作说明

④磁吸式充电线√

眼镜开机后,会出现单侧镜腿红蓝灯交替快闪。打开要连接的设备蓝牙(如手

四击双腿触摸区域,依次听到"开机"提示音,左右耳"咚"提示音,此时进入

点击"配对",并提示"蓝牙已连接",蓝牙连接成功

搜索模式,单腿蓝灯红灯交替闪烁

① 音乐播放 / 暂停: 单击任意腿触摸区域

② 音乐切换上一首 / 下一首: 双击左 / 右腿触摸区域

③ 音乐增减音量: 长按左/右腿触摸区域 1 秒后松开

① 拔下充电器自动开机。或在关机状态,同时长按左右镜腿下方按键 3 秒开 ② 插上充电器自动关机。或在开机状态,长按任意镜腿下方按键 3 秒关机; 或蓝

断开 3 分钟后自动关机。提示音"关机"。

② 挂断电话,双击任意腿触摸区域

① 五击任意腿触摸区域切换中英文提示音

①使用本产品前请仔细阅读说明书, 并保留本说明书。

在使用本设备前, 请先阅读所有安全信息以确保正确和安全

重要安全信息

请保持设备干燥。

•使用未经本制造商认可的电源,充电器或电池,可能引发火灾、

擦拭时,眼镜布要朝着同一个方向擦拭,不能来回擦拭,也不能

⑤当电池温度超出 -10°C—60°C 的时候,产品将会停止工作。 ③ 拒接来电,双击任意腿触摸区域

① 低电报警,每隔 2 分钟提示一次"低电量";

三击任意褪触摸区域启动语音助手,例如 Siri 、小艺、小爱同学等。

请使用本制造商认可且与此型号设备配套的配件 ●建议在温度 0°C-35°C 范围内使用本设备,当环境温度过高或过

低时,可能会引起 设备故障。 ●该设备使用不可拆卸的内置电池,请勿自行更换电池,以免损坏

拔掉充电器,连续充电时间请勿超过 12 小时。

①请勿以任何理由拆除或维修改装本产品,否则可能会导致起火 电子击穿甚至彻底损坏本产品。

②请勿将设备置于温度过低或过高 (0°C 以下或 45°C 以上)环境下 ③请勿将产品接触液体弄湿,或浸泡在液体里。

④不能将眼镜放在阳光下长时间暴晒,否则易变形、老化、折断。

③ 充电时,指示灯常亮红;充电完成,红灯熄灭。

· 请勿将充电线磁吸端靠近金属物体,防止磁吸金属物体后引

的短路危险。 ⑥请勿用酒精擦拭本产品,以免发生化学反应。

②首次使用,请先将本产品充满电。

③如果产品长期 (超过两周) 不充电,使用前请对其充电。

④较脏的镜片不要直接擦拭,应先镜片打湿,再用眼镜布拭干。

量使用绒面且吸水性较强眼镜布轻轻抹拭干净,注意不要太用力

•若充电完毕,请断开充电器与本设备的连接,并从电源插座上

•电池禁止拆卸,撞击,挤压或投入火中,若出现严重膨胀,请

•若设备或其他任何部件不能正常工作,请勿自行维修任何产品。

连接其他设备时,请参考用户手册的连接方法,不要随意连接

请勿置于高温环境中,电池过热可能会引起爆炸。

品的环境,严禁使用设备。

身伤害,起火和充电器损坏。

若要在个人医疗设备附近使用此设备,请咨询医师和设备制造 Bluetooth

•请遵守有关驾车时使用此设备的所有安全警告和规定

为避免听力受损,请勿长时间使用高音量。

请遵循相关法律法规,不要在以下环境使用。

•请勿在医院手术室、急诊室、深切治疗部等场所使用此设置

为避免干扰医疗仪器工作,使用此设备时请远离心脏起搏器、助

听器、植入耳蜗等医用设备,请保持此设备和起搏器之间超过 15

•请遵守在任何环境里明确禁止使用的相关法律规定。

•雷雨天气时,为避免雷击事故,请勿在室外使用。

•请勿在浴室等高湿度的地方使用充电器,否则会导致触电,人

Search for Bluetooth devices

SMART EYEWEAR

Quick guide

hearing "Power on" indicates the eyewear is working

Turn on bluetooth on your smart phone or other sma

device, search" SZ-2503" and connect it, when hearing

SZ-2503 connected ①

"connected" ,the set-up is done.

Bluetooth

Thank you for using our products. Please read the manua before use. The manual might change because of hardware

Statement

Product characteristics

Temple color Black

Bluetooth

SZ-2503 eyewear with open directional audio, this product in a bluetooth glasses with stereo super mini speakers, easy

...... • microphone

Temple material TR/Rubber Tip Battery capacity 100mAh for each temple

Speakers Dual stereo speakers *Actions AB5656C, compatible with mainstream brands o

mobile phones, tablets and other bluetooth devices

1) Automatically turns on when connected to the charger. the off state, press and hold the lower button on either side of

1. Power On/Off

2. Bluetooth Pairing

give you real stereo sound effect.

•Support AptX audio decoding technology, achieve CD-level

Left and right speakers, audio directed all around ye

speakers

touch control area

the temple for 3 seconds to turn on: Prompt tone: "Power on 2)Automatically turns off when unplugged from the charger.

in the on state, press and hold the lower button on either sid

1. Auto Pairing (Power On) When powered on, one arm flashes red and

blue. Enable Bluetooth on your phone or computer, search for SZ-2503

and connect.On success, both arms say "Connected" and flash blue

2. Tap the touch areas on both legs four times. After the "power on

tone and "dong" tones in both ears, the device enters search mode,

with blue and red lights on one leg flashing alternately.

of the temple for 3 seconds to turn off; or automatically po

off 3 minutes after Bluetooth disconnection. Prompt ton

7)Reject a call:Double-tap any temple touch area

3.How to operate

voice assistant (e.g., Siri, etc.).

8) Switch between Chinese and English: tap the touch area five time

2)when device is run out of power, it will prompt " Power off"

3)When charging, the indicator light is always red; when fully

1)Play/pause music: Tap the left / right temple touch area

2)Previous/next song: Double-tap either temple touch ar

left / right temple touch area for 1 second, then release

5)Answer a call: Tap any temple touch area onc

6)End a call: Double-tap any temple touch area.

3)Increase/decrease the volume of sound: Press and hold the

4)Voice control: Triple-tap any temple touch area to activate the

4.About charging

charged, the red light goes out.

complete damage to the product. 2)Do not put the equipment in an environment with too lov or too high temperature(below 0 °C or above 45°C) 3)Do not put the product under water or other liquid or

Noticement

product and keep this manual well.

1)Please read the user manual carefully before using this

2)For the first time use, please fully charge the product.

3) If the product is not charged for a long time (more th

4)Use cleaning cloth inside the pouch to clear up the di

5)when the battery temperature exceeds -10 °C- 60°C , the

1)Do not unassemble and repair the product for any reason

otherwise it might cause fire, electronic breakdown or even

two weeks), please charge it fully before use.

lens. Other cloth might damage your lens.

Matters needing attention

protuct will automatically shut down.

Important safety information

tion to ensure correct use and safe use.

it may cause equipment failure.

overheating may cause explosion.

•Please keep theequipment dry.

to the equipment that does not match.

replace the battery to avoid damage.

•Before using the device, please read all safety informa

• Use of power supply, chargers or batteries not certified

by the manufacturer may cause fir and explosion or oth

Please use the accessories approved by the manufact

Please use the equipment within the temperature range

of 0-35°C. When the temperature is too high or too low,

The device use a non-removable built-in bettery, do not

After fully charged, disconnect the charger from the

device and unplug the charger from the power socket. Do

. Do not disassemble battery, or bump, squeeze or put the

battery into the fire. If serious expansion occurs, please do

Do not put in a high temperature environment, battery

Do not repair the product by yourself when it cannot work

When connecting other devices, please refer to the user

manual for the connection method, do not arbitrarily con-r

er and compatible with this type of equipment.

1)Low battery alarm: you will hear indicating tone "Battery Leve

4)Do not expose your device in the sun for long time, other-

wise they will be easily deformed, aged and broken. 5)Do not put charger's magnetic suction close to any metal.

6)Do not wipe the device with alcohol to avoid chemical reaction

high humidity, or it will lead to electric shock, personal injury, fire and charger damage. Please comply with the relevant laws that clearly prohibit

Warning

Please follow the relevant laws and regulation

For example, gas stations, oil warehouses, chemical ware-

house and other places where inflammable and explosive

oil and gas or chemicals are stored are prohibited to use

Do not use the equipment in the operating room, emer

In order to avoid interference the medical devices, please

keep the device away from pacemaker. Please keep at least

• If need to use this device near a personal medical device

•Please comply with all safety warnings and regulations

•Do not use outdoors in thunderstorm, to avoid lightning

genry room, intensive care department, etc.

15 centimeters distance from the pacemaker.

regarding the use of this device while driving

consult a physician and device seller.

do not use in the mentioned environment be

Consult the dealer or an experienced radio/TV technician for help

ncrease the separation between the equipment and receive

ference will not occur in a particular installation. If this equipment does cause