

## W570 Qibla Watch

### User Guide

1

#### MAIN FEATURES

Prayer times and Qibla direction for all cities around the world.

Digital compass and automatic Qibla direction.

Full-Quran audio player.

Tasbih counter.

Receive and answer the phone calls and receive social media notifications (through Bluetooth).

Weather forecast (updated through the app).

Schedule (updated through the app).

Heart rate.

Different sport modes

5 Alarms.

IP68 Water resistant (waterproof).

2

#### APPEARANCE INTRODUCTION



1. Touch Screen
2. Digital Crown
3. Microphone
4. Side Button
5. Speaker
6. Charging Contact
7. Heart rate sensor

#### 1: Digital Crown:

1. On the main screen, rotate the crown to change face.
2. On the main screen, short press the crown button to enter the menu.
3. On the menu, rotate the crown to go through the menu functions.
4. In any function, short press the crown button to go back to the previous step.

#### 2: Side Button:

1. On the main screen, short press to wake up or turn off the screen.
2. In any function, short press to go back to the previous step.
3. Long press to power off/power on the watch.

3

#### TURN ON/OFF/RESET THE SMART WATCH

##### Turn on

- Long press the side button to start the watch in the shutdown state.

When starting with ultra-low power, connect the charger to charge the watch for 5 minutes before starting.

##### Turn off

- Long press the side button to turn off the watch.
- Or, on the main screen, swipe down and select: Setting > Power > Power off.
- Or, after the ultra-low battery vibration reminder, the watch will automatically shut down.

##### Reset

- On the main screen, swipe down and select: Setting > Reset.
- Or, in the app, in the watch setting, choose Restore.

After restoring the factory settings, the watch will restart automatically, and all user data of the watch will be cleared after the restart.

4

#### CONNECT THE WATCH TO THE PHONE

After you bind the smart watch to the app, the real time, date, prayer times, and the Qibla direction on the watch will automatically be updated. Health and sports data from your watch will sync automatically with the app.

To bind the Qibla smart watch, follow the steps below:


1. Turn on the smart watch.
2. Turn on the Bluetooth on your phone.
3. In the app, click on the 'Add Device' section, then select the product 'Smart Watch'.
- 4.1. On the watch's main screen, swipe down and click on the QR code, then in the app click on the 'Scan code to add device' and scan the QR code to bind.
- 4.2. Or: In the app, click on 'Manually add device' and select the watch you want to bind according to its MAC address. [You can get the MAC address from your smart watch: Settings > About > MAC Address.]
5. Enable notification permissions so that you can receive and answer phone calls through your smart watch; also, your message notifications (Facebook, SMS, WhatsApp, etc.) can be received and viewed on your smart watch, and to do so: In the App > Smart Watch > Settings > Notifications.

Note:

We advise you to connect the smart watch to the app from time to time to make sure that the Qibla direction and prayer times are up to date.

5

#### WATCH OPERATING INSTRUCTIONS:



**Swipe left:**

Tasbih counter, Quran audio player, Qibla direction.

**Swipe right:**

Weather forecast.

**Swipe up:**

Notifications: Display the messages and notifications of Facebook, SMS, WhatsApp, etc., received from your phone.

**Swipe down:**




Settings



Notes:




When entering any function on the menu, swipe right to go back and leave this function.

7

On the main screen, short press the crown button to enter the menu:


 The Qibla app icon is a circular dark blue button. At the top, the word 'Qibla' is written in white. In the center, there is a white icon of a Kaaba with a green arrow pointing towards it. To the left of the Kaaba is a white alarm clock icon, and to the right is a white circular arrow icon. At the bottom, there is a row of seven small white dots, with the first dot on the left being slightly larger and colored green.	<p>Qibla: Find the accurate Qibla direction according to your location. This feature is updated through the app.</p>
 The Tasbih app icon is a circular dark blue button. At the top, the word 'Tasbih' is written in white. In the center, there is a white icon of a Tasbeeh (string of beads) with a green arrow pointing to the right. To the left of the beads is a white Kaaba icon, and to the right is a white icon of an open book. At the bottom, there is a row of seven small white dots, with the first dot on the left being slightly larger and colored green.	<p>Tasbih: You can make the Tasbih by touching the screen; the watch will vibrate every time it reaches 33 or one of its multiples. After leaving the function and going back to it, you can continue counting the Tasbih or reset the counter.</p>
 The Quran app icon is a circular dark blue button. At the top, the word 'Quran' is written in white. In the center, there is a white icon of an open book with a green arrow pointing to the right. To the left of the book is a white circular arrow icon, and to the right is a white icon of a person running. At the bottom, there is a row of seven small white dots, with the third dot from the left being slightly larger and colored green.	<p>Quran: Full-Quran audio player with a clear and clean sound; listen to the Quran with the beautiful recitation of Saad al-Ghamdi.</p>
 The Schedule app icon is a circular dark blue button. At the top, the word 'Schedule' is written in white. In the center, there is a white icon of a calendar with a green arrow pointing to the right. To the left of the calendar is a white icon of a cloud with rain, and to the right is a white alarm clock icon. At the bottom, there is a row of seven small white dots, with the fourth dot from the left being slightly larger and colored green.	<p>Schedule: Show your schedule, This feature is updated through the app.</p>

 <p>A circular watch face with a black background. At the top, the word 'Weather' is written in white. Below it, there are three icons: a heart rate monitor, a sun partially covered by a cloud with raindrops, and a calendar icon. At the bottom, there is a row of seven small dots, with the fourth dot from the left being highlighted in blue.</p>	<p>Weather: Display weather information, This feature is updated through the app.</p>
 <p>A circular watch face with a black background. At the top, the words 'Heart Rate' are written in white. Below it, there are three icons: a person running, a heart with a pulse line, and a cloud with raindrops. At the bottom, there is a row of seven small dots, with the fourth dot from the left being highlighted in blue.</p>	<p>Heart rate: 24/7 monitor your heart rate. The watch will automatically monitor your heart rate throughout the day as long as you are wearing it. It takes measurements every 5 minutes.</p> <p>You can also click on 'Measure' and get the results anytime you want; please note that the measurement takes around 15s to 20s to capture a reading.</p>
 <p>A circular watch face with a black background. At the top, the word 'Sports' is written in white. Below it, there are three icons: a crossed sword, a person running, and a heart rate monitor. At the bottom, there is a row of seven small dots, with the fourth dot from the left being highlighted in blue.</p>	<p>Sports: Six different sports modes, including running, walking, cycle, basketball, Soccer, and yoga. Once a sport mode has been selected, your smart watch will record data such as time, heart rate, calories burnt, steps, and distance walked.</p>
 <p>A circular watch face with a black background. It displays two notification cards. The top card has a blue icon of a house with a signal wave and the text 'Asr' and '30 min remaining'. The bottom card has a red icon of a telephone handset and the text 'Missed Call' and 'Mom'.</p>	<p>Notifications: Display the messages and notifications and reminder for the remaining time of the Fajr time.</p>

	<p>Alarm and Fajr Alarm: Five different alarms you can set separately, and choose the days of the week you want the alarm to repeat on (Fri, Sat, Sun, etc.). There are five alarms, and it can be used to follow the Iqamah time.</p>
	<p>Settings: Adjust the watch settings:</p> <ul style="list-style-type: none"><li>- Brightness: Adjust your watch brightness and choose from three levels: low, medium, and high, to suit your needs.</li><li>- Auto lock: Set duration for automatic screen lock (10, 20, 30, or 60 seconds).</li><li>- Raise Wake: Lift your wrist to wake the screen and view info quickly.</li><li>- Power: Switch off your smart watch.</li><li>- Battery: Check the battery level.</li><li>- Restore: Reset your watch to factory settings; this will erase all the data.</li><li>- About: View watch details, such as device name, MAC address, software version, build info and certification info</li></ul>
	<p>E-label: swipe up at the main watch face→find “i” icon(about)→check compliance information</p> <p>View watch details, such as device name, MAC address, software version, build info and certification info</p>

### CHARGING INSTRUCTIONS

The smart watch set includes a charging dock. To charge your watch, position the watch's charging contact with the metal pins on the dock, then plug the USB connector of the dock into a USB power adapter or a computer's USB port, and you will see the charging screen on your watch. If your watch has a very low battery, it will take approximately 5 minutes of charging before the charging status is visible on the display.



#### Notes:

- Use the special charging dock included in the box to charge. and make sure the charging contact of the watch are clean and dry before charging.

### PRECAUTIONS

- The product's measurements are intended for informational purposes only. The data should not be relied upon for medical diagnosis or treatment.
- If you use a power adapter for charging, you should use a power adapter that meets the requirements of the corresponding safety standards to avoid bursting or fire caused by fake power adapters.
- Do not wear the watch while taking a bath or a sauna. Exposure to steam, soap, or hot spring minerals can degrade the watch's water resistance.
- If the watch gets stained or contains any foreign materials, wipe it with a moistened, soft-bristle toothbrush.
- Clean the rubber watchband with clean water and dry thoroughly.

### SPECIFICATIONS

- Product Name: Qibla Smart Watch
- Body Size: 43\*13
- Screen Size: 1.39"
- Screen Resolution: 360x360
- Body Material: ABS + Stainless Steel
- Strap Material: Silicone Rubber
- Battery Capacity: 250 mAh
- Bluetooth Version: V5.0
- Waterproof Rating: IP68
- Support System: Android 7.0 and later or iOS 12.0 and later

### FCC Statement

#### FCC compliance statement

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

#### FCC Radiation Exposure statement

This equipment complies with FCC radiation exposure limits set forth for an uncontrolled environment. This transmitter must not be co-located or operating in conjunction with any other antenna or transmitter.