## Product Introduction

This product adopts the innovative circular appearance design, Integrated 3D display technology, easy to use Interactive for personalized audio and video playback

Built-in high-efficiency battery and energy storage system, Supporting multiple media formats to meet Daily demand, entertainment demand.

Product specification

Type: round HD display

Resolution: 480x480 pixels

Display effect:3D movie and television

Battery capacity: 800mAh
Service time: 2-4 hours
Depending on what is being played)
Memory capacity: 100MB
Supporting video and picture storage)

Size: 2.76*2.76*2.76inch

Material housing

ABS plastic (environmental protection and wear-resistant)+transparent hemisphere

• Dial key control

Middle: press for 3 seconds to turn on/off
Press to pause/play
Left dial: short toggle to switch the previous track, Long toggle to lower volume.
Right dial: short toggle to switch to the next track, Long toggle to increase volume.

• USB cable (type-c) charging

Avoid long-term storage in high temperature and wet environment.
When cleaning, please wipe the screen and shell with a soft cloth
Do not use corrosive solvents.
After-sales Service: If you have any questions, please contact the customer service

⚠ Matters needing attention

WIFI showed white disconnection, upload failed, mobile phone re-connected. Green when mobile phone is connected to Wi-Fi, pictures/videos can be uploaded

Remarks: WIFI hot spot will be automatically turned on after each startup, If no mobile phone is connected to the hot spot, the hot spot will be automatically turned off after 1 minutes, The name of the hot spot is not displayed To turn on the hot spot again, restart the crystal ball

⚠ Warning! / 🔥 Source of a fire!

Safety precautions:

Do not charge the product without supervision!

In case of improper operation, the crystal ball and battery will have serious fire risk
Please read the complete operation manual carefully before using the crystal ball
The crystal ball may emit heat during use
Operate the crystal ball only in a ventilated place and keep away from inflammables
Failure to comply with safety procedures may result in property damage or personal injury

Electronic ball

WiFi version

User Manual v2.0


FCC ID: 2BRWM-EB282-2

Material Change Guidelines

Select the picture/video file you like to save in the album

Scan QR code and download ihanfo software

iPhone will jump to App store, Then download the software

Android scans the QR code and opens it with a browser,Then download the software

**(1) Open the crystal ball,
Mobile phone connection WIFI: MEB-XXXX
(suffix is random four-bit character)
Password: 12345678**

Unable to access the Internet after the mobile phone is connected to the product hot spot, So the phone will pop up the following confirmation interface and click the red box button

Android System Interface

Apple System Interface

(2) Open the installed software and click "A Single picture is displayde" to enter the page of Figure 2 , Click "Camera" to take picture directly and upload it to crystal ball for display, Click "Gallery" to select the picture upload display in the mobile phone album

History: select the file to be deleted and click the Delete button under the icon , You can delete the selected file

(3) Click "Video Display" and "Gallery" to select the video in the mobile phone album, Click "Upload" to transmit to the crystal ball (the video duration shall not exceed 300s and free editing duration is available)

(4) Click the " ⚙ " setting icon to set the crystal ball

Switch mode
Image/video mode switching

Loop mode
Single file loop play, sequential play, random play

When clicking " Show Battery Level", The screen will display the battery indicator

Brightness adjustment
Free "+" "-"

Clear Files: Delete all files

Language selection: Chinese/English