


Projector





※Quick Installation Guide※


Safety notice

- 1.Please read use manual careful before you use projector.
- 2.To ensure stable power supply, please use national standard power cable standard power cord with grounding.
- 3.Regularly clean projector vents, or dust may cause cooling malfunction.
- 4.When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain.
- 5.Regularly clean projector vents, or dust may cause cooling malfunction. To avoid clog of the projector vent, please do not cover with cloth, carpet and other materials.
- 6.To avoid electric please keep the projector away from moisture. No such apparatus as vase or cup should be put around the projector.
- 7.If this projector is not used for a long time, Please cut off the power supply.
- 8.Please handle with care during daily use. Use the originally foam or other anti-shock material to protect projector if you need transport this projector.
- 9.In order to prolong the service life of the projector and protect vision, it is recommended to take a rest after 3-4 hours of use.
10. If found projector defected, do not attempt to repair it by yourself. Please contact with your distributor or factory directly.
11. It's a normal phenomenon that there may come out hot air or odor from the vent during using.

Structure description




Remote Component and Functions



Switch in the Applications

Click on "My apps" to view installed programs, click program icon to switch between applications.

Move to "My Apps", click OK to enter.
All Apps' can be clearly distinguished from the icons.




Settings

Enter to setup Networking, Language, Other Setting, Projection, Audio, Date And Time


Networking Setting

Settings - Networking Setting - WIFI setting, WIFI "ON", select objective WIFI ID and input password to connect internet.




Language Setting

Settings - Language Setting, enter to setup language and select input method.




Other Setting

Setting - Other Setting, enter to get Application setting, Factory Reset Setting.



Projection Setting

Setting - Projector setting, enter to setup projection mode, keystone correction and Zoom in and out of the image.




Audio Setting

Setting - Audio setting, enter to adjust volume.

Date And Time Setting


Setting - Date And Time Setting, enter to setup timezone, timeformat, dateformat, date and time.




Miracast

Ensure that Android devices(phone,pad,ect)are in the same local wireless LAN with these devices

Operations on Devices:
Home Screen -> My Apps -> Miracast -> Open miracast service -> Turn on the phone mirroring -> Connection




Operations Android phone devices



AirPin

Ensure that devices(iphone,pad,ect)are in the same local wireless LAN with these devices

Operations on Devices:
Home Screen -> My Apps -> AirPin -> Open AirPin service -> Turn on the phone mirroring -> Connection



Safety instructions

- Please pay attention to important information related to the operation and maintenance of the projector. You should read this information carefully to avoid problems. Following safety instructions will increase the life of projector.
- Please consult the qualified personnel for installation and repair services, and do not use damaged wires, accessories and other peripherals.
- Projector should be kept away from flammable, explosive, strong electromagnetic interference (large radar stations, power stations, substations), etc. Strong ambient light (avoid direct sunlight), etc.
- Do not cover projector vents.
- Please use the original power adapter.
- Keep adequate ventilation and make sure vents are not covered to avoid projector overheating
- When projector is working, please do not look directly into the lens, the strong light will flash your eyes and cause slight pain.
- Do not bend or drag the power cord.
- Do not put power cord under projector or any heavy objects.
- Do not cover other soft materials on power cord.
- Do not heat the power cord.
- Avoid touching power adaptor with wet hands.

Disclaim

This manual is general instructions, The pictures and functions in this manual should subject to the actual product. Our company is devoting to improve product performance, we reserve the right to modify product functions and interface described in this manual without notice.

Please keep your device properly. We are not responsible for any loss caused by wrong operation of software/hardware or repairing or any other reasons. We are not responsible for any loss of any third party claims.

This manual has been carefully checked by professional engineer, please understand for any inevitable omissions.



Attention:

Please do not look directly into the lens when projecting to prevent the strong light doing harm to your eyes.

YMS-X100-AZ-950S

FCC Warning

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions:

(1) This device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

NOTE 1: This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

NOTE 2: Any changes or modifications to this unit not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

RF Exposure Statement

To maintain compliance with FCC'S RF Exposure guidelines, This equipment should be installed and operated with minimum 20cm between the radiator and your body. This device and its antenna(s) must not be co-located or operation in conjunction with any other antenna or transmitter.