



PB100 User Manual

Keys Specification

1.1 Keys specification

General keypad definitions:

Left soft key	Generally indicates Confirmation
Right soft key	Generally to delete or clear a letter or number.
Navigation key	Generally to move the cursor.
#key	Switch between different input methods.
*key	show the Symbols interface.
Call key	Generally to call the number.
End key	Generally to end a call.
1 key	,?1
2 key	ABC,abc,2
3 key	DEF, def.3
4 key	GHI, ghi, 4
5 key	JKL, jkl, 5
6 key	MNO, mno, 6
7 key	PQSR, pqsr, 7
8 key	TUV, tuv, 8
9 key	WXYZ, wxyz, 9
0 key	0, space


2 User Guide


2.1 Installing/ Removing the battery/SIM card.

Installation Notice

Before you install or remove the battery and the SIM card, please make sure to turn off the mobile phone.


1) Removing the battery.






Step2:

- Remove the back cover.
- Remove the battery from the battery slot properly.





2) Inserting/Removing the SIM card.



Step3:

- Insert/Remove the SIM card.

Slide the SIM down to remove
 Slide the SIM up to Insert



Step4:

- Insert the battery
- Place the Back cover on.

2.2 Charging the battery

- Plug the charger into the electrical outlet.
- Plug the charger connector into the mobile phone
- The Battery indicator icon starts to flash until charging is finished.
- When charging is complete, disconnect the charger connector from the mobile phone and unplug the charger from electrical outlet.

2.3 Flashlight

This mobile phone has a flashlight function. In idle state, long press the middle key to turn on the flashlight and when the flashlight is on and you are in the Idle state, press the middle key to turn off the flashlight.

2.4 Power On or Off

Make sure the battery is already inserted:

- Power on/off: Long Press the End key to Switch on/off the mobile phone.

3 Call Functions

3.1 Making a Call

- On idle state, input the phone number directly
- Press the Call key to make a call.
- You can input number in this order:
(Area code, phone number, and press the Call key)

3.2 Emergency Calls

You can make emergency calls as long as your current location is covered by the network area. You can check the signal strength bar on the top left corner of the screen.

3.3 Dialing an International Number

Making International calls:

For international calls, long press the “0” key until the “+” sign is shown in the screen then enter the number in the following order:

(“+”, Country code, complete number then press the Call key)

3.4 Rejecting a Call

Press the End key to Reject or cancel an incoming call.

3.5 Missed Calls

The unanswered incoming calls appear on the display screen. Press Middle key to check the details of the missed calls or press Call key to call the number.

3.6 Call Waiting

In this menu, you can activate the call waiting function to be notified of incoming calls while you have a call in progress.

3.7 Call Options

Press the left soft key or the middle key to perform the following options:

- **Mute:** turn on/off microphone.
- **Loudspeaker:** turn on/off the loudspeaker function.

- **Speaker volume:** change the speaker volume.
- **Hold/Remove hold:** Put a call on hold or retrieve a call.
- **Contacts:** enter phonebook menu.
- **Messages:** enter message menu.

4 Alarms

To set an alarm clock, Select alarm then press left soft key and choose from once, Daily, weekly or workday alarm to set the period that it will alarm and then edit its time, date and ring tone.

5 Profiles

Profiles options: General, Meeting, Outdoor, Indoor and Headset.

Select and enter personal settings menu, profile modification are as follows:

- **Tone setup:** lets you specify the ring tone for incoming calls and alerts.
- **Volume setup:** set the volume of the Ring tone, Speaker volume and Key tone.
- **Alert type:** set the ring tone type.

6 Call center

- **All calls:** lists of the missed, dialed and received calls.
- **Missed Calls:** lists the records of missed calls.
- **Received Calls:** lists the records of received calls.
- **Dialed Calls:** lists the records of dialed calls.
- **Call Time:** four sub-menus are provided in Call Duration: Last Call, Dialed Calls, Received Calls and Reset all time.
- **Call settings:**
 - **IP Number:** The mobile phone support IP dial function.
 - **Call firewall:** set the number in the Call firewall list to reject the incoming call(s) of the contact that was set in the Call firewall list,
 - **Barred dial:** to restrict calls
 - **International Calls:** restrict international calls.
 - **All expect home:** restrict all the calls except your home number.
 - **Incoming Calls:** restrict the Incoming of calls
 - **Incoming if abroad:** restrict the Incoming calls if your abroad.
 - **Outgoing Calls:** restrict outgoing calls.
 - **Cancel All Barring:** cancel all the active barred function.
 - **CLIR:** set the call ID to set by network, Hide ID or Send ID.
 - **Call time reminder:** Allow the user to limit the duration of a call.
 - **Connected reminder:** turn on/off this function.
 - **Call Waiting:** You can activate it to be notified of incoming calls while you have a call in progress.
 - **Call Divert:** The call diversion network service permits you to divert an incoming call to another number (designated by you). Select from the options (Divert all voice calls, Divert if unreachable, Divert if no answer, Divert if busy, Divert all data calls and Cancel all divert.)
 - **Divert all voice calls:** divert incoming calls to another number.
 - **If out of reach:** divert incoming calls to another number if you cannot be reached.
 - **If busy:** divert incoming calls to another number when your mobile phone network is busy.
 - **If no answer:** divert incoming calls to another number after your phone rings for a

specified time without answering.

- **Cancel all diverts:** cancel all the active divert call function.

7 Contacts

- **Add new contact:** add a new contact to SIM or phone.
- **Edit:** edit the phonebook details.
- **Delete:** delete the contact details.
- **Search:** input the name you want to search.
- **IP dial:** The mobile phone support IP dial function and set the IP number first.
- **View:** view the contact details
- **Send a message:** send a text message to the selected contact.
- **Send name card:** send the name and number of the selected contact.
- **Add to speed dial list:** set the number corresponding to the numeric keys from 2 to 9, when this function is activated, press and hold the numeric keys to automatically call the specific contact (only in idle state).
- **Call firewall:** set the number in the blacklist number list to reject the incoming call(s) of the
- **Copy:** copy the contact details to the phone or the SIM.
- **Move:** move the contact details to the phone or the SIM.
- **Settings:**
 - **Preferred storage:** select the default storage location.
 - **Used space:** the memory status of SIM card and the phone.
 - **Ringtone:** set the tones of the different group.
 - **Speed dial list:** view the speed dial list.
- **Batch operation:**
 - **Copy SIM to phone:** copy all the SIM contact to phone.
 - **Copy phone to SIM:** copy all the phone contacts to SIM.
 - **Move SIM to Phone:** move all the SIM contact to phone.
 - **Move phone to SIM:** move all the phone contacts to SIM.
 - **Delete all SIM Contacts:** delete all the SIM contacts
 - **Delete all Phone Contacts:** delete all the phone contacts

8 Messages

8.1 Write message

- **Done:** done creating a message and ready to be send.
- **Use templates:** select the template message from the template list.
- **Insert name card:** insert the contact details from the phonebook list to the write message interface.

After editing the message, select “Done” from options to perform the following options:

- **Send:** send the message.
- **Send to many:** send the message to many.
- **Save:** save the message.

8.2 Inbox

- **Reply:** reply a message to the sender
- **Delete:** delete the current message

- **Forward:** send this message to somebody else.
- **Call reply:** call the sender of the message.
- **Extract number:** use the number inside the message.

8.3 Outbox

- **Read:** view the message content.
- **Delete:** delete the current message
- **Send:** send the unsent message.
- **Forward:** send this message to somebody else.
- **Extract number:** use the number inside the message.

8.4 Draftbox

The Drafts stores any messages that you have saved. You can view the messages in the Drafts list.

8.5 Message settings

You can set your SMS through this menu options:

- **Template edit:** edit the template from the template list.
- **Message center:** edit and save the SIM message center.
- **Message validity:** set the message validity period.
- **Delivery report:** turn on/off the delivery report function.
- **Used space:** check the capacity of message storage
- **Preferred Storage:** set the default message storage location, including phone storage and SIM card.
- **Send and save:** turn on/off the send and save function.

8.6 Voicemail

This function needs network support, for activation or details please contact your local network service provider.

8.7 Cell Broadcast

For details should contact your local network service provider.

9 STK

Please contact your service provider about the STK features.

10 Extras

10.1 FM radio

earphones must be plugged in first before you can use the FM radio function.

10.2 Calculator

Calculator functions:

- 1) Press numerical key to input the desired numbers.
- 2) Press navigation keys to operative symbol “+、-、×、÷”.
- 3) Press the left soft key or the middle key to get the result.
- 4) Press right soft key to clean screen information. When all the character is cleaned, you press right soft key to exit the function.

10.3 World Clock

Enter World Clock from the Organizer and you can see a picture of the world time zone. Move the Left and right navigation key to view the current time in any city. Press left soft key to save the selected country as the default city.

10.4 Calendar

Press the 4-way navigation key up, down, left or right to move to different date or press the left soft key “Goto” to go to specific date you want.

11 Settings

11.1 Phone settings

- **Language:** set your phone's display language.
- **Clock settings:** set your current time/date, format and display of date and time.
- **Display settings:**
 - **Wallpaper:** set the standby image.
 - **Brightness:** set the brightness of the LCD.
 - **Backlight:** set the backlight time of the LCD.
 - **Display operator name:** turn on/off the display operator name.
- **Dedicated key:** Set the function of navigation keys in idle screen
- **Own number:** set or add your own number.
- **Greeting text:** Set/edit the greeting text function
- **Poweron ring:** Set on/off the poweron ring
- **Poweroff ring:** Set on/off the poweroff ring

11.2 Network settings

Set the network selection mode to Automatic or Manual.

11.3 Security settings

- **Auto lock keypad:** Activate the Auto keypad lock function and set the time in which the keypad should be lock.
- **PIN code:** SIM protection code.
- **Phone code:** this function prevents the illegal use of your phone.
- **Fixed dial:** When this function is activated, you may only dial the numbers that are in the fixed dialling list, or numbers that have the same initial numbers as those on the fixed dialling list.
- **Change password:** Set a new password. The default value of Phone Lock is 123456; please change it as soon as possible.

11.4 Restore factory settings

This function lets you restore the initialized settings.

Note: The default value of Restore Factory Setting password is: "123456".

12 Games

This mobile phone has games for you to enjoy.

FCC Compliance

FCC ID:A2F-PB100

This device complies with part 15 of the FCC Rules. Operation is subject to the condition that this device does not cause harmful interference.

Caution: Changes or modifications not expressly approved by the manufacturer could void the user's authority to operate the equipment.

This mobile phone meets the government's requirements for exposure to radio waves.

This Mobile phone is designed and manufactured not to exceed the emission limits for exposure to radio frequency (RF) energy set by the Federal Communications Commission of the U.S. Government: The exposure recommendations for mobile phones use a measurement unit known as the Specific Absorption Rate (SAR). The SAR limit set by the FCC is 1.6W/kg. The highest SAR value for this model phone when tested was 0.758W/kg at ear and 0.688 W/kg at the body worn .

For body worn operation, this phone has been tested and meets FCC RF exposure guidelines when used with an accessory that contains no metal and that positions the handset a minimum of 15mm from the body. Use of other accessories may not ensure compliance with FCC RF exposure guidelines.