

Setup Photographs

<Radiated Emission>


<Primary Antenna>


X Plane with Adapter for EN-DC 2A-n12A and EN-DC 2A-n71A


LF




HF



SHF

Y Plane with Adapter for EN-DC 7A-n5A and EN-DC 14A-n2A**LF****HF**


SHF


**Z Plane with Adapter for EN-DC 26A-n25A, EN-DC 71A-n66A and
EN-DC 28A-n7A**

LF



HF



SHF


<ASDIV Antenna>


Y Plane with Adapter for EN-DC 7A-n5A, EN-DC 14A-n2A and EN-DC 26A-n25A

LF



HF




SHF

Z Plane with Adapter for EN-DC 2A-n12A, EN-DC 71A-n66A, EN-DC 28A-n7A and EN-DC 2A-n71A


LF



HF



SHF



————THE END————